



JN5169-001-M03-2 label location



Label location is on top of the module. It's laser marked on the metal shield