
Label location: LABEL will be attached on the bottom of the Antenna Unit



## Label drawing:

for Primary Antenna Unit



for Secondary Antenna Unit

