
Label location and sample LABEL LOCATION and Drawing:

LABEL will be attached on the bottom of the Primary and Secondary Antenna Unit

[Primary Antenna Unit]





[Secondary Antenna Unit]



