

## USER INSTRUCTIONS AND SAFETY

Congratulations on your purchase of an N-Com product.

N-Com **B901** was made using the most advanced technologies and the best materials. Long-running tests and thorough system development have allowed the highest audio quality to be achieved.

For additional information about **B901** visit the website [www.n-com.it](http://www.n-com.it)

Firmware version: **1.0x**

### REFERENCE STANDARDS




The products of the N-Com line are in compliance with standards as per the table below:

<b>B901</b>	The Bluetooth system complies with the main safety requirements and other applicable provisions of Directive 99/5/CE, Directive 2009/65/EC, Directive 2011/65/CE, Directive 2012/19/EU
-------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<b>Battery charger</b>	Directive 2006/95, 2004/108, 2009/65/EC, 2011/65/CE, 2012/19/EU, 2009/125/CE
------------------------	------------------------------------------------------------------------------

<b>Battery</b>	Directive 2006/66/CE
----------------	----------------------

The Declarations of Compliance can be downloaded from the website [www.n-com.it](http://www.n-com.it) (Download section).

FCC ID: <b>Y6MNCOM17</b>	IC: <b>9455A-NCOM17</b>			
--------------------------	-------------------------	-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------

*The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by N-Com is under license. Other trademarks and trade names are those of their respective owners.*

# Contents

<b>1. WARNINGS AND SAFETY</b> .....	<b>4</b>
1.1.Road safety .....	4
1.2.Switching on the system in safe environments .....	4
1.3.Interferences .....	4
1.4.Appropriate use .....	4
1.5.Qualified personnel .....	5
1.6.Accessories and batteries .....	5
1.7. Disposal .....	5
<b>2. CONTENT OF THE PACKAGING</b> .....	<b>6</b>
<b>3. INSTALLATION</b> .....	<b>7</b>
3.1.Installing the microphone .....	9
3.2.Installing the system on the helmet .....	10
<b>4. REMOVING THE SYSTEM</b> .....	<b>13</b>
<b>5. BASIC FUNCTIONS</b> .....	<b>14</b>
5.1.Volume adjustment.....	14
5.2.Auto On / Off function .....	14
5.3.N-Com EASYSET .....	14
<b>6. CONFIGURATION MENU</b> .....	<b>15</b>
<b>7. PAIRING UP WITH MOBILE PHONES OR OTHER BLUETOOTH DEVICES</b> .....	<b>16</b>
<b>8. MOBILE PHONE</b> .....	<b>16</b>
8.1.Speed dialling .....	16
8.2.Conference call function .....	17
<b>9. MANAGING TWO MOBILE PHONES (OR BLUETOOTH DEVICES)</b> .....	<b>18</b>
<b>10. MUSIC VIA BLUETOOTH</b> .....	<b>18</b>
10.1.Sharing music via Bluetooth ( <i>A2DP Sharing</i> ).....	18
<b>11. MUSIC VIA CABLE</b> .....	<b>19</b>
<b>12. SATELLITE NAVIGATOR FOR MOTORCYCLES</b> .....	<b>19</b>
<b>13. FM RADIO</b> .....	<b>19</b>
<b>14. N-COM INTERCOM (SERIES "900")</b> .....	<b>20</b>
14.1.Intercom pairing up.....	20
14.2.Intercom function (one-to-one connection).....	20
14.3. <i>Smart Conference</i> (Group Intercom) .....	21
<b>15. "UNIVERSAL INTERCOM" INTERCOM</b> .....	<b>22</b>
15.1.Pairing up the UNIVERSAL INTERCOM.....	22
15.2.Universal Intercom Function.....	22
15.3.Universal Conference (chain intercom).....	23
<b>16. REMOTE control</b> .....	<b>25</b>
<b>17. BATTERY</b> .....	<b>25</b>
17.1.Low battery signal .....	25
17.2.Charging the system .....	25
<b>18. SUMMARY TABLE OF CONTROLS</b> .....	<b>26</b>
<b>19. LIMITED WARRANTY</b> .....	<b>28</b>
19.1.Warranty coverage.....	28
19.2.Exclusions and limitations of the coverage .....	28
19.3.Validity of this limited warranty .....	29
19.4.Procedure for the forwarding of claims .....	29
19.5.Product identification .....	29
<b>20. WARRANTY REGISTRATION FORM</b> .....	<b>30</b>

## 1. WARNINGS AND SAFETY

Read this User Manual carefully, as well as the User Manuals for other N-Com kits that you will be using with the N-Com **B901**. Read the simple rules listed below. Failure to comply with these rules may lead to dangerous situations.

**Caution:** The product cannot be used in official or non-official competitions, motordromes, circuits, racing tracks and the like.

**Caution:** Installation of the N-Com **B901** system results in a weight increase of approximately 110g, which is added to the weight of the helmet and of the other accessories.

**Warning:** The electronic components of the N-Com system mounted inside the helmet are not waterproof. Consequently, make sure the inside of the helmet, including the comfort padding, does not get wet in order to avoid damage to the system. If it does, remove the N-Com system and the helmet comfort padding and let it air dry. Disconnect the battery connector and let it dry as well.

### 1.1. Road safety

Always obey all Traffic Regulations in force. While riding the motorcycle, your hands should always be engaged in actually riding the vehicle. Any operation to the N-Com system must be carried out with the vehicle stopped. Specifically:

- Set your cell phone on automatic answer (see the cell phone instructions to do this).
- If your cell phone is not equipped with this function, first stop your vehicle in a safe area, in compliance with Traffic Regulations and then answer the call.
- Do not make any calls while riding. Stop your vehicle in a safe place in compliance with Traffic Regulations, and then make the call.
- Adjust the volume so that it does not cause a disturbance or distraction while riding and at the same time allows you to distinctively hear background noises.
- Do not operate your cell phone or other devices connected to N-Com while riding your motorcycle.
- In all cases, obey the Traffic Regulations and remember that riding the motorcycle has absolute priority over any other maneuver.

### 1.2. Switching on the system in safe environments

- When using the N-Com system, comply with all limitations and instructions related to the use of cell phones.
- Do not turn on your cell phone or the N-Com system whenever their use is forbidden or when the devices can cause interference or dangerous situations.
- Turn off while refueling. Do not use the N-Com system in filling stations. Do not use the device near combustible materials or chemical products.
- Turn off in proximity to explosive materials.

### 1.3. Interferences

All phones and devices with wireless signal transmission are subject to interferences that may affect the performance of the device connected to them. These interferences are not ascribable to a defect of the N-Com system.

### 1.4. Appropriate use

Use the device only in the normal position, as described in the product documentation. Do not attempt to disassemble, tamper with or modify any part of the N-Com system.

**Caution:** Adjust the volume of the N-Com system (where provided) and of the audio sources connected to it before you use the system on the road.

**Caution:** Adjusting the volume to very high levels may cause damage to your hearing.

**Caution:** Adjust the volume of the N-Com system (where provided) and of the audio sources connected to it so as to avoid audio reproduction at high volumes. Constant exposure to high audio volumes may damage your hearing.

**Caution:** An incorrect installation of the system in the helmet may alter the aerodynamic and safety characteristics of the helmet itself, thus creating dangerous conditions. Install the N-Com system according to the instructions provided in the product documentation. In case of doubt, please contact your local N-Com dealer.

**Warning:** Listening to other equipment should not interfere with driving the vehicle, which must be the top priority at all times. Carry out all operations on the electronic equipment and on the N-Com system with the vehicle stopped, in compliance with Traffic Regulations.

**Caution:** B901 allows radio reception. Any radio licence fees are to the user's charge.

## 1.5. Qualified personnel

- Only qualified personnel can carry out technical assistance on this product. In case of any malfunction, always turn to your local dealer.
- The helmet is a safety device. Tampering with it and/or with the electronic system inside the helmet, in addition to invalidating the product warranty, can also lead to dangerous situations.

## 1.6. Accessories and batteries

- Only use the type of batteries, battery chargers and accessories approved by Nolan for the specific model.
- The use of a battery type different from the recommended one may lead to dangerous situations and invalidate the warranty.
- Contact your local dealer to see about the availability of approved accessories.
- When disconnecting the power supply cable of any accessory or of the battery charger, always grab and pull the plug not the cable.
- Do not use batteries for purposes other than the prescribed ones.
- Never use batteries or battery chargers that turn out to be damaged.
- Do not short-circuit the battery.
- **Keep the battery at a temperature between 0° / +45°C (charging); -20° / +60 °C (in use).**
- Danger of fire or explosion: do not throw the batteries into a fire nor expose them to high temperatures!
- Do not throw out batteries together with household refuse. The batteries should be disposed of in compliance with local regulations
- Do not wear the helmet while the battery is recharging.
- The helmet should never be left within the reach of unsupervised children in order to prevent damage to their health caused by access to the batteries.

<b>Battery</b>	Li-Po PL053448P	3,7V – 1000 mAh
<b>Battery charger</b>	S-TR-009L	100/240V – 50/60 Hz 5V - 0.5 A

## 1.7. Disposal

Refer to this user manual and to manuals related to other parts of the N-Com system in order to disassemble the system from the helmet. Once the system has been disassembled, dispose of it according to the following instructions:












- The presence of a crossed-out wheeled bin indicates that in the European Union the product is subject to separate collection at the end of its useful life (European Directive 2002/96/EC).
- Do not dispose of these products together with undifferentiated urban waste.

- The proper disposal of obsolete equipment contributes to preventing possible negative consequences on people's health and on the environment.
- For more detailed information on the disposal of obsolete equipment, contact your municipality, a waste disposal service or the store where the product was purchased.

## 2. CONTENT OF THE PACKAGING

The N-Com **B901** package contains:

			
<p><b>e-box B901</b></p>	<p><b>Electronic plate</b></p>		
			
<p><b>Microphone</b></p>	<p><b>Rechargeable battery</b></p>	<p><b>Battery charger</b></p>	
			
<p><b>PC connection cable</b></p>	<p><b>Battery holder</b></p>	<p><b>Key, screw, clamp Microphone-Stop</b></p>	<p><b>Adhesive Velcro pads</b></p>

### 3. INSTALLATION

You can download the installation video from [www.n-com.it](http://www.n-com.it) N-Com / Download section.




Fig. 1



Fig. 2



Fig. 3

- Remove the "N-Com" protection plate located on the helmet shell (Fig. 1) and open the helmet chin guard (flip up helmets).
- Remove the right and left cheek pads from the helmet (see specific instructions provided in the user manual of the helmet).
- Remove the Noise Reducers from the two cheek pads, and tear off the pre-cut plastic (if equipped).




Fig. 4




Fig. 5



Fig. 6




Fig. 7




Fig. 8

- Remove the back of the comfort padding by pulling on the neck roll until it separates from the shell (Fig. 4).
- Temporarily put the padding on the outside of the helmet (Fig. 5).
- Remove the N-Com cover from the helmet border gasket. Push from the inside of the helmet to facilitate the removal (Fig. 6).

#### **ONLY FOR FULL-FACE HELMETS**

- Remove the chin guard by pulling on the special red tab.

- Remove the right and left polystyrene cheek pads by gently pulling them out of the helmet. The helmet shell can be opened slightly to facilitate the removal of the cheek pad.

**Caution:** In case the polystyrene cheek pad is damaged during this operation, turn to your local dealer for its replacement.

### 3.1. Installing the microphone

#### JET HELMETS OR FLIP-UP HELMETS



Fig. 9



Fig. 10




Fig. 11




Fig. 12

- Prepare the microphone by inserting the microphone clamp, being careful to position it properly (Fig. 9)

**Note:** the flat part of the clamp must be facing upward when the microphone is positioned as shown in figure 11.

- Position the microphone in its support as shown in figure 10, being careful that the fluorescent clamp is facing toward the inside of the helmet.
- Insert screw in the microphone clamp; use the key to screw in the microphone securing screw to the shell frame.

#### FULL-FACE HELMETS

- Take the polystyrene cheek pad (left-hand side) and position the microphone in its housing, as shown in fig. 13, making sure that the fluorescent band stays facing the inside of the helmet. (Fig. 14)



Fig. 13




Fig. 14



### 3.2. Installing the system on the helmet




Fig. 15

- Position the system inside the helmet as shown in figure 15, next to the N-Com housing in the shell.




Fig. 16

- Looking at the helmet from the outside, slide the rear positioning tab into groove A as shown in the figure;
- Press in the area marked PUSH from inside the helmet until the fastening clasp B clicks (Fig. 16).



Fig. 17

- Pull out the connectors area from the helmet gasket: the gasket will have to be slightly deformed to facilitate the insertion.

- Insert the microphone connector in the micro USB electronic plate.
- Before you place the speaker in its housing, apply the Velcro pad to the polystyrene cheek pad (Fig. 19).



Fig. 18




Fig. 19



Fig. 20

- Position the loudspeaker in the special housing obtained in the polystyrene cheek pad (Fig. 20).



Fig. 21

- Replace the polystyrene cheek pad (left side), positioning the cable in the groove that you see in the cheek pad (Fig. 20).

**Note:** Make sure the cheek pad is properly positioned in its housing, pushing in the lined corner underneath the ribbing on the shell (Fig. 21).



Fig. 22

#### ONLY FOR JET HELMETS OR FLIP-UP HELMETS

- Secure the battery-holder support to the right side of the helmet, lining up the holes with the pins on the shell (Fig. 22)



Fig. 23

#### ONLY FOR FULL FACE HELMETS

- Position the battery in the right polystyrene cheek pad housing (Fig. 23).

- Before you place the speaker in its housing, apply the Velcro pad to the polystyrene cheek pad (right side).
- Position the loudspeaker in its housing obtained in the polystyrene cheek pad (right side).
- Replace the polystyrene cheek pad (right side), positioning the cable in the groove you see in the cheek pad.



Fig. 24

#### ONLY FOR FULL-FACE HELMETS

- Insert the chin guard (microphone side), gently placing the microphone in its housing. Then press down on the red tab until the chin guard is locked in place on the helmet. (Fig. 24)



Fig. 25



Fig. 26

- Position the comfort padding in its housing (see specific instructions provided in the helmet user manual), hooking the neck roll (Fig. 25).
- Position both the comfort cheek pads in their housing (see specific instructions provided in the helmet user manual) making sure that all the press-studs click.

**Note:** Carefully check the proper final positioning of the cheek pad, pulling the chinstrap toward the inside of the helmet and testing the press-studs.

**Caution:** Make sure that there are no cables sticking out of their housing.

**Caution:** Always verify the proper length of the chinstrap and adjust it as necessary, once again referring to the specific helmet instructions.

- Position the e-box in the relevant housing. First insert the front part, then press down on the e-box until both hooks fully click. To remove the e-box, press the two sliding hooks at the same time until the e-box comes out.

**Warning:** Do not leave the helmet exposed to atmospheric agents without the e-box or the protection plate provided with the helmet.

#### 4. REMOVING THE SYSTEM




Fig. 27

- To remove the system from the helmet, remove the earphone and the comfort cheek pads as shown in the assembly operations. Then remove the polystyrene cheek pads. Remove the protection plate, then, looking at the helmet from the outside, release the connector by acting on the fastening clasp as illustrated in the figure.

- After releasing the connector from the shell, also remove the right part by releasing the battery holder.
- Now remove the entire system from the helmet.

## 5. BASIC FUNCTIONS

<b>System ON</b>	Press " <b>ON</b> " and keep it pressed for about 2 seconds, until the LEDs turn on and you hear the voice announcement.
<b>System OFF</b>	Press " <b>ON</b> " and keep it pressed for about 3 seconds, until the LEDs turn off and you hear the voice announcement.

### 5.1. Volume adjustment

You can easily adjust the volume by tapping the "▲" button or the "▼" button. You will hear a beep when the volume reaches the maximum or minimum level.

The volume is independent for each sound source. Once it is set for a specific source (phone call, radio, Mp3), it will remain in memory even after the system is switched off.

However, if you adjust the volume during stand-by mode, it will affect volume levels of every audio source.

### 5.2. Auto On / Off function

If the helmet does not move for more than 60 seconds, the **B901** system goes into "deep sleep" mode. The system is completely turned on as soon as movement is detected.

If the system is in "deep sleep" mode for more than 3 days, it turns off completely. To turn it back on, the "**ON**" key needs to be pressed.

### 5.3. N-Com EASYSET



"N-Com EASYSET" is the application that can be used to manage and configure the **B901** system. The programme can be downloaded from the Internet site [www.n-com.it](http://www.n-com.it), in the "Download" section. The functions that can also be managed from the N-Com EASYSET are listed here below with the specific icon.



The N-Com system can be managed from the dedicated App "N-Com EASYSET", which makes it possible to configure and control the N-Com system directly from your Smartphone.

The N-Com APP can be downloaded free of charge from Google Play or Apple Store. For additional details, please visit the website [www.n-com.it](http://www.n-com.it)

The functions that can also be managed from the N-Com EASYSET App are listed here below with the specific icon.

## 6. CONFIGURATION MENU

All Bluetooth pair ups and other adjustments are carried out in this mode.

To put the system in "Configuration mode" (starting from a switched off system) press the "ON" key and keep it pressed for 4 seconds, until the blue LED starts flashing quickly and you hear the voice announcement "*Configuration*".

Once in the "Configuration" menu, press the keys "▲" and "▼" to scroll through the various menu items.

In the items marked with an "\*", it is possible to enable / disable the function or carry out the commands by pressing the "ON" key to confirm.

The following items make up the "Configuration" menu:

- A. **Mobile phone pair up** (chapter 7)
- B. **Intercom pair up** (chapter 14)
- C. **Universal Intercom pair up** (chapter 15)
- D. **Second mobile phone pair up** (chapter 9)
- E. **Remote control pair up** (chapter 16)
- F. **Speed dialling\*** (chapter 8.1)
- G. **Audio boost \***

By enabling the "Audio boost" (Audio Boost), all the audio sources inside the device will be reproduced at a higher and potentially less clear volume.

Press the "ON" confirmation key to enable / disable the function, which is not enabled by default on the device.

- H. **Delete all pair ups\***

In order to delete all Bluetooth pair ups stored in the device, press the key "▲" or "▼" until you hear the voice announcement "*Delete all pair ups*".

Press the "ON" confirmation key to delete all Bluetooth devices stored in memory.

- I. **Reset\***

In order to restore the factory settings of the device, press the key "▲" or "▼" until you hear the voice message "*Reset*".

Press the "ON" confirmation key to restore all the factory settings of the device.

- J. **Exiting the configuration\***

To exit the "Configuration" menu, press the key "▲" or "▼" until you hear the voice announcement "*Exit the configuration menu*".

Press the "ON" confirmation key to exit the "Configuration" menu.

If no key is pressed within 10 seconds, the device automatically exits the "Configuration" menu.

## 7. PAIRING UP WITH MOBILE PHONES OR OTHER BLUETOOTH DEVICES

- Make sure the B901 is turned off;
- Put the system in the "Configuration" mode, then press the "ON" key and keep it pressed for 4 seconds until the blue LED starts flashing quickly;
- Press the key "▲" to access the "Mobile phone pair up mode".
- Turn on the search for Bluetooth devices (smartphone, GPS, MP3 reader) on the device;
- Select the N-Com device. If a password is requested, enter 0000 (four zeros);
- Connection between the two devices is established after a few seconds.

**Note:** The affiliation is stored in the helmet and in the cell phone and it is not lost when the two devices are turned off. As a result it needs to be carried out only once.

<b>Automatic Connection</b>	Once the Bluetooth device has been paired up, connection is automatic when the system is turned on.
<b>Manual Connection</b>	In case connection is not automatically initiated after a few seconds, you can connect from the Bluetooth device or by pressing "ON" and keep it pressed for about 2 seconds.

## 8. MOBILE PHONE

Per affiliare un telefono cellulare al sistema B901 seguire la procedura illustrata al Cap. 7.

<b>Answering a phone call</b>	Briefly press any key when you hear the incoming call signal.
<b>Vocal answer</b>	When you hear the ringtone, say any word out loud.
<b>Voice call</b>	Press "ON" and keep it pressed for about 2 seconds.
<b>Hanging up/rejecting a phone call</b>	Press "ON" and keep it pressed for about 2 seconds.
<b>Manual phone connection</b>	Press "ON" and keep it pressed for about 2 seconds.

### 8.1. Speed dialling



Using the N-Com EASYSET program or the N-Com EASYSET App, you can store up to 3 of your favourite numbers, which you will be able to dial from the "Speed Dialling" menu.

#### Saving the Speed Dialling numbers

To assign one or more speed dialling numbers:

- Put the system in the "Configuration" mode: starting from a switched off system, press the "ON" key and keep it pressed for 4 seconds, until the blue LED starts flashing quickly and you hear the voice announcement "**Configuration**".
- Press the key "▲" or "▼" until you hear the voice command "**Speed dialling**".
- Press the "ON" confirmation key. You will hear the voice announcements "**Speed dialling 1**" and "**Phone connected**".
- Press the keys "▲" or "▼" to select the speed dialling number to be assigned. The saved position is confirmed by the voice announcement "**Speed dialling 1** / "**Speed dialling 2**" / "**Speed dialling 3**".

- On your own mobile phone (paired up and connected to the N-Com system), call the phone number you wish to assign to the selected speed dialling position. The call is interrupted before it goes through, and the selected number will be saved; at this point you will hear the special voice announcement confirming the selection ("*Save Speed Dialling 1*" / "*Save Speed Dialling 2*" / "*Save Speed Dialling 3*").



You can also configure these setting through the program "N-Com EASYSET" or through an Android Smartphone, iPhone, iPad on which the "N-Com EASYSET" App has been installed.

### Using the stored numbers

To access the "Speed Dialling" menu, press at the same time the "ON" and "N" keys ("*Speed Dialling*"), then use the keys "▲" and "▼" to scroll through the menu items.

Then press the "ON" key to confirm the selection of one of the following items:

- *Call Last Number Dialed*
- *Speed Dialling 1*
- *Speed Dialling 2*
- *Speed Dialling 3*
- *Cancel*

If you wish to exit the "Speed Dialling" menu, press the keys "▲" and "▼" until you hear the command "*Cancel*", then press "ON" to confirm.

**N.B.:** If no key is pressed within 15 seconds, the system exits the "Speed Dialling" menu.

## 8.2. Conference call function

When a call comes in on a mobile phone connected via Bluetooth to **B901**, the intercom is temporarily turned off. However, if you wish to share the phone call with the other helmet, simply turn on the intercom manually during the phone call.

Turning on the phone conference call function	During the phone call, briefly press "ON" (channel 1). During the phone call, press the "ON" key twice (channel 2). During the phone call, press the "ON" key three times (channel 3).
Turning off the phone conference call function	During the phone call, briefly press "ON".



## 9. MANAGING TWO MOBILE PHONES (OR BLUETOOTH DEVICES)

The **B901** system can be hooked up to two phones (or Bluetooth) devices at the same time. The second phone (secondary device) can receive calls but not make them.

To pair up the second Bluetooth phone (secondary device):

- Make sure the B901L is turned off;
- Put the system in the "Configuration" menu: press the "ON" key and keep it pressed for 4 seconds, until the blue LED starts flashing quickly;
- Press the pushbutton "▲" until you reach the option "*Pair up second mobile phone*".
- Turn on the search for Bluetooth devices (smartphone, GPS, MP3 reader) on the device;
- Select the N-Com system from the list. If a password is requested, enter the code 0000 (four zeroes);
- After a few seconds, the connection between the two devices is activated.

Once the Bluetooth device has been paired up, connection is automatic when the system is turned on.

## 10. MUSIC VIA BLUETOOTH

Per affiliare un lettore Mp3 al sistema B901 seguire la procedura illustrata al Cap. 7.

<b>Play music (Play)</b>	Press "▲" for 2 about seconds.
<b>Pause function (Pause)</b>	When the player is connected and playing music, press "▲" for 2 about seconds.
<b>Next track (Skip)</b>	When the player is playing music, press "▲" for 3 about seconds.
<b>Previous track (Rew)</b>	When the player is playing music, press "▼" for 3 about seconds.

### 10.1. Sharing music via Bluetooth (*A2DP Sharing*)

Durante il collegamento interfono, è possibile avviare la riproduzione musicale il tasto "▲" per circa 2 secondi. The music will be played in both systems.

Music sharing temporarily cuts off the intercom conversation; however, this can be automatically restored by stopping the music (this is done by briefly pressing the "ON" key).

**N.B.:** Music shared through the intercom can be managed by both systems, for example, both systems can change the track by pressing the relative command.

## 11. MUSIC VIA CABLE

Connect the mini USB connector of the Multimedia Wire (not included) to the helmet and the other end to the audio device. A coloured band on the cable indicates the connector to be hooked up to the audio device.

Turning on the cable audio	Premere contemporaneamente i tasti "ON" e "▲".
Turning off the cable audio	Premere contemporaneamente i tasti "ON" e "▲".

## 12. SATELLITE NAVIGATOR FOR MOTORCYCLES

**B901** system is compatible with the most common satellite navigators for motorcycles. For a list of compatible models and additional details, visit the website [www.n-com.it](http://www.n-com.it)

To pair up a satellite navigator to the **B901** system, follow the procedure illustrated in Chapter 6.

**N.B.:** Intercom connection is automatically cut off every time the navigator gives directions and restored at the end of the message from the navigator.

## 13. FM RADIO

Turning on the radio	Press "▼" for 2 about seconds.
Turning off the radio	Press "▼" for 2 about seconds.
New station automatic search	Press "▲" and keep it pressed for 2 seconds.
Pre-setting a radio station (max. 10 stations)	Press the key "▼" and keep it pressed for about 4 seconds. Select the pre-setting position using the keys "▲" and "▼". Saving is confirmed by means of a voice message.
Changing radio stations (among the pre-set ones)	Press "▼" and keep it pressed for 2 seconds.



This function can also be turned on using the "N-Com EASYSET" programme or through the "N-Com EASYSET App" for Smartphone Android, iPhone, iPad.

## 14. N-COM INTERCOM (SERIES "900")

The N-Com B901 system allows communication with other N-Com systems, up to a distance of about **700 m** (in open field, with no obstacles).

**Important:** The procedure described below refers exclusively to the pairing up and operation between the B901 and the "900" series N-Com systems.

To pair up to N-Com systems of a range other than the "900" series, please refer to the procedure described in chapter 15 "Universal Intercom".

**N.B.:** The range and quality of the communication may vary significantly depending on the presence of obstacles, weather conditions, magnetic fields.

**N.B.:** The range of the communication varies depending on the N-Com systems used.

### 14.1. Intercom pairing up

- Make sure the B901 is turned off;
- Put the systems in "Configuration" mode: press the "ON" key and keep it pressed for 4 seconds, until the blue LED starts flashing;
- On both systems, press the key "▲" until you reach the option "*Intercom pair up*";
- On system A, press the key pertaining to the "pre-setting position" where you wish to save system B.

<b>Pairing up CHANNEL 1</b>	Briefly press "ON".
<b>Pairing up CHANNEL 2</b>	Press the "ON" key twice.
<b>Pairing up CHANNEL 3</b>	Press the "ON" key three times.

The Intercom connection with the selected channel is automatically activated at the end of the pair up procedure.

### 14.2. Intercom function (one-to-one connection)

To establish an Intercom connection with one of the systems stored in memory, simply press the command related to the channel where the system was saved.

<b>Connection CHANNEL 1</b>	Briefly press "ON".
<b>Call CHANNEL 2</b>	Press the "ON" key twice.
<b>Call CHANNEL 3</b>	Press the "ON" key three times.
<b>Disconnection of active intercom</b>	Briefly press "ON".

The B901 system is equipped with the VOX function, which makes it possible to switch the intercom on and off vocally. Once the intercom is manually activated for the first time, the B6L system detects your voice and automatically activates/deactivates the communication.



You can enable / disable the "VOX" function and set the activation sensitivity, using the N-Com EASYSET program or the N-Com EASYSET APP.

The VOX function is disabled by default on the device.

**N.B.:** In case the pre-setting position is empty, or the system being called cannot be reached within the maximum range or it is already engaged in a phone call, you will hear an error voice message.

**N.B.:** In case the Intercom connection system falls outside the range (Intercom connection interrupted), the B901L system will automatically try to reconnect every 8 seconds. Double beeps will be emitted until the Intercom connection is not restored.


If you do not want automatic reconnection, press the "ON" key to stop the automatic reconnection attempts.

### 14.3. Smart Conference (Group Intercom)

Thanks to the "Smart Conference" function, you can start the conference communication between N-Com intercom systems of the "900" series previously paired up and saved in the 3 available channels. All systems must be turned on and available within the connection range.


1. Each system must have been previously paired up to all the other systems: B, C and D.

←-----→ AFFILIAZIONE



2. Qualsiasi sistema può premere contemporaneamente i tasti "▲" e "▼" per attivare l'Interfono di Gruppo e avviare una comunicazione in conferenza tra tutti i sistemi.

←-----→ CONNESSIONE



- In the case where one of the systems presses the "N" key or falls outside the connection range, the group intercom is interrupted.

<b>Smart Conference connection</b>	Premere contemporaneamente i tasti "▲" e "▼". Activation is confirmed by a beep in the helmet and by the voice message " <i>Group Intercom</i> ".
<b>Smart Conference disconnection</b>	Briefly press the "ON" key. Disconnection is confirmed by the voice announcement " <i>Group Intercom ended</i> ".

**N.B.:** During a "Smart Conference" call, connection to the mobile phones of all participants is temporarily cut off. When the conference call ends, all phones automatically reconnect to their own intercom system.

## 15. "UNIVERSAL INTERCOM" INTERCOM

The N-Com B901 system can be connected via Bluetooth to intercom systems of other brands or to N-Com systems other than the "900" series, thanks to the UNIVERSAL INTERCOM function.

**Important:** N-Com systems other than the "900" series must be paired up to the N-Com B901 by following the procedure "*Pairing up the Universal Intercom*".

**Caution:** Visit the [www.n-com.it](http://www.n-com.it) website for the list of compatible N-Com systems.

### 15.1. Pairing up the UNIVERSAL INTERCOM

The N-Com system can be paired up to the other intercom (from now on referred to as Intercom **B**) as if it was a mobile phone.

- Make sure the B901 is turned off;
- Put the system in the "Configuration" mode: press the "ON" key and keep it pressed for 4 seconds, until the blue LED starts flashing;
- Press the pushbutton "▲" until you reach the option "*Universal intercom pair up*" mode.
- Put intercom B in the mobile phone pairing up mode (refer to the Intercom B manual);
- After a few seconds, Intercom B will emit the "phone connection" confirmation beep;

**N.B.:** The system paired up using the UNIVERSAL INTERCOM is saved in the first available channel.

### 15.2. Universal Intercom Function

To turn on and off the audio between two helmets, proceed as follows:

#### **From the N-Com B901 system:**

Connect or disconnect Intercom B as you would for a regular N-Com intercom (chapter 14). Intercom B may receive a dialing one that must be answered with a phone reply command.

#### **From intercom B**

Press the "Voice call / Dial last number called" command.

To disconnect the intercom, press "Voice call / Dial last number called" once again.

**N.B.:**

- The N-Com B901 systems keeps an active connection with a mobile phone or a GPS even during Bluetooth communication with other intercom systems.
- The intercom system connected to N-Com B901 may not allow simultaneous connection to a mobile phone.
- Only one system paired up in Universal Intercom mode can be stored.

**15.3. Universal Conference (chain intercom)**


The "Universal Conference" mode can be used to connect in conference call N-Com systems of the "900" series and one system paired up in Universal Intercom mode.

**N.B.:** This mode can also be used by connecting only N-Com "900" series systems, in alternative to the "Smart Conference" mode (chapter 14.3).

The connection procedure is outlined in the diagram provided here below:


1. System A must have been paired up beforehand to two B systems (Universal Intercom pair up) and C.

←-----→ AFFILIAZIONE




2. System A has to initiate the first intercom connection with system B (Universal Intercom), by pressing the relative intercom connection command.

←-----→ AFFILIAZIONE  
 ←=====→ CONNESSIONE



3. At this point, system C can join the intercom conference call, establishing an intercom connection with system A.

←→ CONNESSIONE



4. The three systems are not in intercom conference call mode and can talk to each other at the same time. All intercom conference call systems can be disconnected by briefly pressing the "ON" command on any one of the devices connected in conference call.
5. In case you wish to add another system (D), the latter must be paired up beforehand to system C. Press the relative connection command to start a 4-participant intercom conference call.

**N.B.:** The "Universal Conference" mode (chapter 14.3) **CANNOT** be used with systems paired up in Universal Intercom mode.

## 16. REMOTE CONTROL

The B901 device can be controlled through a remote control (sold separately), thus avoiding the need to take your hands off the handlebars to use the keyboard.


Please refer to the specific operating instructions of the Remote Control in order to use its various functions.

## 17. BATTERY

### 17.1. Low battery signal

During its operation, the system alerts the user with a voice message when the battery is low. From the first message, the system has a 1-hour autonomy. Warning is given every 10 minute.

### 17.2. Charging the system



- To charge the system, hook it up to the battery charger or to a USB outlet powered with the USB-mini USB cable supplied as standard equipment. The charge will take place as follows:

<b>B901 system turned off</b>	When the <b>B901</b> system is connected to the battery charger, the blue LED starts to flash quickly. When the battery is charged, the blue LED becomes steady.
<b>B901 system turned on</b>	When the <b>B901</b> system is connected to the battery charger, the blue LED starts to flash quickly. When the battery is charged, the blue LED goes back to its standard flashing.

**N.B.:** If the device has not been charged for a long time (a few months), it may not be possible to turn on the system during the first few minutes of the charging, as the voltage may drop below the minimum limit.

The distance between the antenna of the device and the head surface is at least 35 mm and use 35mm or more.

La distancia entre la antena del dispositivo y la superficie de la cabeza es de al menos 35 mm y utilice una parte de 35 mm o mas.



## 18. SUMMARY TABLE OF CONTROLS

		<i>Button</i>	ON	▲	▼	▲ + ▼
<b>Basic Functions</b>	Turning on		2 sec			
	Turning off		3 sec			
	Increase Volume			X		
	Decrease Volume				X	

<b>Bluetooth Devices</b>	Answer phone call*	X	X	X	
	Voice call	2 sec			
	Speed Dialling Menu **	X		X	
	Hang up/reject a phone call	2 sec			
	Manual Device Connection	2 sec			
	Phone Conference Activation CHANNEL 1	X			
	Phone Conference Activation CHANNEL 2	x2			
	Phone Conference Activation CHANNEL 3	x3			
	Turning off the Conference function	X			

<b>Bluetooth Music / Cable</b>	Play music (Play)		2 sec		
	Pause Function (Pause)		2 sec		
	Next track (Forward)		3 sec		
	Previous track (REW)			3 sec	
	Share A2DP music		2 sec		
	Activate audio via cable	X	X		
	Deactivate audio via cable	X	X		

		<i>Button</i>	ON	▲	▼	▲ + ▼
<b>N-Com Intercom (900 series)</b>	Connection CHANNEL 1		X			
	Disconnection of active intercom		X			
	Calling CHANNEL 2		x2			
	Calling CHANNEL 3		x3			
	Group intercom connection					X
	Group intercom disconnection		X			

<b>Radio Menu</b>	Turning on the Radio				2 sec	
	Turning off the Radio				2 sec	
	Automatic search for new station			3 sec		
	Change station (pre-set stations)				3 sec	
	Pre-set station				4 sec	

<b>Setting***</b>	Pairing up mode (system turned off)		4 sec			
	Pairing up secondary mobile phone (or device)		2 sec			
	Pairing up CHANNEL 1 ("900" series)		2 sec			
	Pairing up CHANNEL 2 ("900" series)		X			
	Pairing up CHANNEL 3 ("900" series)		x2			
	Reset		x3			

\*Press any key on the N-Com keypad.

\*\*Press the keys at the same time.

\*\*\*All the Setting functions must be carried with the system in Setting Mode.

## 19. LIMITED WARRANTY

With this LIMITED WARRANTY CERTIFICATE, Nolangroup warrants this Product to be free from defects in material and workmanship at the time of its original purchase by the buyer.

We invite you to:

- Read the cautions pertaining to safety and proper use.
- Read the warranty terms and conditions.
- Keep the originals sales receipt. This must be shown in case of repairs covered by warranty. In these cases, the product has to be taken back to the dealer where it was purchased.

### 19.1. Warranty coverage

If any defect covered by this limited warranty certificate is discovered within 2 (two) years from the purchase date shown on the tax receipt, Nolangroup shall repair or replace the defective product through its distribution network after having verified the defect. Nolangroup shall supply all the material and labor that is reasonably required to remedy the defect, except in those cases where the damage is caused by one of the items listed in the following paragraph "Exclusions and limitations of the Coverage".

### 19.2. Exclusions and limitations of the coverage

This warranty only covers defects in materials and manufacturing. Nolangroup shall not be considered responsible for product defects that can be attributed, either partially or in full, to any other cause, including but not limited to:

- Defects or damages resulting from using the Product in conditions that differ from the usual ones.
- Damages caused by improper use not conforming with normal operation in accordance with the product operating and maintenance instructions provided by Nolangroup.
- Negligence and normal wear of internal and external parts.
- Any damage caused by an accident;
- Any change or modification made to the helmet or to the N-Com system by the user or by third parties.
- Color changes or damages caused by exposure to harmful chemical products.
- The use of incompatible accessories that are not part of the N-Com product range.
- Moreover, the warranty does not cover product defects caused by fortuitous events, modifications or adjustments, causes of force majeure or damages deriving from the product coming in contact with liquids.
- The internal helmet components are not and cannot be waterproof. Consequently, any improper exposure to rain, humidity, food spillages or other liquids can result in damages to the N-Com electronic devices, damages for which Nolangroup shall not be responsible.
- This warranty does not include those parts subject to wear and tear such as, for example, the rechargeable battery and the cables used for connection between the various N-Com systems or between the N-Com systems and other devices.
- Since Nolangroup does not supply the system on which the cell phones work, it shall not be responsible for the operation, availability, coverage, services or range pertaining to the aforementioned system.
- Whenever the product is used in conjunction with accessories or equipment not supplied by Nolangroup, Nolangroup shall not guarantee proper operation of the product/device combination, nor will it accept requests for repairs or replacements under warranty in case the product is used in such a way.
- Nolangroup shall not be responsible in case the product presents limited capabilities due to the operating mode of cell phones or of other accessories or equipment not supplied by Nolangroup.
- Tampering with the internal electronic card or with other parts of the N-Com system shall invalidate the warranty.
- Moreover, the defects covered by this warranty do not include all those specific and subjective situations that may come up during the active use of the helmet such as, for example, comfort problems while riding or aerodynamic noises.

Nolangroup shall not be held responsible in any case for incidental or consequential damages (including, without any limitation whatsoever, damages to one or more persons) resulting from non-fulfillment of the obligations arising from this warranty as it pertains to Nolangroup products.

### 19.3. Validity of this limited warranty

This warranty is valid only if the enclosed warranty form is duly and completely filled out with the following information:

- Product identification code
- Name and stamp of the authorized dealer.
- Product purchase date.
- Buyer's name and address.

Nolangroup reserves itself the right to not carry out repairs under warranty if the aforementioned information is removed or modified after the original purchase of the product from the dealer.

### 19.4. Procedure for the forwarding of claims

To forward a claim covered by this warranty, the buyer has to directly notify the dealer where the helmet was purchased with regards to the defect, presenting at the same time the defective product, a copy of the sales receipt and the Warranty registration form, duly filled out as instructed above.

PRIOR TO CONTACTING THE DEALER, WE RECOMMEND THAT YOU READ CAREFULLY THE USER MANUAL ENCLOSED WITH THE PRODUCT.

AFTER 2 (TWO) YEARS FROM THE DATE OF PURCHASE, THIS LIMITED WARRANTY IS VOID FOR ALL EFFECTS AND PURPOSES.

Repairs or maintenance under warranty do not extend the period of the warranty itself. Therefore, in case the product or one of its components is replaced, this does not initiate a new warranty period, as the purchase date of the original product shall be taken into account for warranty purposes.

Only for repairs or replacement of electronic components, in the event that Nolangroup proceeds to repairing or replacing the product, said product shall enjoy a warranty period equal to the residual portion of the original warranty or ninety (90) days from the repair date (the longer period being considered).

The repair or replacement can be carried out even with regenerated components with equivalent functions.

The replaced parts or components shall become property of Nolangroup.

THIS WARRANTY VOIDS AND REPLACES ANY OTHER WRITTEN OR VERBAL WARRANTIES PROVIDED FOR BY THE LAW THAT CAN BE DEROGATED AT THE PARTIES' WILL; SPECIFICALLY, NOLANGROUP DOES NOT GRANT SPECIFIC WARRANTS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO CASE SHALL NOLAN BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL DAMAGES, TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY THE LAW. NOLANGROUP RESERVES ITSELF THE RIGHT TO MODIFY, AT ANY TIME AND WITHOUT ADVANCE NOTICE, THE PRODUCT CHARACTERISTICS, FUNCTIONS, COMPATIBILITY AND SOFTWARE.

Some Countries do not allow the exclusion or limitation of incidental or consequential damages, or the limitation of the duration of implied warranties; as a result of this, the previous limitations and exclusions may not be applicable to you.

This warranty does not have any effect on the customer's legal rights under the national jurisdiction in force or on the consumer's rights towards the dealer sanctioned by the purchase/sale contract.


This warranty is valid throughout the European territory, and it represents the only express warranty provided by Nolangroup in relation to the sale of its own products. This warranty does not affect the rights to which the buyer is entitled and which are expressly provided for by Directive 1999/44/CE.

This warranty does not affect the consumer's rights provided for by the law, and specifically by the provisions of Legislative Decree 2 February 2002 n. 24.

### 19.5. Product identification

N-Com products are identified by means of a code that allows product traceability and identification.

The identification code is printed on the adhesive label applied to the B901 system.



**20. WARRANTY REGISTRATION FORM**

**Product name** B901

**Identification code**

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

**Buyer's Information**

**Name**

**Last name**

**Address**

**Phone**

**e-mail**

**Dealer's stamp**

**Date of purchase**

## **Certification and Safety Approvals**

### **FCC Compliance Statement**

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennae
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC RF Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. The antenna used for this transmitter must not transmit simultaneously with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.

### **FCC Caution**

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

## **Certification et homologation de sécurité**

### **Déclaration de conformité FCC**

Cet appareil est en conformité avec la partie 15 des règles de la FCC. Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas créer d'interférences préjudiciables et
- (2) Cet appareil doit accepter toutes les interférences reçues, y compris celles qui pourraient entraver son bon fonctionnement. Cet équipement a été testé et jugé conforme aux limites pour

un appareil numérique de classe B, conformément à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère et utilise de l'énergie radio fréquence et, s'il n'est pas installé et utilisé conformément

aux instructions, il peut occasionner des interférences nuisibles au niveau des communications radios. Cependant, il n'existe aucune garantie que ces interférences ne se produiront pas dans une installation particulière. Si cet équipement génère des interférences nuisibles à la réception de la radio ou de la télévision (ce qu'il est possible de déterminer en mettant l'équipement hors tension, puis sous tension), l'utilisateur est invité à suivre une ou plusieurs des mesures suivantes pour corriger le problème des interférences en prenant l'une des mesures suivantes :

- Modifier l'emplacement ou l'orientation de l'antenne de réception.
- Éloigner l'appareil du récepteur.
- Brancher l'appareil sur une prise située sur un circuit différent de celui du récepteur.
- Consulter le revendeur ou un technicien expérimenté pour obtenir de l'aide.

### **Énoncé FCC sur l'exposition aux radiations RF**

Cet équipement est conforme aux réglementations FCC d'exposition aux radiations définies pour un environnement non contrôlé. Les utilisateurs doivent respecter les instructions d'exploitation spécifiques pour répondre aux exigences de conformité sur l'exposition aux RF. L'antenne utilisée pour cet appareil ne doit pas fonctionner en même temps qu'une autre antenne ou émetteur, sauf s'il y a conformité avec les procédures FCC des produits multi-émetteurs.

### **Précautions FCC**

Tout changement ou modification non expressément approuvé par la partie chargée de la mise en conformité peut annuler le droit de l'utilisateur à utiliser l'équipement.

## **(5) Industry Canada(IC) Statement**

This device complies with RSS-210 of the Industry Canada Rules.

Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference. Including interference that may cause undesired operation of device.

This class B digital apparatus complies with Canadian ICES-003

## **Avis d'Industrie Canada**

Cet appareil est conforme à norme CNR-210 des règlements d'Industrie Canada. Son fonctionnement est sujet aux deux conditions suivantes:

- 1) Cet appareil ne doit pas provoquer d'interférences et
- 2) Cet appareil doit accepter toute les interférences. y compris celles pouvant entraîner son dys-fonctionnement.

Cet appareil numérique de classe B est conforme à la norme NMB-003 du Canada.



**IC Radiation Exposure Statement:**

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: THE MANUFACTURERE IS NO T RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

**Avis d'Industrie Canada sur l'exposition aux rayonnements**

Cet équipement est conforme aux limites d'exposition aux radiations dans un environnement non contrôlé. Les utilisateurs doivent suivre les instructions de fonctionnement spécifiques pour le respect d'exposition aux RF. Cet émetteur ne doit pas être co-localisés ou fonctionnant en conjonction avec une autre antenne ou transmetteur.

REMARQUE: LE FABRICANT N'EST PAS RESPONSIBLE DES INTERFÉRENCES RADIOÉLECTRIQUES CAUSÉES PAR DES MODIFICATIONS NON AUTORISÉES APPORTÉES APPORTÉES À CET APPAREIL. DE TELLES MODIFICATIONS POURRAIT ANNULER L'AUTORISATION ACCORDÉE À L'UTILISATEUR DE FAIRE FONCTIONNER L'APPAREIL.