

# FREQUENCY CHANNEL

CHANNEL NUMBER	01	02	03	04	05	06	07	08	09
FREQUENCY	2402MHZ	2404MHZ	2406MHZ	2408MHZ	2410MHZ	2412MHZ	2414MHZ	2416MHZ	2418MHZ

CHANNEL NUMBER	10	11	12	13	14	15	16	17	18
FREQUENCY	2420MHZ	2422MHZ	2424MHZ	2426MHZ	2428MHZ	2430MHZ	2432MHZ	2434MHZ	2436MHZ

CHANNEL NUMBER	19	20	21	22	23	24	25	26	27
FREQUENCY	2438MHZ	2440MHZ	2442MHZ	2444MHZ	2446MHZ	2448MHZ	2450MHZ	2452MHZ	2454MHZ

CHANNEL NUMBER	28	29	30	31	32	33	34	35	36
FREQUENCY	2456MHZ	2458MHZ	2460MHZ	2462MHZ	2464MHZ	2466MHZ	2468MHZ	2470MHZ	2472MHZ

CHANNEL NUMBER	37	38	39	40					
FREQUENCY	2474MHZ	2476MHZ	2478MHZ	2480MHZ					

HANGZHOU ZT MODEL Co., Ltd		PRODUCT NAME		SKY TANGO HELICOPTER	
				FREQUENCY CHANNEL	
		PAGE NUMBER	1 OF 1	ISSUE DATE	2011.01.10
DRAWN BY	HUAMING YANG	CHECKED BY	HUAMING YANG	APPROVED BY	HUAMINGYANG