



Via di Monte Verde 33 – 00152 Rome – Italy.
Website www.linear-amplifier.com

Tel. (39-6) 58209429
e_mail info@linear-amplifier.com


Fax (39-6) 58209647

Exhibit 3: Block Diagram

External Radio Frequency Linear Amplifier Model Expert 2K-FA



Block Diagram



The position of the contacts, as shown in the diagram, is the situation of the linear amplifier in OFF state.

The linear amplifier can be used in the following ways:

- 1) OFF Only two direct connections are actuated:
 - a) Between INPUT 1 and ANT 1.
 - b) Between INPUT 2 and SO2R.
- 2) STANDBY All the functions are activated (band change, antenna change, tuner control) but the transmission is from the transceiver only.
- 3) OPERATE All the functions are activated and the transmission is using the linear amplifier.