



Mounting and Installation

Option 1: Flush Wall Mount

Step 1



Paste the mount sheet on the wall
Step 4



Plug in the required cables to the room panel


Option 2: Mounting on Glass

Step 1



Paste sticker on the back of the mounting plate
Ensure the glass surface is clean and dry


Step 5



Plug in the required cables to the room panel


Option 3: Mounting close to a window frame

Step 1



Align the mounting sheet guide parallel to the window frame

Step 5




Attach the room panel to the mounting plate

Step 2



Drill the four mounting holes

Step 5



Attach the room panel to the mounting plate

Step 2




The mount sheet can be temporary fixed on the other side of the glass to locate the area for the cover sheet.

Step 6




Attach the room panel to the mounting plate

Step 3



Install the mounting plate using the four screws
Step 6




Lock the room panel to the mounting plate using a screw at each corner

Step 3




1. Affix the cover sheet to the glass surface.
2. Align the mounting plate to the cover sheet with the Kensington lock hole.

Step 7




Lock the room panel to the mounting plate using a screw at each corner

Step 3




Install the mounting plate using the four screws

Step 7




The room panel is ready to be brought online

Step 7




The room panel is ready to be brought online

Step 4



Affix the mounting plate to the glass surface

Step 8




The room panel is ready to be brought online

System Setup


1 Boot up

Plug in the AC adapter and Ethernet cable to the room panel and it will power on automatically. Once the user has exited the boot up screen, users can go through system configurations in both landscape and portrait orientations.




2 Autoplay content

When boot up is complete, if the system detects preloaded content, the loading circle will appear. Once the loading circle completes, content will be played. To stop autoplay and enter "Basic settings," users need to select the pause button in the center of the loading circle.




3 Basic settings

When boot up is complete and there is no preloaded contents, the user will see the "Basic settings" which allows the user to make configurations or autoplay pre-loaded content.




4 Make configurations

To change room panel system language, select "(Current Language)" For system configurations, select "Advanced."




Important recommended configurations:

- 1 Set correct time, date, and time zone for properly scheduled playback.
- 2 Set password to prevent unauthorized access during setup menu.
- 3 Set network for establishing network connection.



5 Set content

Users can set content by clicking "Set Content" to enter the URL or use the desired content management system to upload the contents onto the room panel.



Content Management

Please consult the software documentation for information specific to your content management solution.

Troubleshooting


How do I interrupt playback and enter setup menu?

Use USB mouse to click and hold one corner of the screen for 10 seconds to exit playback and enter setup menu.

How do I provide a DEBUG log for a misbehaving room panel to the support team?

Please follow the instructions below to collect the room panel's DEBUG log:

- 1 Prepare a blank USB stick in FAT-32 format.
- 2 Create a folder named "DEBUG" (case insensitive) in the root of USB stick.
- 3 Make sure the room panel is operating (see welcome screen or playing content).
- 4 Insert the USB stick into room panel and wait for yellow dot on upper right corner to stop blinking.
- 5 Within the "DEBUG" folder, is a folder with a string of number as its name. If the string of numbers are all zero's, the debug log has not been collected properly. Repeat step 1-4 again and make sure to wait until stop blinking.
- 6 Zip the "DEBUG" folder and send to IAdea Support Team.



Resetting room panel to factory default

Factory resetting the room panel will result in the removal of all saved contents, passwords, and configurations in settings. Please refer to the steps below to complete the room panel factory resetting process:


- 1 Use a pen to press and hold the reset button - do not release until Step 4.
- 2 Insert the power cord.
- 3 Wait 30 seconds for the system reboot indicating your data is erased.
- 4 Release the reset button and your room panel will initialize in factory default state.

IAD-18010 series


Quick Start Guide

This is a quick walkthrough of the set up process. For complete documentations and quick start guides, please visit <http://support.IAdea.com>.

Box Content



Port Connections



- | | | | |
|-------------------|---------------------|-----------------|--|
| ① Screw Hole | ⑥ MicroSD card slot | ⑩ Reset | ⑭ 12V DC power |
| ② Camera* | ⑦ ADB | ⑪ USB port | ⑮ Expansion* |
| ③ Microphone* | ⑧ 3.5mm audio | ⑫ Ethernet RJ45 | ⑯ Kensington Lock |
| ④ LED | ⑨ USB port | ⑬ Power LED | ⑰ VESA mount (MIS-D75)
Screw spec: M4 |
| ⑤ NFC/RFID reader | | | |

* The functions marked with "*" only appear on certain models.

CARE AND WARNING

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Europe – EU Declaration of Conformity

This device complies with the essential requirements of the Radio Equipment Directive (2014/53/EU). The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the Radio Equipment Directive This equipment is compliant with Class A of EN55032. In a residential environment this equipment may cause radio interference.



Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

"FCC & CE RF Radiation Exposure Statement Caution: To maintain compliance with the FCC & CE's RF exposure guidelines, place the product at least 20cm from near by persons."

The suitable temperature for the Colour Monitor and sccessories is 0°C-50°C. Adaptor with ferrite must be used with this equipment to ensure compliance with the Class A FCC limits.

Power Adapter information:
Model No.: WB-24J12R
INPUT: 100-240V~50/60Hz
OUTPUT: 12VDC 2.0A
Installation height :<2M

CAUTION



Risk of explosion if the battery is replaced by an incorrect type
Wait one-half hour after switching off before handling parts

- Replacement of a battery with an incorrect type that can be defeat a safeguard;
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

company Name: IAdea Corporation
Address: 3F, No. 21, Lane 168, Xingshan Road, Neihu Dist. Taipei, 114 Taiwan
Tel: 886-2-2791-1110



Q41G78SP05904A