

Preface

Welcome to the world of Hytera and thank you for purchasing this product. This manual includes a description of the functions and step-by-step procedures for use.

To avoid bodily injury or property loss caused by incorrect operation, please carefully read the *Safety Information Booklet* before use.

This manual is applicable to the following product:

PNC 550 Smart LTE Terminal

Contents

Preface.....	1
Copyright Information.....	1
Disclaimer.....	1
FCC Statement.....	1
IC Statement.....	2
Documentation Information	4
Icon Conventions	4
Notation Conventions	4
Key Operations	5
1. Unpacking	6
1.1 Packing List	6
1.2 Product Overview	7
1.3 Installing Cards.....	7
1.4 Attaching the Battery	8
1.5 Charging the Battery	9
2. Basic Operations.....	11
2.1 Activating the Terminal.....	11
2.2 Turning the Terminal On/Off	11
2.3 Adjusting the Volume	12
2.4 Understanding the Screen.....	12
2.4.1 Status Indications.....	13
2.4.2 Control Center.....	14
2.4.3 App Center	15
2.4.4 Screen Operation	15
2.5 Configuring the Dual SIM Standby Feature	18
2.5.1 Enabling/Disabling the SIM Card.....	18
2.5.2 Setting the Preferred SIM Card.....	18
2.6 Connecting to the Network.....	19
2.6.1 Mobile Network	19
2.6.2 Wi-Fi	19
3. Terminal Settings	20
3.1 Network and Internet.....	20
3.1.1 Mobile Network	20
3.1.2 Data Usage	20
3.1.3 Hotspot and Tethering	20
3.1.4 VPN	21
3.1.5 Airplane Mode	22
3.2 Display	22

3.2.1	Brightness Level.....	22
3.2.2	Night Light.....	22
3.2.3	Sleep.....	23
3.2.4	Auto Rotate Screen.....	23
3.2.5	Text Display.....	23
3.2.6	Wallpaper and Screen Saver.....	24
3.3	Sound.....	24
3.3.1	Volume, Sound Effect, and Vibration.....	24
3.3.2	Do Not Disturb Mode.....	25
3.4	Location.....	26
3.5	Language and Input.....	26
3.6	Date and Time.....	27
3.7	Reset Options.....	28
3.8	Data Tethering.....	28
3.8.1	BT.....	28
3.8.2	NFC.....	30
3.8.3	USB.....	30
3.9	Product Information.....	30
3.9.1	Battery.....	30
3.9.2	Storage.....	31
3.9.3	About Product.....	32
4.	Applications.....	33
4.1	Installation.....	33
4.2	Uninstallation.....	33
4.3	App Permissions.....	33
5.	Communication Services.....	34
5.1	Phone.....	34
5.1.1	Initiating Calls.....	34
5.1.2	Receiving Calls.....	35
5.1.3	Emergency Call.....	35
5.1.4	Other Operations.....	36
5.2	Message.....	36
5.2.1	Sending Messages.....	36
5.2.2	Receiving Messages.....	36
5.2.3	Other Operations.....	36
5.3	Contacts.....	37
5.3.1	Creating Contacts.....	37
5.3.2	Managing Contacts.....	38
5.3.3	Searching for Contacts.....	38
5.3.4	Sharing Contacts.....	38

5.3.5 Deleting Contacts.....	38
5.3.6 Other Operations.....	39
6. Multimedia Services.....	40
6.1 Snapdragon Camera	40
6.1.1 Photo Mode.....	40
6.1.2 Video Mode.....	43
6.1.3 Panoramic Mode.....	44
6.2 Snapdragon Gallery	44
6.2.1 Viewing Pictures or Videos.....	45
6.2.2 Playing Videos.....	45
6.2.3 Cutting Videos.....	46
6.2.4 Editing Pictures.....	46
6.2.5 Sharing Pictures or Videos.....	47
6.2.6 Deleting Pictures or Videos.....	47
6.3 Videos	47
6.4 Music	47
6.4.1 Playing Music.....	47
6.4.2 Other Operations.....	48
7. Google Apps.....	49
7.1 Chrome	49
7.1.1 Multipage Operations.....	49
7.1.2 Webpage Settings.....	50
7.1.3 Bookmark Operations.....	50
7.1.4 History.....	51
7.1.5 Download.....	51
7.2 Drive	51
7.3 Duo	51
7.4 Gmail	51
7.5 Google	52
7.6 Maps	52
7.7 Photos	52
7.8 Play Movies & TV	52
7.9 Play Music	53
7.10 Play Store	53
7.11 YouTube	53
8. Utility Apps.....	54
8.1 File Manager	54
8.2 Sound Recorder	54
8.2.1 Recording Audio Files.....	54
8.2.2 Viewing Recording Files.....	55

8.2.3 Managing Recording Files	55
8.3 Clock	56
8.3.1 Setting the Alarm Clock.....	56
8.3.2 Viewing the World Clock	56
8.3.3 Using the Timer	57
8.3.4 Setting the Stopwatch	57
8.4 Calendar	57
8.4.1 Adding Accounts.....	57
8.4.2 Adding Activities	58
8.4.3 Searching for Activities.....	58
8.4.4 Setting the Calendar	58
8.5 Calculator	59
9. System Upgrade.....	60
10. Troubleshooting.....	61
11. Care and Cleaning.....	63
11.1 Product Care	63
11.2 Product Cleaning.....	63
12. Optional Accessories	64

Copyright Information

Hytera is the trademark or registered trademark of Hytera Communications Corporation Limited (the Company) in the People's Republic of China (PRC) and other countries or areas. The Company retains the ownership of its trademarks and product names. All other trademarks and/or product names that may be used in this manual are properties of their respective owners.

The products described in this manual may include the Company's computer programs stored in memory or other media. Laws in PRC and/or other countries or areas protect the exclusive rights of the Company with respect to its computer programs. The purchase of this product shall not be deemed to grant, either directly or by implication, any rights to the purchaser regarding the Company's computer programs. The Company's computer programs may not be copied, modified, distributed, decompiled, or reverse-engineered in any manner without the prior written consent of the Company.

Disclaimer

The Company endeavors to achieve the accuracy and completeness of this manual, but no warranty of accuracy or reliability is given. All the specifications and designs are subject to change without notice due to continuous technological development. No part of this manual may be copied, modified, translated, or distributed in any manner without the prior written consent of the Company.

We do not guarantee, for any particular purpose, the accuracy, validity, timeliness, legitimacy or completeness of the third-party products and contents involved in this manual.

If you have any suggestions or would like to receive more information, please visit our website at <http://www.hytera.com>.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10 mm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC Statement

The device has been tested and complies with SAR limits; users can obtain Canadian information on RF exposure and compliance.

Après examen de cematériel aux conformité aux limites DAS et/ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation

of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :



- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 10 mm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour environnement non contrôlé. ce matériel doit être installé et exploité avec distance minimale 0mm entre le radiateur et votre corps.cet émetteur ne doit pas être situées ou opérant conjointement avec toute autre antenne ou l'émetteur.

Documentation Information

Icon Conventions

Icon	Description
 Note	Indicates references that can further describe the related topics.
 Caution	Indicates situations that could cause data loss or equipment damage.

Notation Conventions

Item	Description	Example
Boldface	Denotes menus, tabs, parameter names, window names, dialogue names, and hardware buttons.	To save the configuration, click Apply .
		The Log Level Settings dialogue appears.
		Press the PTT key.
" "	Denotes messages, directories, file names, folder names, and parameter values.	The screen displays "Invalid Battery!"
		Open "PDT_PSS.exe".
		Go to "D:/opt/local".
		In the Port text box, enter "22".
>	Directs you to access a multi-level menu.	Go to File > New .
<i>Italic</i>	Denotes document titles.	For details about using the DWS, refer to <i>Dispatch Workstation User Guide</i> .
Courier New	Denotes commands and their execution results.	To set the IP address, run the following command: <code>vos-cmd - m name IP</code>

Key Operations

Operation	Description
Short press	Press and release quickly.
Long press	Press and hold for the preset duration.
Press and hold	Keep the key pressed.

1. Unpacking

1.1 Packing List


Please unpack carefully and check that you have received the following items. If any item is missing or damaged, please contact your dealer.

Item	Quantity (PCS)	Item	Quantity (PCS)
Terminal	1	Data Cable	1
Battery	1	Battery Cover	1
Power Adapter	1	Documentation Kit	1

Note


- Figures in this manual are for reference only.
 - Check the main unit label inside the battery compartment to ensure that the purchased product is correct.
-

1.2 Product Overview



1.3 Installing Cards

Insert the Nano SIM cards and Micro SD card into the slots as shown in the following figure.



 Note


To remove the Nano SIM cards, slide the latch until the Nano SIM cards pop out.

1.4 Attaching the Battery


 Caution

- Use the approved battery by the Company to avoid the risk of explosion.
 - Dispose of the used battery in accordance with "Precautions for Disposal" in the *Safety Information Booklet*.
-


1. Slide the battery latch to the unlock position and remove the battery cover.



2. Attach the battery.



3. Press the cover into place and slide the battery latch to the lock position.



1.5 Charging the Battery

Caution

- Use the approved charger to charge the battery.
- Read the Safety Information Booklet before charging.
- The remaining lithium-ion battery power is limited to 30% pursuant to the new lithium battery shipment regulation approved by International Air Transport Association (IATA). Therefore, you must charge the battery before initial use to avoid the low battery alarm.
- Do follow the standard procedure of charging the standalone battery below, so as to prevent overcharging and prolong the battery life.

You can charge the standalone battery according to the following standard procedure:

1. Place the battery into the charger.
2. Insert the output connector of the power adapter into the port on the back of the charger.
3. Plug the power adapter into a power outlet.

You can also charge the terminal with battery attached by connecting the terminal to the USB port on the

power adapter, mobile power supply or PC by the data cable.

It is recommended to charge the battery when the power is below 15%.


During charging, check whether the battery is fully charged by the battery level icon or battery percentage displayed on the touchscreen.

2. Basic Operations

2.1 Activating the Terminal

Note

Activation must be done over a network. Make sure that the SIM card is inserted or the Wi-Fi network is available during activation.

1. Long press  until the startup screen appears, and then tap **START**.
2. (Optional) Connect to the Wi-Fi network.
3. Configure your terminal data in one of the following ways:
 - Tap **Copy your data**, and then follow the onscreen instructions to transfer data from other devices to the terminal.
 - Tap **Set up as new** to skip this step.
4. Sign in to your Google account or create a new Google account by following on-screen instructions.
5. Configure the basic information as follows:
 - a. Set the date and time.
 - b. Enter the user name.
 - c. Select a lock mode.
 - d. Configure your voice match assistant.
6. Read and accept the privacy terms and policy, including google services and accelerated location.


After activation is completed, the terminal enters the home screen.

2.2 Turning the Terminal On/Off


Turning the Terminal On

To turn the terminal on, long press  until the startup screen appears.

Turning the Terminal Off

To turn the terminal off, long press  until the terminal displays **Power Off** and **Restart**, and then select **Power Off**.


2.3 Adjusting the Volume

- To increase or decrease the ring volume, press the **Volume Up** or **Volume Down** key.
- To increase or decrease the media volume or alarm volume, press the **Volume Up** or **Volume Down** key, click  in the displayed control box, and then drag the volume slider.









Note















You can also adjust the volume through the **Settings** menu. For more operations, see [3.3 Sound](#).

2.4 Understanding the Screen



2.4.1 Status Indications

Icon	Terminal Status	Icon	Terminal Status
	The Wi-Fi network is connected.		The BT feature is enabled.
	The SIM card registers with the mobile network.		An earpiece is connected.
	The SIM card does not register with the mobile network.		The GPS is positioning.
	The hotspot is enabled.		The Do Not Disturb mode is enabled, and Alarms only/Priority only is selected..


Icon	Terminal Status	Icon	Terminal Status
	The battery is fully charged.		The Do Not Disturb mode is enabled, and Total silence is selected.
	The battery is being charged.		There is/are new message(s).
	The Power Saver is enabled.		There is/are missed call(s).
	No SIM card is installed.		The terminal has downloaded file(s)
	The airplane mode is enabled.		The terminal has uploaded file(s)
	The alarm is enabled.		The terminal has downloaded file(s).
	The vibration mode is enabled.		Screenshot(s) is/are captured.

2.4.2 Control Center

Control Center allows you to access handy features by using shortcut switches, adjust the screen brightness, and view or clear the notifications.

To open the control center, swipe down from the status bar.

To view all the shortcut switches in the control center, tap .



2.4.3 App Center

Tap \wedge or swipe upward on the home screen to open the app center, and then swipe up or down to view all apps.

2.4.4 Screen Operation

Understanding Gestures



Tap: Touch the target to open an app or select a function.



Tap and hold: Touch the target for more than two seconds to enter the editing mode.



Swipe: Swipe through items, such as control panels, pages, or recently used apps.



Drag: Touch the target and move it to a new location.




Zoom in: Separate two fingers on the screen.



Zoom out: Close two fingers on the screen.

Using Screenshots


To capture the current screen, press the **On-Off** key and the **Volume Down** key at the same time.

To view the screenshot, tap  to enter the Snapdragon Gallery menu.


Locking/Unlocking the Screen

When you do not use the screen, you can lock the screen to save battery power, avoid unintended operations, and preserve privacy. In this case, you can still initiate an emergency call, answer a call, and receive a message or notification.


When using the terminal for the first time, lock or unlock the screen in the following ways:

- Locking the screen
 - Press  to put the screen to sleep.

➤ When the standby time reaches the Sleep time, the terminal will be automatically locked.

You can change the lock pattern. To change the pattern, tap **Settings**  > **Security & Location** > **Screen lock**, and then select **Pattern**, **PIN** or **Password**. To prevent data loss or data leakage, you can also suspend the terminal receiving calls, messages, or notifications when screen is locked.


- Unlocking the screen

Press  to wake up the screen, and then swipe upward.

Customizing Home Screen

- Wallpaper, widget, and home screen settings

To change the wallpaper, add widgets, or configure the home screen, tap and hold the customized zone to enter the home screen editing mode, and then tap **WALLPAPERS**, **WIDGETS**, or **HOME SETTINGS**.



- App icon

➤ To add an app to the home screen, enter the app center, tap and hold the app icon, and then drag it to the customized zone.

➤ To arrange the apps on the home screen, tap and hold an app, and then drag it to the desired place.

➤ To remove an app from the home screen, tap and hold it, and then drag it upward to **Remove**.


Clearing History

To reduce memory usage, you can clear the recently used apps as follows:

1. Tap  to enter the recently used apps interface.

2. Do one of the following:


- To end one app, tap **X** , or swipe it left or right.
- To end all apps, swipe the interface downward to the last app, and then tap **CLEAR ALL**.



2.5 Configuring the Dual SIM Standby Feature

The terminal supports Dual SIM Dual Standby feature, and allows you to use two SIM card at the same time.

2.5.1 Enabling/Disabling the SIM Card


1. Tap **Settings**  > **Network & Internet** > **SIM cards**.
2. Turn on or off the SIM card.

Note

You can tap the SIM card to customize the name and color of the SIM card for easy identification.

2.5.2 Setting the Preferred SIM Card

You can set a SIM card as the preferred one, after which the terminal will preferentially use the card to access the network, initiate a call, or send a message. To set a preferred SIM card, do as follows:

1. Tap **Settings**  > **Network & Internet** > **SIM cards**.
2. Tap **Default 4G/3G Subscription** or **Calls** to select the preferred card for the functions.

Note


If you select Ask every time, you need to select one SIM card every time you initiate calls or send messages. Otherwise, the terminal uses the preferred SIM card.

2.6 Connecting to the Network

2.6.1 Mobile Network

Before you connect the terminal to the mobile network, make sure that the SIM card has registered with the carrier network. When you do not use the mobile network, disable the mobile network to save the data usage and prolong the standby time.

To enable/disable the mobile network, do one of the following:


- Swipe down from the status bar to expand all shortcuts, and then turn on **Mobile data**.
- Tap **Settings**  > **Network & Internet** > **Mobile network**, and then turn on **Mobile data**.

2.6.2 Wi-Fi


The terminal can connect to a Wi-Fi network to access the Internet, so as to reduce mobile data usage and avoid unnecessary data charges.

To connect the terminal to the Wi-Fi network, do the following:

1. Turn on Wi-Fi in one of the following ways:

- Swipe down from the status bar to expand all shortcuts, and then turn on **Wi-Fi**.
- Tap **Settings**  > **Network & Internet** > **Wi-Fi**, and turn on **Wi-Fi**.

2. Tap one of the listed available networks.


3. If the icon  displays next to the wireless network, enter the network password and tap **CONNECT**.

After the terminal is connected to a wireless network, the network will be automatically saved. To view, add, or forget saved networks, tap **Wi-Fi** > **Saved networks**.

To allow the terminal to automatically notify when detecting a wireless network, do as follows:

1. Tap **Wi-Fi** > **Wi-Fi preferences**.
2. Turn on **Open network notification**.

3. Terminal Settings

Tap  to open **Settings**, and then you can configure the following terminal settings:

3.1 Network and Internet

3.1.1 Mobile Network


- To enable Roaming, tap **Network & Internet > Mobile network**, and then in one SIM card interface turn on the **Roaming** switch.
- To select network type, tap **Network & Internet > Mobile network > Advanced > Preferred network type**, and then select **2G, 3G, or 4G**.

Note

Before using the 4G network, make sure that the SIM card is enabled with the 4G service.

3.1.2 Data Usage

To view the usage of mobile data, tap **Network & Internet > Mobile network > Data usage**.

To set the data usage cycle reset date, data usage alarm, or data usage limit, in the data usage interface, tap , and then perform the desired operation. In this case, the terminal will give notifications or disable the mobile network when the data usage exceeds the limit.

3.1.3 Hotspot and Tethering

- Wi-Fi Hotspot

After connecting the terminal to the mobile network, you can create a hotspot to offer internet connection to other devices. To configure the Wi-Fi hotspot, do as follows:

1. Tap **Network & Internet > Hotspot & tethering > Wi-Fi Hotspot**, and then enable the hotspot.
2. Tap **Set up Wi-Fi hotspot** to set the **Network name**, **Security** and **Password**, and then tap **SAVE**.

Note

After configuring the Wi-Fi hotspot, you can quickly access the Hotspot through the Hotspot

shortcut in the control center.

- USB Tethering

Before using the USB tethering, make sure that the driver is installed on the computer or the network connection is established.


To configure the USB Tethering, do as follows:


1. Connect the terminal to the computer with a USB cable.
2. Tap **Network & Internet > Hotspot & tethering > USB tethering**, and then enable the USB tethering.

- BT Tethering

Before using the BT tethering, the terminal and the BT device must be connected and paired. For details, see Connecting to BT Device in [3.8.1 BT](#).

To configure the BT tethering, do as follows:

3. Tap **Network & Internet > Hotspot & tethering > Bluetooth tethering**, and then enable the BT tethering.
4. Return to the **Settings** interface, and tap **Connected devices > Bluetooth**.
5. In the **Bluetooth** interface, tap  next to the paired device, select **Internet Access**, and then tap **OK**.



3.1.4 VPN

VPN (Virtual Private Network) is a secured temporary network established on the public internet. It can encrypt transmitted data, and achieve information security of the private network.

To configure the VPN, do as follows:

1. Tap **Network & Internet > VPN**.
2. Tap **+** to edit the VPN profile, including **Type/Server address/Username/Password**, and then tap **SAVE**.


Note

- To obtain the VPN user name and password, consult your dealer.
 - Before adding a VPN profile, you need to set the PIN code or Password.
-

3.1.5 Airplane Mode

Airplane Mode suspends the terminal's signal transmitting or receiving, so as to avoid emitting interference to the airplane when you are on a flight. When the Airplane Mode is enabled, the terminal automatically disables the mobile network and Wi-Fi. You cannot use the voice and data services. If permitted by the airline, you can manually enable the BT or Wi-Fi.

To enable the feature, do one of the following:

- Swipe down from the status bar to expand all shortcuts, and then turn on **Airplane mode**.
- Tap **Settings**  **> Network & Internet > Airplane mode**, and then turn on **Airplane mode**.

3.2 Display

3.2.1 Brightness Level


Brightness Level allows you to adjust the screen brightness, so as to ensure good visual effect in different situations. To adjust the brightness level, do one of the following:

- Manual adjustment
Tap **Display > Brightness Level**, and then drag the slider to manually adjust the brightness.
- Auto adjustment
Tap **Display > Adaptive brightness** to enable the feature, and then the terminal will automatically adjust screen brightness according to the environment light.

3.2.2 Night Light

Night Light allows the screen to turn amber, so as to relieve your eye strain or protect your eyesight

when you work in the darkness.

- To enable Night Light, swipe down from the status bar to expand all shortcuts, and then turn on **Night Light**.
- To configure Night Light, tap **Settings**  > **Display** > **Night Light**, and then do one of the followings:
 - a. Tap **Schedule** to set a schedule for enabling the night light mode, and then the terminal automatically enters night light mode as scheduled.
 - b. Tap **Status** to turn on the switch, and then the terminal enters the night light mode.
 - c. Drag the **Intensity** slider to adjust the amber intensity.

3.2.3 Sleep

Sleep allows the terminal to automatically turn off its screen when no operation is made within the sleep time, so as to save battery power.


To set the sleep time, tap **Display** > **Advanced** > **Sleep**, and then select the desired time in the time list.

Note

If you want the terminal screen to be waken up upon receiving a notification, you can tap **Display** > **Advanced** > **Ambient Display**, and turn on the switch next to it.


3.2.4 Auto Rotate Screen

Auto Rotate Screen allows the terminal to automatically adjust the orientation types between portrait and landscape. To enable the feature, do one of the following:

- Swipe down from the status bar to expand all the shortcuts, and then tap **Portrait** to switch to Auto rotate mode.
- Tap **Settings**  > **Display** > **Advanced** > **Auto-rotate screen**, and then turn on the switch.


3.2.5 Text Display

- To adjust the font size, tap **Display** > **Advanced** > **Font size**, and then drag the slider to set the font size as **Small**, **Default**, **Large**, or **Largest**.



- To adjust the display size, tap **Display > Advanced > Display size**, and then drag the slider to set the display size as **Small**, **Default**, or **Large**.


3.2.6 Wallpaper and Screen Saver

- To set the wallpaper, tap **Display > Wallpaper**, and then select your favorite picture as the wallpaper.
- To set the screen saver, do as follows:
 1. Tap **Display > Advanced > Screen saver**, tap **Current Screen saver**, and then select **Color**, **Clock**, or **Photo** as the screen saver.
 2. Tap  next to the **Current screen saver**, and then set the **Style** as **Analog** or **Digital**, or select the **Night mode**.
 3. Tap **When to start** to set the time to activate the screen saver.

3.3 Sound

3.3.1 Volume, Sound Effect, and Vibration

In the Sound menu, you can customize the ring tone and alert tone of your terminal as follows:



3.3.2 Do Not Disturb Mode

Do Not Disturb Mode prevents your terminal from giving audio indications or waking the screen when the terminal receives calls or notifications.


To enable the Do Not Disturb mode, do one of the following:

- Through the shortcut
 1. Swipe down from the status bar to expand all shortcuts, and then turn on **Do not disturb**.
 2. Tap ▼ next to the switch, and then select **Total silence**, **Alarms only**, or **Priority only** as required, and set duration before entering the mode.

Note

When you select **Priority Only mode**, you must tap **MORE SETTINGS** to set your preferences.

- Through **Settings** menu

Tap **Settings**  > **Sound** > **Do not disturb preferences**, and then you can configure the feature as follows:

 - Tap **Priority only allows**, and then select **Reminders**, **Events**, **Messages**, or **Calls**.
 - Tap **Block visual disturbances**. Hence with the Not to disturb mode enabled, the screen notifications and LED notifications are blocked.

- Tap **+** to add more automatic event rules, or add time rules to schedule the Do not disturb mode according to your needs.

3.4 Location

The Location feature allows the terminal to determine its location through Wi-Fi, mobile network, BT, or GPS.

This feature also allows the location-related apps, such as Camera, Intercom, and Map to realize services such as positioning, navigating, and weather forecasting.


To configure the Location feature, do as follows:

1. Tap **Security & location > Location**, and turn on **Location**.
2. Tap **Mode**, and then select one of the following location modes:
 - **High Accuracy**: The terminal locates accurately through Wi-Fi, mobile network, BT, or GPS.
 - **Battery Saving**: The terminal locates only through Wi-Fi, mobile network or BT, so as to save battery power.
 - **Device Only**: The terminal locates only through GPS and sensors without using data traffic.
3. Tap **Location > App-level Permissions**, and then set the permission of the apps to access location information.

3.5 Language and Input

To configure language and input, tap **System > Language & input**, and then perform the following operations:

- To configure the display language, tap **Languages**, and then drag the desired language to the list top. To add a new language not included in the list, tap **Add a language**, and then search the desired language.
- To configure the input method, tap **Virtual keyboard**, and then select the desired input method. To add a new input method, download and install the desired input method when the device is connected to network, and then configure and enable it in the **Virtual keyboard** menu.


When two or more input methods are enabled, open the text input interface, and then tap  in the lower right corner of the screen to switch between them.


3.6 Date and Time


With network connected, you can enable automatic synchronization of date, time, and time zone of the system. Or you can manually adjust them, if an error appears.

To configure date and time, tap **System > Date & time**, and then perform the following operations:

- To enable automatic synchronization of date, time, and time zone, do as follows:
 - Turn on the **Automatic date & time** switch, and then the system uses the date and time provided by the network.
 - Turn on the **Automatic Time Zone** switch, and then the system uses the time zone provided by the network.
- To manually adjust the date, time, and time zone, do as follows:
 - Tap **Set Date**, and then select the date according to the actual situation.



- Tap **Set Time**, and then rotate the clock pointer to set time, or tap  in the lower left corner to enter time.



- Tap **Select Time Zone**, and then select the desired time zone from the list.
- To set the time format of 12-hour or 24-hour, turn on or turn off the **Use 24-hour format** switch as required.

3.7 Reset Options

Caution

Before a terminal reset, back up the data in advance to avoid loss of important data.

When the terminal runs slowly or the apps quit unexpectedly, you can reset the network, apps, or system to fix the problem. To reset the terminal, tap **System > Reset Options**, and then you can perform the following operations:

- To reset all network settings, tap **Reset Wi-Fi, mobile & Bluetooth > RESET SETTINGS**, and then tap **RESET SETTINGS** to confirm reset.
- To reset all app data, tap **Reset app preferences**, and then tap **RESET APPS** to confirm reset on the prompt.
- To clear all data in the storage, tap **Erase all data (factory reset) > RESETTING PHONE**, and then tap **ERASE EVERYTHING** to confirm reset.

3.8 Data Tethering

3.8.1 BT



After the terminal is successfully connected to a BT device, you can transmit or receive files such as pictures, audios, and videos through BT.

Connecting to a BT device

- Through the shortcut
 1. Swipe down from the status bar to expand all shortcuts, and then turn on **Bluetooth**.
 2. Tap ▼ to view the paired device list, and then select an available BT device.
- Through Settings menu
 1. Tap **Connected devices > Bluetooth**, and then turn on the BT switch.
 2. Tap **Pair new device**, and then the terminal automatically detects available devices.
 3. In the **Available devices** list, tap the desired BT Devices, and then tap **Pairing**.

Transmitting and receiving Files

With BT paired, apps such as the Snapdragon Gallery, Contacts, and Sound Recorder can transmit and receive files through BT. The followings take the Snapdragon Gallery as an example:

1. Tap  to open Snapdragon Gallery.
2. Select the desired picture or video to transmit, and then tap  and select **Bluetooth**.
3. Select the desired BT device to receive the file.
4. After the BT device receives the request, the terminal can transmit the file.


Other Operations

- Modifying the BT device name

With BT enabled, the terminal is discoverable to other BT devices with its model as the default device name. To better identify your device, tap **Device name**, and then modify the device name.
- Viewing the received files

To view the received files through BT, tap **Received files**.
- Bluetooth tethering

For detailed operation, see [3.1.3 Hotspot and Tethering](#).
- Unpairing a BT device

If a paired BT device is no longer used, tap  next to the paired device, and then select **FORGET** to unpair it.

3.8.2 NFC


NFC (Near Field Communication) is a wireless connection technology that offers easy, secure and fast communication. With this feature enabled, the terminal can be identified by compatible devices in a short distance, and then it exchanges data upon touching the devices.

To enable this feature, tap **Settings**  > **Connected devices** > **NFC**, and then turn on the **NFC** switch.

With NFC enabled, the terminal automatically enables Android Beam, through which, the two devices in touch can share specified app information, such as web pages and contacts.

3.8.3 USB


The terminal can be connected to the computer through a USB cable for charging or data transmission.

To configure this feature, connect the terminal to the computer with the USB cable, tap **Settings**  > **Connected devices** > **USB**, and then select one of the following USB connection mode:

- **Charge this device:** The terminal will only be charged.
- **Transfer files:** The terminal can transfer files with the computer.
- **Transfer photos (PTP):** The terminal can transfer photos with the computer.
- **Use device as MIDI:** The terminal can be used as the MIDI (Musical Instrument Digital Interface) input device to play music on the computer.

3.9 Product Information


3.9.1 Battery

To configure the battery, tap **Settings**  > **Battery** , and then you can perform the following operations:


Battery Saver

Battery Saver can reduce power consumption by decreasing the screen brightness or adjusting the sleep time.

To enable Battery Saver, do one of the following:

- Swipe down from the status bar to expand all shortcuts, and then turn on **Battery Saver**.
- Tap **Settings**  > **Battery** > Battery saver, and then perform the following configurations:

- To manually enable Battery Saver, turn on the switch.
- To enable automatic Battery Saver, tap **Turn on automatically**, and then select the condition to trigger battery saver.



Note

Battery Saver is disabled when the terminal is being charged.


Remaining Power Display

To display the remaining power in the status bar, turn on the **Battery percentage** switch.

3.9.2 Storage


Storage allows you to view the proportion of used storage, and release space for better use.

To extend the storage, you can install a Micro SD card.

To release the storage, tap Settings  > **Storage**, and then do one of the following:


- Manual Release

Tap **FREE UP SPACE**, and then remove the latest cached data such as pictures, videos, and app data.




- Auto Release

Tap **Storage Manager**, and then select the time period for automatic removal of pictures, videos, and app data that have been backed up.



3.9.3 About Product

To view the information about the terminal, tap **Settings**  > **System** > **About Phone**.

- To view the status of the terminal, tap **Status**, and then check the detailed information, including battery status, SIM status, IMEI information, serial number, and power-on time.
- To view the legal information of the terminal, tap **Legal information**, and then check the detailed information, including the third party license, system WebView license, and wallpapers.

4. Applications

4.1 Installation



Caution

- To protect the device from malware or viruses, download the trusted applications only.
 - To avoid personal information leakage or misuse, read the instruction carefully and operate with caution when installing an application.
-

If the default apps cannot meet your requirements, you can download more apps through browser, computer, Micro SD card or BT. During installation, open the installation package and follow the instructions. After the installation is completed, the app icon will appear on the app center.

4.2 Uninstallation


If you no longer use an app, you can uninstall it to release storage and improve terminal performance. To uninstall an app, do one of the following:

- On the app center, tap and hold the icon of the desired app, and then drag it upward to  on the top of screen.
- Tap **Settings**  > **Apps & notifications**, select the desired app from the list, and then tap **UNINSTALL**.

4.3 App Permissions

App Permissions allows you to view and set the permissions for apps to access privacy features, such as location information, storage, contact, phone, message, and camera, so as to protect your personal data and avoid information leakage.

To configure the app permissions, do as follows:

1. Tap **Settings**  > **Apps & notifications** > **App permissions**.
2. Select a privacy, and then turn on/off the switch next to the app to enable/disable its access to the privacy.



5. Communication Services


5.1 Phone


5.1.1 Initiating Calls

With a registered SIM card, you can initiate a call in one of the following ways:




- Manual Dialing

1. Tap  to open the Phone app.
2. Tap  to open the dial pad.





3. Enter the full number of the contact, and then tap  to initiate a call. Or enter the number, and then tap the desired contact from the search results to initiate a call.


- Contact

1. Tap  to open the **Phone** app.
2. Enter the contact list in one of the following ways:
 - Tap  to view the favorite contacts.
 - Tap  to view all contacts.
3. Tap the desired contact to initiate a call.

- Call Log

1. Tap  to enter the Phone app.
2. Tap  to view all call logs.

Tap  to select **Call history**, and tap  to view the call logs by categories.



3. Tap the desired call log to initiate a call.


5.1.2 Receiving Calls

Answering or Rejecting calls

When receiving an incoming call, you can answer or reject it.

- To answer the call, tap **Answer**.
- To reject the call, tap **Reject**.

Viewing Missed Calls



If any missed call exists, the status bar displays .

To view the missed calls, swipe down from the status bar, and read the missed call notifications.



5.1.3 Emergency Call

In case of emergency, you can initiate an emergency call within the carrier network coverage, even when no SIM card is installed.

To initiate an emergency call, do one of the following:

- When the screen is unlocked, tap  to open the **Phone** app, tap  to open the dial pad, and then initiate an emergency call.
- When the screen is locked, wake the screen, and then tap **EMERGENCY** to initiate an emergency call.



5.1.4 Other Operations


To configure other settings, such as the ring tone, alert tone, quick dial, reject message, and shield the call, tap  to open the **Phone** app, tap  on the right side of the search box, and then perform the desired operations.

5.2 Message


Message allows you to exchange text messages or MMS messages with other devices.


5.2.1 Sending Messages

1. Tap  to open the **Messaging** app.
2. Tap  to start a conversation.
3. Enter the phone number in the **To** text box.

To add more message receivers, tap  next to the **To** text box.

4. Enter the message content in the **Send message** text box.

If necessary, tap  to add pictures, videos, or audio files.

5. Tap  to send the message.



5.2.2 Receiving Messages

Upon reception of a message, you can view the message, and then reply the message or initiate a call to the message sender.

5.2.3 Other Operations



Archiving Messages

To archive a message, do as follows:

1. Tap  to open the **Messaging** app.
2. Tap and hold the message until the message editing icons appear on the top of the interface, and then tap  to archive the message.





Configuring Message Settings

To configure the message settings, do as follows:

1. Tap  to open the **Messaging** app.
2. Tap  at the upper right corner.
3. Select **Settings**.
4. Customize your message settings such as notification sound, delivery report etc.

Sharing, Copying, Forwarding and Deleting Messages

Open a conversation, select one or more messages, and then you can perform the following operations:

- To share the selected message(s) with others, tap .
- To forward the selected message(s), tap .
- To copy the selected message(s), tap .
- To delete the selected message(s), tap .

Note



To delete the entire conversation, tap and hold the conversation, and then tap .

5.3 Contacts

Contacts allows you to manage your contacts information, including phone numbers, e-mails, addresses etc.


5.3.1 Creating Contacts

To create a new contact, do as follows:

1. Tap  to open the **Contacts** app.
2. Tap  at the lower right corner.
3. Enter the contact name, phone number, and email address.
4. Tap **SAVE** at the upper right corner.


5.3.2 Managing Contacts

To manage a contact, tap the contact in the contact list, and you can perform the following operations shown in the figure below.



5.3.3 Searching for Contacts


To quickly find a contact in the contact list, do as follows:

1. In the **Contacts** interface, tap .
2. Enter the contact-related keywords.

Contacts meeting the keywords are displayed in the contact list.


5.3.4 Sharing Contacts

To share a contact with others, do as follows:


1. In the **Contacts** interface, tap and hold the contact.
2. Tap  at the upper right corner.
3. Select a way to share the contact, such as BT, email etc.

5.3.5 Deleting Contacts

To delete a contact, do as follows:

1. In the **Contacts** interface, tap .
2. Select one or more contacts, and then tap **Ok**.

5.3.6 Other Operations

In the **Contacts** interface, tap , and then you can perform the following operations:



- To view the contacts saved in the SIM card or the terminal, tap **SIM 1**, **SIM 2**, or **Device**.
- To configure the settings, tap **Settings** and customize your settings such as your profile, accounts, blocked numbers etc.

6. Multimedia Services

6.1 Snapdragon Camera


Snapdragon Camera allows you to shoot photos and videos.

To open the camera, do one of the following:

- When the screen is unlocked, tap  to open the camera.
- When the screen is locked, wake the screen, tap and hold  at the lower right corner, and then swipe upward to open the camera.




6.1.1 Photo Mode

The following figure shows the options available in the photo mode.



Photographing

To take a photo, do as follows:

1. Tap  to open camera.
2. Switch to the photo mode.
3. (Optional) Tap  to switch the front/rear camera.
4. (Optional) Zoom in or zoom out to increase or decrease the focal length.
5. Tap  to take the photo.

To view the photo you have taken, tap the thumbnail button.

Other Operations


- Selecting a capture mode

The camera provides the following professional shooting modes for your choice.

- **AUTO:** The AUTO mode allows the camera to automatically select an ideal capture mode according to the surrounding environment.
- **HDR:** The HDR (High-Dynamic Range) mode allows the greater dynamic range of exposures and produces pictures with correct brightness from bright parts to dark parts.
- **UbiFocus:** The UbiFocus mode allows the camera to take an all-in-focus image. After taking the photo, you can tap the picture to re-focus the desired places.
- **OptiZoom:** The OptiZoom mode allows you to lock an object that the camera will automatically zoom in. When the object moves, the camera adapts the zooming to clearly capture it.
- **Other modes:** Besides, Snapdragon Camera provides a number of shooting modes for different objects and scenes, including **Portraits, Landscape, Sports, Flowers, Backlight, Candlelight, Sunset, Night, Beach, and Snow.**


- Applying a filter

In AUTO mode, the camera provides various filters for different effects.


In the viewfinder, tap  and select a filter among **Mono, Sepia, Negative, Solarize, Posterize, Aqua, Emboss, Sketch, and Neon.**

To turn off the filter, select **None.**

- Configuring the camera


In the viewfinder, tap  and then you can perform the following operations.

- **Flash:** Tap **Flash** and select **Off, Auto, or On.** The flash provides extra lighting when you take pictures in dim light conditions.

- GPS Location: Tap **GPS Location** and select **Off** or **On**. With this feature turned on, your geographic location will be recorded when you take a photo.
- Picture Size: Tap **Picture size** and select the picture resolution. A photo of higher resolution consumes more storage.
- Picture Quality: Tap **Picture quality** and select the quality as **Low**, **Standard**, or **High**.
- Storage: Tap **Storage** and select **Phone** or **SD Card** to store the pictures you take. The pictures are stored in the terminal by default.
- Continuous Shot: Tap **Continuous Shot** and select **On** or **Off**. The Continuous Shot feature allows you to continuously take a number of photos when you tap and hold .
- Redeye Reduction: Tap **Redeye Reduction** and select **Disable** or **Enable**. With this feature enabled, the camera automatically removes the redeye effect from the photo when you photograph a person in dim light.





6.1.2 Video Mode



The following figure shows the options available in the video mode.




Recording a Video

To record a video, do as follows:


1. Tap  to open camera.
2. Switch to the video mode.
3. (Optional) Tap  to switch the front/rear cameras.
4. (Optional) Tap  to mute the video.
5. (Optional) Zoom in or zoom out to increase or decrease the focal length.
6. Tap  to start recording video.

On the top of the recording interface, tap  to pause, and  to resume.

7. Tap  when you finish recording.

To view the video you have recorded, tap the thumbnail button.



Other Operations

In the viewfinder, tap , and then you can perform the following operations:

- **Flash:** Tap **Flash** and select **On** or **Off**. The flash provides extra lighting when you record videos in dim light conditions.
- **Video Quality:** Tap **Video quality** and select the video resolution. A video of higher resolution consumes more storage.
- **Video Duration:** Tap **Video duration** and select the duration of the video you can take.
- **GPS Location:** Tap **GPS Location** and select **On** or **Off**. With this feature turned on, your geographic location will be recorded when you take a video.
- **Storage:** Tap **Storage** and select **Phone** or **SD Card** to store the video you record. The videos are stored in the terminal by default.

6.1.3 Panoramic Mode


The Panoramic mode allows you to take one photo to cover the whole scene instead of taking multiple photos, when you require a wide angle to capture scenery or persons. To take a panoramic photo, do as follows:


1. Tap  to open the camera.
2. Switch to the panoramic mode.
3. Hold your device steady and tap  to start shooting.
4. Move the lens slowly in the same horizontal direction until the progress bar gets full.

To view the panoramic photo you have taken, tap the thumbnail button.


6.2 Snapdragon Gallery

The Snapdragon Gallery allows you to view, share, and manage the pictures or videos.

To open the gallery, tap , and then you can perform the following operations.




6.2.1 Viewing Pictures or Videos


Open the Snapdragon Gallery, tap  at the upper left corner:



- Tap **Timeline** to view all pictures and videos by the time they were taken.
- Tap **Albums** to view pictures and videos taken by camera, downloaded images, or screenshots.
- Tap **Videos** to only view the videos.




6.2.2 Playing Videos

To play a video, do as follows:


1. In the gallery, select the video you want to play.
2. Tap  to start play.
3. During the play, you can perform the following operations:




- Tap  to pause, and tap  to resume.


- Tap  to play the video in full screen, and tap  to exit.
- Tap  to capture a video screenshot.





6.2.3 Cutting Videos






1. In the gallery, select the video you want to cut.
2. Tap  and select **Trim**.
3. On the progress bar, move the two blue balloons to set the starting and ending points, and then tap **SAVE**.

6.2.4 Editing Pictures

1. In the gallery, select the picture you want to edit.
2. Tap  to enter the edit interface, and then perform the following operations:




- Tap and hold  at the upper right to view the original picture, and release it to view the edited picture.
- Tap  to select the color of the picture to display.
- Tap  to cut, straighten, or rotate the picture.
- Tap , and then swipe the sliders to adjust the exposure, contrast, saturation, and brightness of the picture.

- Tap  to beautify face in the portrait photo.
- Tap  to calibrate the lenses.
- Tap  to remove the haze from the picture.
- Tap  to enhance pictures of people.
- Tap  to add a watermark to the picture.

3. After editing, tap **SAVE** in the upper right corner.


6.2.5 Sharing Pictures or Videos

To share a picture or video, do as follows:

1. Tap and hold the picture or video you want to share.
2. Tap .
3. Select a way to share the contact, such as BT, email etc.

6.2.6 Deleting Pictures or Videos


To delete a picture or video, do as follows:

1. Tap and hold the picture or video you want to delete.
2. Tap , and then select OK to confirm deletion.


6.3 Videos

The **Videos** app lists all the videos in the terminal, and allows you to play, share, or trim the selected video. For details, see [6.2 Snapdragon Gallery](#).


6.4 Music

The **Music** app allows you to play the audio files saved in the terminal or SD card. To open the **Music** app, tap , and then you can perform the following operations.







6.4.1 Playing Music

To play an audio file, directly tap the file you want to play. Also, you can tap  and play music by the


Artists, Albums, Songs, or Playlists.



In the music play interface, you can perform the following operations:

- Tap  to pause playing.
- Tap  to resume playing.
- Tap  to enable or disable the repeat playback.
- Tap  to enable or disable the shuffle play.
- Tap  or  to play the previous or next song.


6.4.2 Other Operations

1. Select a song in the playlist.
2. Tap , and then do as follows:
 - Use the song as phone ring tone.
 - Share the song with others through BT, Messaging, or email etc.
 - Delete the song.

7. Google Apps



A Google account is required before you use the Google apps. Otherwise, your access to Google services may be totally or partially restricted.

To create your Google account, you can:

- Follow the setup instructions of the terminal in [2.1 Activating the Terminal](#).
- Tap **Settings**  > **Users & accounts** > **Add account** > **Google**, and then follow the on-screen instructions.


For more details of the Google account, visit <http://support.google.com/account>.

7.1 Chrome

Google Chrome™  allows you to browse the website. To open the Chrome browser, tap  in the app center.


Caution

To protect your device from malware or viruses, visit trusted website only.



7.1.1 Multipage Operations

In the browser interface, tap the Multipage icon to view all webpages, and then perform the following operations:



- To open a new webpage, tap **+**.
- To switch among multiple webpages, swipe up or down the webpages, and then select the page you want to view.
- To close a webpage, tap **X** on the selected webpage, or swipe it left or right.

7.1.2 Webpage Settings


Open a webpage, tap **:** and then you can perform the following operations:

- To refresh the webpage, tap **↻**.
- To download the webpage, tap **↓**.
- To mark the webpage as a favorite site, tap **☆**.
- To share the current webpage, tap Sharing....
- To search on the webpage, tap Find in page, enter the key words in the text box, and then the webpage highlights the search results.
- To switch to the desktop website, select Desktop site, and then the current page is converted into a computer version.

7.1.3 Bookmark Operations

To enter the Bookmark interface, open a webpage, tap Settings **:** > Bookmarks, and then you can view all bookmarks in the browser.

To access a bookmark, tap the desired one in the list.



To manage a bookmark, tap and hold the desired bookmark in the list, or tap  next to each bookmark, and then you can edit, move, or delete the bookmark.


7.1.4 History

To view the history websites you have visited, tap Settings  > History.

To clear the history, tap CLEAR BROWSING DATA, select the specific time range and content, and then tap CLEAR DATA.


7.1.5 Download

To view all files you have downloaded through the browser, tap Settings  > Downloads. To view and change the download storage location, in the Download interface, tap .

To share or delete the downloaded file, tap and hold the file in the download list, or tap  next to each file.


For more details of the app, visit <http://support.google.com/chrome>.

7.2 Drive

Google Drive™  allows you to manage the files you have saved in the drive cloud account. You can store files of photos, recordings, and videos in Drive, and then the Drive synchronizes the files with the terminal, smartphone, or computer. You can also view or rename the files, and share the files with other devices.


For details of the app, visit <http://support.google.com/drive>.

7.3 Duo

Google Duo™  allows you to initiate or receive a video call to or from a contact. With a simple user interface, you can initiate a video call with a tap. With the Knock Knock feature, you can see live video of your caller before answering the call.


For details of the app, visit <http://support.google.com/duo>.

7.4 Gmail

Google Gmail™  allows you to send and receive emails, and manage the emails in different boxes. You can archive important emails, or delete the ones you no longer need. With spam filtering feature, you can also use Gmail to block spam for a better experience.


For details of the app, visit <http://support.google.com/gmail>.

7.5 Google

Google™  allows you to customize the contents to update on the internet. You can use customize feed to select your favorites and follow the topics that most interest you. Google also uses your search history to recommend stories for you, and allows you to follow or remove, so that you can better personalize your Google.

For details of the app, visit <http://support.google.com/websearch>.


7.6 Maps

Google Maps™  allows you to position your location and explore the local businesses, gives directions for driving, and provides traffic information for other kinds of transportation.

Before using the Maps, make sure to enable the location services on the terminal.


For details of the app, visit <http://support.google.com/maps>.

7.7 Photos

Google Photos™  can analyze and organize your images into categories, and gives you a quick access to the desired image by searching by different categories (for example, People, Places, and Things). The Photos also allows you to store and back up your photos and videos.


For details of the app, visit <http://support.google.com/photos>.

7.8 Play Movies & TV

Google Play Movies & TV™  allows you to watch the high-quality movies and TV shows that you have purchased or rented on the app. You can pre-order the content and have it automatically delivered upon release. You can also view the videos you have saved in the terminal.


For details of the app, visit <http://play.google.com/store/movies>.

7.9 Play Music

Google Play Music™  allows you to listen to music online and offline. With the music streaming service, you can listen to the online songs in the Google catalog. You can also download the songs and store them on the app for offline playback.


For details of the app, visit <http://support.google.com/googleplaymusic>.

7.10 Play Store

Google Play Store™  allows you to search and purchase Android apps and games. In the digital library you can view the detailed features of the apps or games, and then easily download and install them on the terminal. You can also search files of music, videos, or books for more entertainment.

For details of the app, visit <http://support.google.com/googleplay>.

7.11 YouTube






Google YouTube™  allows you to watch and upload videos, and subscribe to other users or channels on the app. You can view the trending videos, search the content among a variety of categories, and follow the users you like. After registering, you can also upload your video with annotations and share it with the world.

For details of the app, visit <http://support.google.com/youtube>.

8. Utility Apps

8.1 File Manager

File Manager allows you to manage all your files, including pictures, videos, audio files, and downloaded applications.

1. Tap .
2. View files.
 - a. tap  on the left side of the screen.
 - b. Do one of the following:
 - To view files by categories, tap **Images, Videos, Audio, Recent, or Downloads**.
 - To view all files, tap the terminal icon.
3. Manage files.
 - a. Tap and hold the file.
 - b. Do as follows:
 - To share the file, tap  and select a way, such as BT, email etc.
 - To delete the file, tap , and then confirm the deletion.
 - To copy, move, compress, or rename the file, tap , and then perform the desired operation.


8.2 Sound Recorder





Sound Recorder allows you to record voice at any time during your work time or daily life.

8.2.1 Recording Audio Files

To record an audio, do as follows:


1. Tap  to open the recorder.



2. Tap  to start recording.
During recording, tap  to pause, and tap  again to continue recording.
3. Tap  to finish the recording.
The "Save recording?" dialog appears.
4. Enter the file name and tap **SAVE**.





8.2.2 Viewing Recording Files

To view the recording files, do as follows:

1. In the recording interface, tap  to enter the **Recording** list.
2. In the recording list, tap a recording file to replay it.


8.2.3 Managing Recording Files

To manage recording files, do as follows:

1. tap  to enter the **Recording** list.
2. tap and hold a recording file.
3. Rename, share, or delete the recording file.
 - To rename the file, tap  to enter the name, and then tap **Save**.
 - To share the file, tap , and then select a way to send the file, such as BT, email etc.
 - To delete the file, tap , and then select **DELETE** to confirm deletion.





8.3 Clock

The Clock can manage the alarm clock, world clock, timer and stopwatch.

To open the Clock, type .




8.3.1 Setting the Alarm Clock

To set an alarm, do as follows:

1. Tap  **ALARM** to enter the alarm interface.
2. Tap  to add an alarm.
3. Tap the clock pointers to set the time, or tap  in the lower left corner to enter the time, and then select **OK**.
4. Set the repeating period, ringtone, or the label of the alarm clock, and then tap  to hide these parameters.



8.3.2 Viewing the World Clock

To view the city time of another time zone, do as follows:


1. Tap  **CLOCK** to enter the clock interface.
2. Tap  at the bottom to enter the world clock list.
3. Select a city time, type , and then you can view the city time in the clock interface.

8.3.3 Using the Timer

To use timer, do as follows:



1. Tap  to enter the timer interface.
2. Enter the desired time duration.
3. Tap  to start the countdown.

During the countdown, you can perform the following operations:


- Tap  to pause the timer.
- Tap **DELETE** to delete the current timer.
- Tap **ADD TIMER** to add a new timer.

8.3.4 Setting the Stopwatch

To use stopwatch, do as follows:

1. Tap  **STOPWATCH** to enter the stopwatch interface.
2. Tap  to start timing.


During the timing process, you can perform the following operations:

- Tap  to pause the timer.
- Tap **RESET** to delete the current timer.
- Tap **LAP** to add one lap and put the current value of stopwatch to the lap list.

8.4 Calendar


The Calendar allows you to schedule activities such as work plans, travel plans, and birthday reminders.

To view your calendar, do as follows:

1. Tap  to open the calendar.
2. At the top of the **Calendar** interface, tap the current year and month, and then select **Day**, **Week**, **Month**, or **Agenda** to view.


8.4.1 Adding Accounts

To add an account to the calendar, do as follows:



1. In the **Calendar** interface, Tap .
2. Select **Settings**.
3. Tap **ADD ACCOUNT** in the upper right corner, and then add a personal mailbox account.

8.4.2 Adding Activities


After adding an account, you can add an activity through the calendar. Do as follows:

1. In the **Calendar** interface, tap .
2. Select **New event**.
3. Enter the activity title and location, and then set the duration, importance level, repetition period and reminder time.

8.4.3 Searching for Activities

1. In the **Calendar** interface, tap .
2. Select **Search** and enter the related keywords in the search text box.
3. Tap  on the keypad, and then the activities meeting the keywords are displayed in the interface.


8.4.4 Setting the Calendar


To configure the calendar, in the **Calendar** interface, tap  > **Settings** > **General settings**, and then perform the following operations:

If you tap...	You can...
Show week number	view the week number in the calendar interface.
Week starts on	select Locale default , Saturday , Sunday , or Monday as the first day the week.
Use home time zone	always view calendar data and event time in your home time zone, even when you travel around.
Clear search history	remove all the search records.
Notifications	set the notification for the event reminder, such as Sound , Vibrate , and Pop-up notification .

If you tap...	You can...
Default reminder time	select the time to remind you of an event in advance.

8.5 Calculator


The Calculator allows you to perform basic calculations. To open the Calculator, tap  in the app center, and then swipe left or right to enter the math symbols or numbers.




9. System Upgrade

Caution

- Use the official software only to upgrade the system, to prevent equipment failure, data loss, or damage to the system security.
 - Be sure to back up your data before upgrade.
 - Ensure that the battery power is more than 30% before upgrading.
-

The terminal prompts  in the status bar when the latest software version becomes available.

To upgrade the terminal, do as follows:

1. Connect to the network and tap  in the status bar.
2. Tap **CHECK UPDATE** to detect the new version.
3. Download and install the latest upgrade package.

When upgrade is completed, the terminal will automatically restart.

To configure the upgrade, do as follows:

1. In the **System upgrade** interface, tap **SETTINGS**.
2. Set the upgrade.
 - Auto check for update: The terminal automatically checks the latest package on a daily basis when the cellular data network is connected.
 - Wifi auto download: The terminal automatically checks and downloads the upgrade package when Wi-Fi is connected.

10. Troubleshooting

Phenomena	Analysis	Solution
You cannot turn on the terminal.	The battery may be improperly installed.	Remove and reattach the battery.
	The battery power may run out.	Recharge or replace the battery.
	The battery may suffer from poor contact caused by dirty or damaged battery contacts.	Clean the battery contacts.
The terminal is frozen with no response to your operations.	The terminal runs too many apps.	Stop some running apps or restart the terminal.
You cannot use the keys.	The keys may not work temporarily.	Restart the terminal and try again.
	The keys are damaged.	Contact your dealer to repair.
The LED indicator works abnormally.	The LED indicator gives wrong indications.	Restart the terminal and try again.
	The LED indicator is damaged.	Contact your dealer to repair.
The touchscreen displays nothing.	The touchscreen may not work temporarily.	Restart the terminal and try again.
	The touchscreen is damaged.	Contact your dealer to repair.
You cannot connect the terminal to mobile network.	An error occurs to the SIM card.	Ensure that the SIM card can be identified.
	The SIM card is suspended.	Restart the terminal after subscription.
	The SIM card does not support data	Contact the carrier or your dealer to enable

Phenomena	Analysis	Solution
	service.	the data service.
	The signal is poor.	Ensure that the terminal is within signal coverage.
	The terminal is connected to Wi-Fi and the cellular data network. But the Wi-Fi network is unstable.	Disconnect the Wi-Fi network.
During receiving, the voice is weak or discontinuous.	The signal is poor.	Ensure that the terminal is within signal coverage.
	The volume level may be low.	Increase the volume
	The speaker is blocked or damaged.	Clean the surface of the speaker.
You cannot use the camera.	No front or rear camera is detected.	Restart your terminal and try again.
	The memory is insufficient.	Clear the memory.
The SIM card or SD card cannot be identified.	The SIM card or SD card is not properly installed.	Remove and reattach the SIM card or SD card.
	The SIM card or SD card may suffer from poor contact caused by dirty or damaged battery contacts.	Clean the metal contacts of the SIM card or SD card.
The GPS cannot locate your position.	The terminal may be at an unfavorable position, so that no GPS signal is received.	Move to open and flat area, and restart the GPS.
You cannot charge the battery.	The power adapter may suffer from poor contact.	Reconnect the power adapter.
	The data cable may suffer from poor contact.	Reconnect the data cable.

If the above solutions cannot fix your problems, or you may have some other queries, contact your dealer or the Company for more technical support.

11. Care and Cleaning

To guarantee optimal performance as well as a long service life of the terminal, follow the tips below.

11.1 Product Care

- Do not pierce or scrape the screen of the terminal.
- Do not drop the terminal or collide with other objects.
- Keep the terminal far away from substances that can corrode the circuitry.
- Do not hold the terminal by the earpiece cable.

11.2 Product Cleaning

Caution

Turn the terminal off and remove the battery before cleaning.

- Clean up the dust and fine particles on the terminal surface and charging piece with a clean and dry lint-free cloth or a brush regularly.
- Use neutral cleanser and a non-woven fabric to clean the screen, keys, knobs, and front case after long-time use. Do not use chemical preparations such as stain removers, alcohol, sprays or oil preparations, so as to avoid surface case damage.
- Make sure the terminal is completely dry before use.

12. Optional Accessories

Caution

Use the accessories specified by Hytera only; otherwise, we will not be liable for any loss or damage arising out of the use of any unauthorized accessories.

Contact your dealer for the optional accessories used with the terminal.