

FCC ID: YAW522350L

Label (Contains FCC ID XMR201605EC25A):



95.0

SunPower PV Supervisor 5x (PVS5x)

See the PVS5x documentation for safety information and complete instructions and operating procedures.


Follow instructions to connect to the PVS5x then commission at:
<http://www.sunpowerconsole.com>.

PVS5x Cable Termination


PVS5x (all ports)	2-Wire RS-485 (D+, D-, GND)
	

RJ-45 Plug Clip is painted away from you

WARNING: The installation and servicing of this device must be performed by qualified and trained personnel only. No user serviceable parts inside. Follow proper safety precautions and warnings. Disconnect power before servicing. Device must be wired in accordance with the NEC and use appropriately sized overcurrent protection.



FCC ID: YAW522350L



ITE: E477122
Enclosure rated as
UL Type 3R

INPUT: 0.2 A @ 240 VAC, 50/60 Hz or 0.2 A @ 208 VAC (2-pole), 60 Hz


This device complies with part 15 of the FCC Rules. Operations subject to the following two conditions (1) This device may not cause harmful interference and (2) this device must accept any interference received include interference that may cause undesired operation. Contains transmitter module FCC ID: XMR201605EC25A.

<http://www.sunpower.com>
Patented as shown at www.sunpower.com/patents

☐

132.0

Unit : mm



Label Location