


3 AA Batteries For The Vehicle

ATTENTION Do not mix old and new batteries. Do not mix alkaline standard(carbon-zinc)or rechargeable(nickel-cadmium)batteries. Only the same or equivalent type of batteries are recommended. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged(if removable). Rechargeable batteries are only to be charged under adult supervision (if removable). Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited. Colors and contents may vary from illustration.



2 AA Batteries For The Transmitter.

TO REPLACE BATTERIES Open the battery compartment cover, position the batteries as shown in the photo,make sure that the(+)&(-)are in the correct position.To ensure proper safety and operation,batteries must always be replaced by adult.Never let a child use this product unless battery door is secured.Keep batteries away from small children. Immediately and safely dispose of all used batteries.

Cantion: The user is Cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



Made In China

SPECIFICATIONS AND COLORS OF CONTENTS MAY VARY FROM PHOTO. SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. KEEP THIS INFORMATION FOR FUTURE REFERENCE. PACKING IS NOT A TOY.TAKE IT AWAY FROM CHILDREN.



WARNING:

CHOKING HAZARD-Small parts.
Not for children under 3 years.