

Notebook V70A

User's Guide

Preface

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

Limitation of Liability

While reasonable efforts have been made to ensure the accuracy of this manual, the manufacturer and distributor assume no liability resulting from errors or omissions in this manual, or from the use of the information contained herein.

Federal Communications Commission Radio Frequency Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference; and 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced Notebook technician for help.

NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: Changes or modifications not expressly approved by COLD SCORE could void the user's authority to operate the equipment.

Index

- Chapter 1. Preface
- Chapter 2. Setup Computer
- Chapter 3. Install operation system and drive

User guide

Dear customer:

Thanks very much for your choice!


Your computer combines powerful information processing and convenient mobility. It enhances your efficiency whenever you are in the office, on-the-go or at home

Chapter 1: Preface

■ Packing List

Please do not open the carton box, check the content with the packing list. If anything is missed or faulty, please contact with the provider.

■ Insert and remove battery




■ Connect adapter



Chapter 2: Setup computer

For reference




■ Open the panel

Open the panel directly, adjusts the angel of LED for comfortable viewing. Please be gentle when open or close the panel. Any rough handling may cause damage to your computer.

■ Run your computer

Please connect adapter or insert battery, then press power button more then 1 seconds to start your computer.




Item Description

- 1 Power LED Blue light indicates system is on, Flashing light indicates system is in standby.
- 2 Charger / Discharge LED status indicator Blue indicates fully charged, Orange indicates battery is being charged. Flashing orange indicates battery in running low.
- 3 HDD LED Blue light indicator HDD is in use.
- 4 Wireless LED Blink blue light indicates its connect to AP, it is off when the wireless LAN is not active.

■ Shortcut keys

To use the following function, hold down the 'Fn' key, and at the top of the keyboard function keys (F2 ~ F12).

keys	Description	keys	Description
Fn + F2	change-screen	Fn +F9	Enable or disable volume
Fn + F3	Enable/disable the touchpad	Fn +F10	N/A
Fn + F4	Decrease Screen brightness	Fn +F11	On / off the wireless
Fn + F5	Increase the brightness	Fn+F12	sleep
Fn + F6	N/A	Fn+NumLk	Enable / disable Number Lock
Fn + F7	turn down the volume	Fn + ScrLk	N/A function
Fn + F8	turn up the volume		



Specification:

Displayscreen	10.2"LED
Pixels	1024*600
Aspect Ratio	300:1
Processor	INTEL N270 1.6G
Chipset	945GSE+ICH7M
Frequency	1.6G
L2 Cache (KB)	512KB
FSB	533MHZ
HDD	160G
HDD Type	SATA
Memory	1GB
Memory Type	DDR II


Memory support	667MHZ
Memory Max	2GB
Video Chipset	INTEL GMA950 integrated
Audio	HDA 2.1
Web Cam	3.0m px
Wireless LAN	802.11 B/G
I/O	USB2.0*3+AUDIO*2+VGA*1
LAN	10/100M
CardReader	3 MMC/MS/SD CARD
A/C Adaptor	19V 2.5A
Battery	2200MAH 3CELL
Dimension	265*185*30mm

Chapter 3. Install operation system and drive

■ Install operation system

Before installing, you should set BIOS as boot device. The method as following: Start your computer; Press [DEL] to enter BIOS-setup interface.


Then use[→] or [←] key to select boot, choose a device and press “+” or “-” to set the boot order; If it in Excluded from boot order, press “↑ ↓” to move it to boot priority order.




● Main menu

MAIN menu: Set system time, data channel and show relative information such as BIOS, EC, MB Version, system memory etc.

● Boot menu




● Security menu



Security menu: allows you to configure security setting.

● Exit menu



Exit menu: exiting from the BIOS program

Exit Saving Changes: exit the BIOS and save the changes you have made.

Exit Discarding Changes: exit the BIOS without saving.

Load Setup Defaults: Reset the BIOS settings to the defaults mode.

Discard Changes: Restore the BIOS settings to the last changes you had made.

Save Changes: save the setting

■ Install program driver


Please use the disk come with your computer, Please follow the step to complete installing.

Option 1: Program driver

Option 2: Application programmer.

Maybe the System should re-star while installing.

Main menu Exit menu



Exit menu: exit from the BIOS program
Exit Saving Changes: exit the BIOS and save the changes you have made
Exit Discarding Changes: exit the BIOS without saving
Load Setup Defaults: Reset the BIOS settings to the default mode
Discard Changes: Restore the BIOS settings to the last changes you had made
Save Changes: save the setting