

## EACH UNIT USE ONE 9V BATTERY (NOT INCLUDED). **COLOR AND DESIGN MAY VARY.**

- Replacement of batteries must be done by adult.
- Do not mix old and new batteries
- Do not mix alkaline, standard(carbon-zinc) or rechargeable (nickel-cadmium) batteries
- Do not use rechargeable batteries.
- The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the toy.
- Only batteries of the equivalent type are to be used.
- Batteries are to be inserted with the correct polarity.

## PLEASE RETAIN PACKAGE FOR FUTURE REFERENCE

#### WARNING:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS **EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S** AUTHORITY TO OPERATE THE EQUIPMENT.











## MADE IN CHINA

# HOW TO USE RING CALL FUNCTION:

- 1. For transmitting a signal, turn on the transceiver by rotating the On-Off Volume Control past click.

  2. While pushing the PUSH-TO-TALK button, press in the Ring call
- button momentarily and release for desired signals.
- 3. For receiving a signal, adjust Volume Control for normal listening
- 4. When back to Voice communications again, use normal PUSH-TO-TALK operation.


## HOW TO OPERATE YOUR TRANSCEIVER:

- 1. Remove screw and open battery door and snap in a 9V battery.
- 2. Turn on the transceiver by rotating the On-Off Volume Control
- past click. Your transceiver is now ready to operate.

  3. Press the PUSH-TO-TALK button for transmitting.
- 4. Release the PUSH-TO-TALK button for receiving.
- 5. When transmitting speak clearly in a normal voice, holding the set about 3 inches from your mouth.
- 6. Best transmission and reception are obtained when the antenna is held in a vertical position-

#### CAUTION:

- 1. Your Transceiver Set has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replacing the battery.
- 2. When the sound becomes weak, it is time to change the battery.
- 3. After use, always return the On-Off Volume Control to the OFF
- 4. Keep your set in a dry and clean place.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

□ Reorient or relocate the receiving antenna.
□ Increase the separation between the equipment and receiver.
□ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
□ Consult the dealer or an experienced radio/TV technician for help.

NARNING: CHOCKING HAZARD-small parts Not for children under 3 years