

INSTRUCTIONS

Dear Customer,
Thank you very much for buying our Bluetooth headset . Please read this manual before using.

1. Note

- *Please use and store this product at normal temperature environment ;
- *Do not expose this product to rain or wet conditions;
- *Do not drop, to avoid damage the product ;
- *Do not disassemble,Repair and modification the product by yourself.
- *This product is built-in lithium battery, do not discard or set to fire to avoid dangerous!

2. Safety Tips

- *Please do not listening music at high volume to protect your hearing and the products.
- *Turn off the power switch immediately when the product no working, To prevent damage of headset and other components.
- *Please charge the bluetooth headset on time, Since low battery power will affect the distance and could make disconnect.

3. Technical Data

- *Bluetooth specification: Bluetooth V3.0&V4.0
- *Transmission distance: ≤10M (due to environmental and the different Bluetooth devices)

*External Battery: Lithium Polymer batteries.

- *Frequency Response: 100Hz-20KHz
- *Sensitivity: 80db ± 2db
- *Signal to noise ratio: ≥ 85dB

4. Components

- * Headset x1
- *3.5 audio cable x 1

*Manual x 1

5. Common Functions

1) Turn on the headset

2) **Bluetooth connection:** Turn on the headset and it will come to pairing mode automatically, blue lights flash.

Turn on the bluetooth of your mobile and search for the headset ,When your phone find out the headset

Choose and confirm to connect it. If need any password or Pin please enter 0000.

And this bluetooth headset has memory connection function, It will connect with the last mobile automatically when next time using..

6. Compatibility:

BLUETOOTH 3.0 or higher version of the device (the relevant agreements, please refer to general specifications), Such as IPAD, IPHONE, IPOD TORCH, MAC with Bluetooth , and most of Bluetooth smart phone or computer. BLUETOOTH V3.0 includes the following profiles: A2DP, AVRCP, HFP,

7. FAQs:

Questions	Solutions
Unsuccessful pairing	1. Recheck if the headset in the pairing mode. Or restart the 2. Too much bluetooth devices around causing the search difficult. Please close other Bluetooth devices. 3. Battery is low, Pls charge it in time.
Sound distorted/ Sound is low	1. Check the volume of the Bluetooth devices and adjust the volume to a proper Position. 2. The battery voltage is low, Please charge on time. 3. Battery is low, Pls charge it in time.
The music not smooth playing	1. Beyond the effective distance, or there is barrier between the headset and devices. 2. Battery is low, Pls charge it in time.
Not working, System halted, Can not turned on	1. Low battery, Please charge again 2. Restart the

8. Button definition and operation

MODE	KEY	Operation	Functions	
BLUETOOTH MODE	Music	⏮ / -	Long Press	Volume Down
			Short press	Previous song
		⏸	Long Press	NO
			Short press	Play/Pause
		⏭ / +	Long Press	Volume Up
			Short press	Next song
	M	Long Press	NO	
		Short press	Switch Mode	
	Phone	⏮ / -	Long Press	Volume Down
			Short press	Transferred to phone
⏸		Long Press	Long press about 2S to reject the call	
		Short press	1 Short click to pick up the phone. 2 Three-click to redial the last Number	
⏭ / +		Long Press	Volume Up	
		Short press	Transferred to phone	
M		Long Press	NO	
		Short press	Switch Mode	

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

User Manual

Model name:S310

Brand name:ROMAN

FCC ID:YGKS310