


# USING INSTRUCTION OF (REMOTE CONTROL) R/C CAR.

THANK YOU VERY MUCH FOR USING SENIOR R/C CAR PRODUCED BY OUR FACTORY. PLEASE READ THIS USING INSTRUCTION CAREFULLY AND GET ENOUGH UNDERSTANDING OF THIS PRODUCT IN ORDER TO BETTER USE IT.

- **BREAKOUT** ① New battery should be charged 8 hours before using it
- ② As for non-chargeable battery, Please install "1.5V" battery.

## CHARACTERISTIC (PARTS)



## SAFETY TIPS

- NOT SUITABLE FOR KIDS UNDER 3 YEARS OLD.
- FINGER, HAIR AND CLOTHES ARE FORBIDDEN TO TOUCH THE WHEEL IN ORDER TO AVOID BEING DAMAGED.
- DO NOT TOUCH THE R/C CAR DURING RUNNING PROCESS. THE LAUNCHER AND R/C CAR SHOULD NOT BE PLACED ON HOT PLACE (LIKE ELECTRIC STOVE, GAS STOVE AND PLACE WITH TOO STRONG LIGHT)
- DO NOT OPERATE ON DANGEROUS PLACE (SUCH AS ROAD, AND SO ON).
- R/C CAR DO NOT GET WET. DO NOT OPERATE OUTSIDE WHEN IT'S RAINING.
- DO NOT OPERATE ON THE SAND.
- DO NOT LET THE CHILDREN CASUALLY LOAD AND UNLOAD THE LAUNCHER AND CAR..
- IF BREAKDOWN HAPPENED DURING PROCESS OF USING, IT SHOULD BE CHECKED AND REPAIRED BY ADULTS. ASK THE SPECIALIST TO REPAIR WHEN NECESSARY.
- changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## USING TIPS OF BATTERY

- YOU SHOULD CHECK WHETHER THE POSITIVE CATHODE AND NEGATIVE CATHODE EACH IS INSTALLED CORRECTLY OR NOT WHEN INSTALLING.
- CHARGE THE NON-CHARGEABLE BATTERY IS FORBIDDEN..
- DO NOT MIX WITH THE DIFFERENT TYPES OF BATTERIES OR MIX THE OLD BATTERIES WITH THE NEW ONES.
- PLEASE TAKE OUT THE BATTERY WHEN NOT USED.
- DO NOT LET THE BATTERY WHICH THE ELECTRICITY HAS BEEN EXHAUSTED STAY IN THE TOY.
- AS FOR STORAGE OF BATTERIES, BATTERIES SHOULD NOT BE KEPT CONTACTING WITH EACH OTHER IN ORDER TO PREVENT FROM LEAKAGE.
- DO NOT PUT THE BATTERY INTO THE FIRE
- PLEASE GUARANTEE SAFETY WHEN DISCARDING BATTERY.

## TIPS ABOUT CORRECTLY OPERATE THIS R/C CAR

- IN THE NEAR DISTANCE, LIKE MANY CARS USE THE SAME FREQUENCY, IT MAY CAUSE MUTUALLY INTERFERING AND CAUSE POOR PERFORMANCE.
- WALL WHEN USING. PLEASE KEEP THE ANTENNA OF THE LAUNCHER UPWARD IN ORDER TO OPTIMIZE ITS BEST PERFORMANCE.
- IF NO RESPOND FROM THE CAR OR MOVING SLOWLY OR REMOTE CONTROL SCOPE IS GREATLY REDUCED, PLEASE REPLACE THE CAR AND R/C BATTERY.
- DO WITH THE WAY OF REMOTE CONTROL.
- DURING THE SITUATION OF NO INTERFERENCE, ITS REMOTE CONTROLLING DISTANCE CAN BE FURTHER DURING THE SITUATION OF INTERFERENCE, REMOTE CONTROLLING DISTANCE WILL BE NEARER.