

## iTrip Aux Bluetooth

### Operating Instruction

- Plug the iTrip into your car's 12V power socket
- Use the supplied audio cable to connect your iTrip's audio jack to the AUX IN jack of your car stereo.
- The first time you use the iTrip with any Bluetooth device, you must pair them to each other. Once the iTrip is power on, it will enter the pairing mode and the blue LED will blink rapidly.
- Open the setting menu of the Bluetooth device and pair your device with the iTrip.
- Once the ITrip is paired successfully with your Bluetooth device, the blue light will turn solid.
- After the first time use, the ITrip will reconnect to the last paired device automatically when it is power on. If the ITrip cannot find the last paired device, it will enter the pairing mode and you can pair with another Bluetooth device.
- When the ITrip is connected with a Bluetooth device, you can press the button to disconnect from the Bluetooth device and the ITrip will enter the pairing mode. This way you can pair the ITrip with another Bluetooth device if you want.
- The iTrip will go into sleep mode if there is no pairing action within 3 minuts. The blue LED will turn off in sleep mode.
- When the ITrip is in pairing mode or sleep mode, press the button and the ITrip will enter reconnect mode again.

#### FCC statement:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.