

FOLDED SIZE: 9 X 6 CM

材质：157g双铜 四色双面印刷 风琴折

正面



BLU Lifestyle **aria1** QUICK GUIDE

SAFETY INFORMATION

Chemical Warning
Do not use around fuels or chemicals.

Temperature Warning
Do not expose to extreme temperatures or conditions.

Water Hazard
Keep away from water or liquids.

Electrical Hazard
Keep away from magnetic or electrical fields to avoid short circuits.

Precautions and Additional Safety Information

- While charging, the speaker LED charging indicator will light up red. Once charged, LED charge indicator will turn off.
- Do not use a charger that exceeds 5V / 1000mA in order to prevent permanent battery and component damage.
- For better performance and longer battery life, it is recommended that you charge the battery fully before using for the first time. Please keep in mind that repeated charge cycles will cause battery performance to deteriorate over time.
- While charging, please keep out of the reach of children.
- Store in a cool and dry place away from direct sunlight.

ENG

BLUETOOTH PAIRING

Turn on Bluetooth from your handset or device and set to "Pair New Device". Click on the power button to power on the **aria1** speaker. Once powered on, the speaker indicator light will begin to flash, and the speaker will go into the Bluetooth pairing state. Click on "**BLU aria1**" from the available devices on your Bluetooth setting to pair. You are now ready to enjoy!

Note: If there is no operation while pairing, the speaker will shut down after 5 minutes.

TF CARD MODE

Turn on the speaker and insert the TF Card. Once inserted the speaker will recognize the TF Card and automatically switch to TF mode and will start playing the music saved on the TF.

Note: The speaker supports up to a 32GB TF card and can only play MP3 file extensions.

ENG

AUX MODE

Turn on the speaker and connect the auxiliary cable to the 3.5mm connector on the speaker. Connect the other end of the cable to either your handset, laptop, PC, or other device. Once connected the speaker will recognize the auxiliary connection and switch to Aux mode.

Note: While in Aux mode, the speaker cannot switch between songs. The playback controls are executed through the external device.

PLAYING MUSIC

- Press the "O" button to start playback. Press to pause.
- Press and Hold the "+" button to play the next song
- Press and Hold the "-" button to play the previous song
- Press the "+" button to increase the volume
- Press the "-" button to decrease the volume

While playing music, LED light will flash slowly. When paused, the LED light will stay on.

ENG

1. Play / Pause / Answer Call / End Call / Redial
2. Volume Up / Next Song
3. Volume Down / Previous Song
4. Change Modes (Bluetooth / TF / AUX)
5. TF Card Slot
6. Auxiliary Port (3.5mm)
7. Charging Port (Micro USB)
8. LED Indicator
9. Power Button

PHONE CALL MODE

When a phone call is coming in, press the Play Button to answer. Repress the Play button to hang up the phone call. During standby mode in Bluetooth, double click the Play Button to redial your last outgoing call.

ENG

15.19:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

15.21:

The user manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

15.105:

ENG

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ENG

RF Exposure statement:

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

ENG

反面



BLU Lifestyle **aria1** GUÍA RÁPIDA

INFORMACIÓN DE SEGURIDAD

Advertencia Química
No lo use cerca de combustibles o productos químicos.

Advertencia de Temperatura
No exponer a temperaturas o condiciones extremas.

Advertencia de Líquidos
Mantener alejado de agua o líquidos.

Advertencia de Electricidad
Mantener alejado de campos magnéticos o eléctricos para evitar cortos circuitos.

Precauciones e Información de Seguridad Adicional

- Mientras este cargando, el indicador de carga LED del parlante se iluminará en rojo. Una vez cargado, el indicador LED de carga se apagará.
- No utilice un cargador que exceda los 5V / 1000mA para evitar daño permanente de la batería y los componentes.
- Para un mejor rendimiento y una mayor duración de la batería, se recomienda cargar la batería por completo antes de usarla por primera vez. Tenga en cuenta que los ciclos de carga repetidos harán que el rendimiento de la batería se deteriore con el tiempo.
- Mientras este cargando, manténgalo fuera del alcance de los niños.
- Almacenar en un lugar fresco y seco y lejos del sol directo.

ESP

EMPAREJAMIENTO BLUETOOTH

Active Bluetooth desde su teléfono o dispositivo y configúrelo como "Emparejar dispositivo nuevo". Hacer clic en el botón de encendido para encender el parlante **aria1**. Una vez encendido, la luz indicadora del parlante comenzará a parpadear y el parlante pasará al estado de emparejamiento de Bluetooth. Hacer clic en "**BLU aria1**" de los dispositivos disponibles en su configuración de Bluetooth para emparejar. ¡Ahora estás listo para disfrutar!

Nota: Si no se realiza ninguna operación durante el emparejamiento, el parlante se apagará después de 5 minutos.

MODO TARJETA TF

Encienda el parlante e inserte la tarjeta TF. Una vez insertado, el parlante reconocerá la tarjeta TF y cambiará automáticamente al modo TF y comenzará a reproducir la música guardada en el TF.

Nota: El parlante admite una tarjeta TF de hasta 32 GB y solo puede reproducir extensiones de archivos MP3.

ESP

MODO AUXILIAR

Encienda el parlante y conecte el cable auxiliar al conector de 3.5 mm en el parlante. Conecte el otro extremo del cable a su teléfono, computadora portátil, PC u otro dispositivo. Una vez conectado, el parlante reconocerá la conexión auxiliar y cambiará al modo Aux.

Nota: Mientras está en modo Aux, el parlante no puede cambiar entre canciones. Los controles de reproducción se ejecutan a través del dispositivo externo.

REPRODUCIENDO MUSICA

- Presione el botón "O" para iniciar la reproducción. Presione para pausar.
- Mantenga presionado el botón "+" para reproducir la siguiente canción
- Mantenga presionado el botón "-" para reproducir la canción anterior
- Presione el botón "+" para subir el volumen
- Presione el botón "-" para bajar el volumen

Mientras música este reproduciendo, la luz LED parpadeará lentamente. Cuando está en pausa, la luz LED permanece encendida.

ESP

1. Reproducir / Pausar / Responder llamada / Terminar llamada / Remarcar
2. Subir volumen / siguiente canción
3. Bajar volumen / Canción anterior
4. Cambiar modos (Bluetooth / TF / AUX)
5. Ranura para tarjeta TF
6. Puerto auxiliar (3.5 mm)
7. Puerto de carga (Micro USB)
8. Indicador LED
9. Botón de encendido

MODO DE LLAMADAS TELEFÓNICAS

Cuando reciba una llamada telefónica, presione el botón de Reproducir para responder. Presione de nuevo el botón de Reproducir para colgar la llamada telefónica. En modo de espera mientras está en Bluetooth, hacer doble clic en el botón de Reproducir para volver a marcar su última llamada saliente.

ESP