




Band41-10MHz-QPSK-40620-1RB#0-Range1:0.009~0.15MHz




Band41-10MHz-QPSK-40620-1RB#0-Range2:0.15~30MHz




Band41-10MHz-QPSK-40620-1RB#0-Range3:30~1000MHz




Band41-10MHz-QPSK-40620-1RB#0-Range4:1000~3000MHz



Band41-10MHz-QPSK-40620-1RB#0-Range5:3000~26500MHz




Band41-10MHz-QPSK-41540-1RB#0-Range1:0.009~0.15MHz




Band41-10MHz-QPSK-41540-1RB#0-Range2:0.15~30MHz




Band41-10MHz-QPSK-41540-1RB#0-Range3:30~1000MHz




Band41-10MHz-QPSK-41540-1RB#0-Range4:1000~3000MHz




Band41-10MHz-QPSK-41540-1RB#0-Range5:3000~26500MHz




Band41-10MHz-16QAM-39700-1RB#0-Range1:0.009~0.15MHz




Band41-10MHz-16QAM-39700-1RB#0-Range2:0.15~30MHz




Band41-10MHz-16QAM-39700-1RB#0-Range3:30~1000MHz




Band41-10MHz-16QAM-39700-1RB#0-Range4:1000~3000MHz



Band41-10MHz-16QAM-39700-1RB#0-Range5:3000~26500MHz




Band41-10MHz-16QAM-40620-1RB#0-Range1:0.009~0.15MHz




Band41-10MHz-16QAM-40620-1RB#0-Range2:0.15~30MHz




Band41-10MHz-16QAM-40620-1RB#0-Range3:30~1000MHz




Band41-10MHz-16QAM-40620-1RB#0-Range4:1000~3000MHz




Band41-10MHz-16QAM-40620-1RB#0-Range5:3000~26500MHz




Band41-10MHz-16QAM-41540-1RB#0-Range1:0.009~0.15MHz



Band41-10MHz-16QAM-41540-1RB#0-Range2:0.15~30MHz




Band41-10MHz-16QAM-41540-1RB#0-Range3:30~1000MHz




Band41-10MHz-16QAM-41540-1RB#0-Range4:1000~3000MHz






Band41-10MHz-16QAM-41540-1RB#0-Range5:3000~26500MHz




Band41-15MHz-QPSK-39725-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-39725-1RB#0-Range2:0.15~30MHz




Band41-15MHz-QPSK-39725-1RB#0-Range3:30~1000MHz



Band41-15MHz-QPSK-39725-1RB#0-Range4:1000~3000MHz



Band41-15MHz-QPSK-39725-1RB#0-Range5:3000~26500MHz




Band41-15MHz-QPSK-40620-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-40620-1RB#0-Range2:0.15~30MHz




Band41-15MHz-QPSK-40620-1RB#0-Range3:30~1000MHz



Band41-15MHz-QPSK-40620-1RB#0-Range4:1000~3000MHz




Band41-15MHz-QPSK-40620-1RB#0-Range5:3000~26500MHz




Band41-15MHz-QPSK-41515-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-41515-1RB#0-Range2:0.15~30MHz




Band41-15MHz-QPSK-41515-1RB#0-Range3:30~1000MHz



Band41-15MHz-QPSK-41515-1RB#0-Range4:1000~3000MHz




Band41-15MHz-QPSK-41515-1RB#0-Range5:3000~26500MHz




Band41-15MHz-16QAM-39725-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-39725-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-39725-1RB#0-Range3:30~1000MHz




Band41-15MHz-16QAM-39725-1RB#0-Range4:1000~3000MHz



Band41-15MHz-16QAM-39725-1RB#0-Range5:3000~26500MHz



Band41-15MHz-16QAM-40620-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-40620-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-40620-1RB#0-Range3:30~1000MHz







Band41-15MHz-16QAM-40620-1RB#0-Range4:1000~3000MHz



Band41-15MHz-16QAM-40620-1RB#0-Range5:3000~26500MHz




Band41-15MHz-16QAM-41515-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-41515-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-41515-1RB#0-Range3:30~1000MHz




Band41-15MHz-16QAM-41515-1RB#0-Range4:1000~3000MHz



Band41-15MHz-16QAM-41515-1RB#0-Range5:3000~26500MHz




Band41-20MHz-QPSK-39750-1RB#0-Range1:0.009~0.15MHz




Band41-20MHz-QPSK-39750-1RB#0-Range2:0.15~30MHz



Band41-20MHz-QPSK-39750-1RB#0-Range3:30~1000MHz



Band41-20MHz-QPSK-39750-1RB#0-Range4:1000~3000MHz



Band41-20MHz-QPSK-39750-1RB#0-Range5:3000~26500MHz