



Band38-10MHz-QPSK-38000-50RB#0-PASS



Band38-10MHz-16QAM-38000-50RB#0-PASS



Band38-10MHz-QPSK-38200-1RB#0-PASS



Band38-10MHz-16QAM-38200-1RB#0-PASS