




Band66-5MHz-QPSK-131997-1RB#0-PASS **Band66-5MHz-16QAM-131997-1RB#0-PASS**




Band66-5MHz-QPSK-131997-25RB#0-PASS **Band66-5MHz-16QAM-131997-25RB#0-PASS**




Band66-5MHz-QPSK-132322-1RB#0-PASS **Band66-5MHz-16QAM-132322-1RB#0-PASS**



Band66-5MHz-QPSK-132322-25RB#0-PASS **Band66-5MHz-16QAM-132322-25RB#0-PASS**



Band66-5MHz-QPSK-132647-1RB#0-PASS **Band66-5MHz-16QAM-132647-1RB#0-PASS**



Band66-5MHz-QPSK-132647-25RB#0-PASS **Band66-5MHz-16QAM-132647-25RB#0-PASS**