



English

DCE041

BLUETOOTH® DeWALT TAG

Definitions: Safety Alert Symbols and Words

This instruction manual uses the following safety alert symbols and words to alert you to hazardous situations and your risk of personal injury or property damage.

- DANGER:** Indicates an imminently hazardous situation which, if not avoided, **will** result in **death or serious injury**.
- WARNING:** Indicates a potentially hazardous situation which, if not avoided, **could** result in **death or serious injury**.
- CAUTION:** Indicates a potentially hazardous situation which, if not avoided, **may** result in **minor or moderate injury**.
- (Used without word) Indicates a safety related message.
- NOTICE:** Indicates a practice **not related to personal injury** which, if not avoided, **may** result in **property damage**.
- WARNING! Read all safety warnings and all instructions.** Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.
- WARNING:** To reduce the risk of injury, read the instruction manual.

If you have any questions or comments about this or any DeWALT tool, call us toll free at: 1-800-4-DeWALT (1-800-433-9258).

GENERAL SAFETY WARNINGS

WARNING! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE

1. This device contains a factory-installed coin cell battery. It cannot be removed or replaced.
2. Chemical burn hazard. Keep out of reach of children.
3. Do not use in extreme hot or cold conditions. Keep between -30° F (-34° C) and 140° F (60° C).
4. Choking hazard. Keep out of reach of children.
5. This device contains a lithium button/coin cell battery. Do not force open the device as the battery can cause severe internal burns and lead to death in as little as 2 hours if swallowed or enters the body. If the device is damaged in any way, stop using the device and keep it away from children. If you think batteries may have been swallowed or entered the body, seek immediate medical attention.
6. If battery contents come into contact with the skin, immediately wash area with mild soap and water. If battery liquid gets into the eye, rinse water over the open eye for 15 minutes or until irritation ceases. If medical attention is needed, the battery electrolyte is composed of an organic solvent and lithium salts.
7. Do not incinerate or dismantle this device.
8. Under abusive conditions, liquid may be ejected from the device. Avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.
9. DO NOT dispose of device together with household waste material! Appliance that has reached the end of its life must be collected separately and returned to an environmentally compatible recycling facility.

The label on your tool may include the following symbols. The symbols and their definitions are as follows:

V.....volts	or AC.....alternating current
Hz.....hertz	or AC/DC.... alternating or direct current
min.....minutes Class II Construction (double insulated)
or DC.....direct current	n_0no load speed
.....Class I Construction (grounded)	nrated speed
.../min.....per minuteearthing terminal
BPM.....beats per minutesafety alert symbol
IPM.....impacts per minutevisible radiation
RPM.....revolutions per minutewear respiratory protection
s/ftm.....surface feet per minutewear eye protection
SPM.....strokes per minutewear hearing protection
A.....amperesread all documentation
W.....watts	

Storage Recommendations

The best storage place is one that is cool and dry, away from direct sunlight and excess heat or cold.

Wireless Certifications and Safety Information

- When traveling on airlines, be sure to comply with the airline restrictions on usage of personal electronic devices and Bluetooth®.
- The out of range alert feature has been designed to act as an aid to warn against products getting misplaced or stolen. It is not a security system.
- The connectivity range is up to 100 feet (30.5 meters) depending on environment and location.
- The shortwave radio frequency signals of a Bluetooth® device may impair the operation of other electronic and medical devices (such as pacemakers or hearing aids).
- This device is CAN ICES-3(B)/NMB-3(B) compliant.
- This device complies with Part 15 of the FCC rules and Industry Canada License-exempt RSS standard(s). Operation is subject to the following two conditions:
 - This device may not cause harmful interference, and
 - This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and adaptor.
- Connect the equipment into an outlet on a circuit different from that to which the adaptor is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated (e.i.r.p.) is not more than that necessary for successful communication.
- To comply with FCC and Industry Canada RF radiation exposure limits for general population, the antenna used for this device must not be co-located or operating in conjunction with any other antenna or transmitter.
- Changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate the device.

NOTE: The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth®, SIG, Inc. and any use of such marks by DeWALT is under license. Other trademarks and trade names are those of their respective owners.

INTENDED USE

This Bluetooth® DeWALT Tag is designed for tracking and locating professional power tools, equipment, and machines using the DeWALT Tool Connect™ app. Do not use DeWALT Tag to track or locate people or animals. **DO NOT** let children come into contact with it.

Fig. A



DeWALT Tool Connect™

This DeWALT Tag is capable of connecting with mobile devices that support Bluetooth® Smart (or Bluetooth® 4.0) technology. (To see if your mobile device is compatible, visit: <http://www.bluetooth.com/Pages/Bluetooth-Smart-Devices-List.aspx>)

DeWALT Tool Connect™ is an application for your smart device (such as a smart phone or tablet) that can connect and control your DeWALT Tag.

NOTE: The Tool Connect™ App is governed by separate terms and conditions available for viewing through the mobile application.

Pairing and Activating the DeWALT Tag (Fig. A)

Step 1: Download the DeWALT Tool Connect™ application at:



Step 2: Follow the instructions in the app to create your Tool Connect™ account.

Step 3: Connect your DeWALT Tag with the DeWALT Tool Connect™ app first by pressing the button on the front of the tag until it begins to blink. Then go to the Home screen of the app and select "+ Tool." The tag can only be connected to one Tool Connect™ account at a time.

Step 4: Once the connection is established, you will be prompted to give the product an individual name as well as confirm that you would like to register the product on your DeWALT.com account.

For more information on DeWALT Tool Connect™ functionality and features, please call 1-800-4-DeWALT (1-800-433-9258), visit www.DeWALT.com or view the FAQ page and help screens located inside the mobile application.

Installing the DeWALT Tag

- WARNING:** Do not apply tag to product where it will become wet or exposed to flammable liquids or gases.
- WARNING:** Do not secure in such a way as to impede the safe use of the product to which the tag is attached.
- WARNING:** Before using screws or rivets to install, ensure the space behind the placement is clear.
- WARNING:** Do not pierce tag with screw, nail, drill bit, etc.

The DeWALT tag is designed to track tools and equipment using the Tool Connect™ app. It will not prevent theft from happening. The tag can be installed in a variety of orientations. Consider installing the tag to prevent tampering.

The tag can be installed using the following attachment options:

- #6 Pan head self-tapping screw through one or both of the mounting holes .
- Glue or epoxy to back of tag. Be sure glue or epoxy is compatible with mounting surface.
- 5/32 diameter rivet through one or both of the mounting holes .
- Adhesive backing.
- Cable or zip tie through one or both of the mounting holes .

Technical Data

		DCE041
Voltage	V _{DC}	3
Battery life		3 Years
Signal Range		≤100'
FCC ID		YJ7-DCE041
IC		9082A-DCE041
Ingress Protection		IP67
Weight	kg	??

MAINTENANCE

Cleaning

WARNING: Never use solvents or other harsh chemicals for cleaning the tag. These chemicals may weaken the plastic materials used in these parts. Use a cloth dampened only with water and mild soap. Never let any liquid get inside the tag; never immerse into a liquid.

Repairs

The tag is not serviceable, though its button cell battery can be replaced at a DeWALT authorized service center.

WARNING: To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment (including brush inspection and replacement, when applicable) should be performed by a DeWALT factory service center or a DeWALT authorized service center. Always use identical replacement parts.

Register Online

Thank you for your purchase. Register your product now for:

- **WARRANTY SERVICE:** Registering your product will help you obtain more efficient warranty service in case there is a problem with your product.
- **CONFIRMATION OF OWNERSHIP:** In case of an insurance loss, such as fire, flood or theft, your registration of ownership will serve as your proof of purchase.
- **FOR YOUR SAFETY:** Registering your product will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act.

Register online at www.dewalt.com/register.

Three Year Limited Warranty

DeWALT will repair, without charge, any defects due to faulty materials or workmanship for three years from the date of purchase. This warranty does not cover part failure due to normal wear or tool abuse. For further detail of warranty coverage and warranty repair information, visit www.dewalt.com or call 1-800-4-DeWALT (1-800-433-9258). This warranty does not apply to accessories or damage caused where repairs have been made or attempted by others. **THIS LIMITED WARRANTY IS GIVEN IN LIEU OF ALL OTHERS, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND EXCLUDES ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so these limitations may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary in certain states or provinces.

In addition to the warranty, DeWALT tools are covered by our:

1 YEAR FREE SERVICE

DeWALT will maintain the tool and replace worn parts caused by normal use, for free, any time during the first year after purchase.

90 DAY MONEY BACK GUARANTEE

If you are not completely satisfied with the performance of your DeWALT Power Tool, Laser, or Nailer for any reason, you can return it within 90 days from the date of purchase with a receipt for a full refund – no questions asked.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, see country specific warranty information contained in the packaging, call the local company or see website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call 1-800-4-DeWALT (1-800-433-9258) for a free replacement.