

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ THIS SECTION CAREFULLY.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the device.”

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/tv technician for help.

CUSTOMER ASSISTANCE

PHONE: 888.551.1115

EMAIL: INFO@FIRSTACT.COM

USED WITH PERMISSION. MANUFACTURED BY: FIRST ACT, LLC, SUNRISE, FL 33326, USA

DISTRIBUTED BY: JAZWARES, LLC, SUNRISE, FL 33326, USA

JAZWARES, 16A CRANE GROVE, LONDON, N7 8LE, UNITED KINGDOM

JAZWARES.GMBH, MINA-REES-STR. 8, 64295 DARMSTADT, GERMANY

WWW.JAZWARES.COM / WWW.JAZWARES.DE

First Act, The First Act Logo and First Act Musician are trademarks of First Act, LLC.

No part of this publication may be reproduced in any form or by any means without the prior written permission of First Act Inc. © 2020 First Act, LLC. All Rights Reserved.



Deluxe Microphone

AGES
12+

INSTRUCTION MANUAL

PLEASE SAVE THIS INSTRUCTION SHEET. IT CONTAINS VALUABLE PRODUCT INFORMATION.

Congratulations on your new Deluxe Microphone! Please read this guide carefully before you begin playing.

• Includes:

- Microphone x 1.
- USB cable x 1.



BEFORE YOU PLAY

CHARGING

Please make sure that the microphone is fully charged before first use.

- Connect the product with USB cable to any compatible plug or device.
- The indicator will show red when charging.
- The indicator will turn off when fully charged.



BLUETOOTH PAIRING

The Deluxe Microphone can play music from any Bluetooth enabled device including smartphones, tablet PCs, computers and more. The speaker supports Bluetooth devices.

1. Open the Bluetooth setting on your mobile phone, tablet, or computer and search for available Bluetooth devices.
2. Find the Bluetooth device named "AGT" and select it.

EXISTING DEVICES


1. If the speaker has connected to Bluetooth devices previously it will automatically connect to the last paired device when switched on.
2. If no Bluetooth device is available the speaker will enter pairing mode.
Connect to another device by following the same process as connecting a new Bluetooth device.
3. No other Bluetooth device can be paired via Bluetooth at the same time as the Deluxe Microphone .
4. Only one Bluetooth device can be connected to the speaker at a time. To end the Bluetooth connection turn off the Deluxe Microphone speaker or disable Bluetooth on your device.

GAME INSTRUCTIONS

Connect microphone using Bluetooth to a compatible speaker.

- Divide into 2 teams (2 Players or more per team) One team will have the microphone, the other team must be in a separate room with speaker.
- Team members take turns singing using voice change feature while other team guesses who the singer is.

BUTTONS OPERATIONS



- ① Press **On/Off button** to activate the microphone and LED lights.
Press **On/Off button** once to change voice modes.
- ② +The **Trebel** effect increase.
- The **Trebel** effect decrease.
- ③ +The **Bass** effect increase.
- The **Bass** effect decrease.
- ④ +The **Microphone Volume** increase.
- The **Microphone Volume** decrease.
- ⑤ +The **Echo** effect increase.
- The **Echo** effect decrease.
- ⑥ +The **Speaker Volume** increase.
- The **Speaker Volume** decrease.
- ⑦ Press **Mode** to turn Bluetooth off.
- ⑧ Press **Light** button to change light effects.
- ⑨ Press **Previous** button to play previous song.
- ⑩ Press **Next** button to play next song.
- ⑪ Press **Play/Pause** button to play or pause song.