


INTERNAL PHOTOGRAPHS

This document contains 4 photographs

Photograph No.1
ES700EP panic button internal view



Photograph No.2
ES700EP panic button PCB front view



Photograph No.3
PCB second side view



Photograph No.4
ES700EP panic button antenna

