




IEEE 802.11a\_Channel 100\_20MHz\_Antenna 0




IEEE 802.11a\_Channel 100\_20MHz\_Antenna 1




IEEE 802.11a\_Channel 100\_20MHz\_Antenna 2



IEEE 802.11a\_Channel 116\_20MHz\_Antenna 0



IEEE 802.11a\_Channel 116\_20MHz\_Antenna 1



IEEE 802.11a\_Channel 116\_20MHz\_Antenna 2

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-EN300328-V1.2



**Shenzhen UnionTrust Quality and Technology Co., Ltd.**

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 36\_20MHz\_Antenna 1




IEEE 802.11n\_Channel 36\_20MHz\_Antenna 2




IEEE 802.11n\_Channel 44\_20MHz\_Antenna 0



IEEE 802.11n\_Channel 44\_20MHz\_Antenna 1



IEEE 802.11n\_Channel 44\_20MHz\_Antenna 2



IEEE 802.11n\_Channel 48\_20MHz\_Antenna 0

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 48\_20MHz\_Antenna 1




IEEE 802.11n\_Channel 48\_20MHz\_Antenna 2




IEEE 802.11n\_Channel 52\_20MHz\_Antenna 0



IEEE 802.11n\_Channel 52\_20MHz\_Antenna 1



IEEE 802.11n\_Channel 52\_20MHz\_Antenna 2



IEEE 802.11n\_Channel 60\_20MHz\_Antenna 0

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 60\_20MHz\_Antenna 1




IEEE 802.11n\_Channel 60\_20MHz\_Antenna 2




IEEE 802.11n\_Channel 64\_20MHz\_Antenna 0



IEEE 802.11n\_Channel 64\_20MHz\_Antenna 1



IEEE 802.11n\_Channel 64\_20MHz\_Antenna 2



IEEE 802.11n\_Channel 100\_20MHz\_Antenna 0

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 100\_20MHz\_Antenna 1




IEEE 802.11n\_Channel 100\_20MHz\_Antenna 2




IEEE 802.11n\_Channel 116\_20MHz\_Antenna 0




IEEE 802.11n\_Channel 116\_20MHz\_Antenna 1




IEEE 802.11n\_Channel 116\_20MHz\_Antenna 2








IEEE 802.11n\_Channel 140\_20MHz\_Antenna 0



IEEE 802.11n\_Channel 140\_20MHz\_Antenna 1



IEEE 802.11n\_Channel 140\_20MHz\_Antenna 2



IEEE 802.11n\_Channel 38\_40MHz\_Antenna 0



IEEE 802.11n\_Channel 38\_40MHz\_Antenna 1

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 38\_40MHz\_Antenna 2




IEEE 802.11n\_Channel 46\_40MHz\_Antenna 0




IEEE 802.11n\_Channel 46\_40MHz\_Antenna 1



IEEE 802.11n\_Channel 46\_40MHz\_Antenna 2



IEEE 802.11n\_Channel 54\_40MHz\_Antenna 0



IEEE 802.11n\_Channel 54\_40MHz\_Antenna 1

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China

Tel: +86-755-28230888


Fax: +86-755-28230886

E-mail: info@uttlab.com


<http://www.uttlab.com>

UTTR-RF-EN300328-V1.2







IEEE 802.11n\_Channel 54\_40MHz\_Antenna 2




IEEE 802.11n\_Channel 62\_40MHz\_Antenna 0




IEEE 802.11n\_Channel 62\_40MHz\_Antenna 1



IEEE 802.11n\_Channel 62\_40MHz\_Antenna 2



IEEE 802.11n\_Channel 102\_40MHz\_Antenna 0



IEEE 802.11n\_Channel 102\_40MHz\_Antenna 1

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11n\_Channel 102\_40MHz\_Antenna 2





IEEE 802.11n\_Channel 110\_40MHz\_Antenna 0




IEEE 802.11n\_Channel 110\_40MHz\_Antenna 1




IEEE 802.11n\_Channel 110\_40MHz\_Antenna 2





IEEE 802.11n\_Channel 134\_40MHz\_Antenna 0




IEEE 802.11n\_Channel 134\_40MHz\_Antenna 1




IEEE 802.11n\_Channel 134\_40MHz\_Antenna 2




IEEE 802.11ac\_Channel 36\_20MHz\_Antenna 0




IEEE 802.11ac\_Channel 36\_20MHz\_Antenna 1




IEEE 802.11ac\_Channel 36\_20MHz\_Antenna 2




IEEE 802.11ac\_Channel 44\_20MHz\_Antenna 0




IEEE 802.11ac\_Channel 44\_20MHz\_Antenna 1




IEEE 802.11ac\_Channel 44\_20MHz\_Antenna 2



IEEE 802.11ac\_Channel 48\_20MHz\_Antenna 0



IEEE 802.11ac\_Channel 48\_20MHz\_Antenna 1



IEEE 802.11ac\_Channel 48\_20MHz\_Antenna 2

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11ac\_Channel 52\_20MHz\_Antenna 0




IEEE 802.11ac\_Channel 52\_20MHz\_Antenna 1




IEEE 802.11ac\_Channel 52\_20MHz\_Antenna 2




IEEE 802.11ac\_Channel 60\_20MHz\_Antenna 0




IEEE 802.11ac\_Channel 60\_20MHz\_Antenna 1




IEEE 802.11ac\_Channel 60\_20MHz\_Antenna 2




IEEE 802.11ac\_Channel 64\_20MHz\_Antenna 0




IEEE 802.11ac\_Channel 64\_20MHz\_Antenna 1




IEEE 802.11ac\_Channel 64\_20MHz\_Antenna 2



IEEE 802.11ac\_Channel 100\_20MHz\_Antenna 0



IEEE 802.11ac\_Channel 100\_20MHz\_Antenna 1



IEEE 802.11ac\_Channel 100\_20MHz\_Antenna 2

## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-EN300328-V1.2



## Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China

Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-EN300328-V1.2