




IEEE 802.11a Channel 60 20MHz Antenna 0




IEEE 802.11a Channel 64 20MHz Antenna 0




IEEE 802.11a Channel 100 20MHz Antenna 0




IEEE 802.11a Channel 116 20MHz Antenna 0




IEEE 802.11a Channel 140 20MHz Antenna 0




IEEE 802.11a Channel 144 20MHz Antenna 0




IEEE 802.11n Channel 36 20MHz Antenna 0




IEEE 802.11n Channel 44 20MHz Antenna 0




IEEE 802.11n Channel 48 20MHz Antenna 0



IEEE 802.11n Channel 52 20MHz Antenna 0



IEEE 802.11n Channel 60 20MHz Antenna 0



IEEE 802.11n Channel 64 20MHz Antenna 0

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-RSS247-V1.1




IEEE 802.11n Channel 100_20MHz_Antenna 0




IEEE 802.11n Channel 116_20MHz_Antenna 0




IEEE 802.11n Channel 140_20MHz_Antenna 0




IEEE 802.11n Channel 144_20MHz_Antenna 0




IEEE 802.11n Channel 38_40MHz_Antenna 0




IEEE 802.11n Channel 46_40MHz_Antenna 0




IEEE 802.11n Channel 54 40MHz Antenna 0




IEEE 802.11n Channel 62 40MHz Antenna 0




IEEE 802.11n Channel 102 40MHz Antenna 0




IEEE 802.11n Channel 110 40MHz Antenna 0




IEEE 802.11n Channel 134 40MHz Antenna 0




IEEE 802.11n Channel 142 40MHz Antenna 0




IEEE 802.11ac Channel 36_20MHz_Antenna 0




IEEE 802.11ac Channel 44_20MHz_Antenna 0




IEEE 802.11ac Channel 48_20MHz_Antenna 0




IEEE 802.11ac Channel 52_20MHz_Antenna 0




IEEE 802.11ac Channel 60_20MHz_Antenna 0




IEEE 802.11ac Channel 64_20MHz_Antenna 0




IEEE 802.11ac Channel 100 20MHz Antenna 0




IEEE 802.11ac Channel 116 20MHz Antenna 0




IEEE 802.11ac Channel 140 20MHz Antenna 0




IEEE 802.11ac Channel 144 20MHz Antenna 0




IEEE 802.11ac Channel 38 40MHz Antenna 0




IEEE 802.11ac Channel 46 40MHz Antenna 0




IEEE 802.11ac Channel 54 40MHz Antenna 0




IEEE 802.11ac Channel 62 40MHz Antenna 0




IEEE 802.11ac Channel 102 40MHz Antenna 0




IEEE 802.11ac Channel 110 40MHz Antenna 0




IEEE 802.11ac Channel 134 40MHz Antenna 0




IEEE 802.11ac Channel 142 40MHz Antenna 0




IEEE 802.11ax_Channel 36_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 44_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 48_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 52_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 60_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 64_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 100_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 116_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 140_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 144_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 38_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 46_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 54_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 62_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 102_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 110_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 134_40MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 142_40MHz_Antenna 0_RU&Index SU




IEEE 802.11a Channel 144_20MHz_Antenna 0




IEEE 802.11n Channel 144_20MHz_Antenna 0




IEEE 802.11n Channel 142_40MHz_Antenna 0




IEEE 802.11ac Channel 144_20MHz_Antenna 0



IEEE 802.11ac_Channel 142_40MHz_Antenna 0



IEEE 802.11ax_Channel 144_20MHz_Antenna 0_RU&Index SU



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China

Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-RSS247-V1.1