




IEEE 802.11ac_Channel 52_20MHz_Antenna 2




IEEE 802.11ac_Channel 52_20MHz_Antenna 3




IEEE 802.11ac_Channel 60_20MHz_Antenna 0




IEEE 802.11ac_Channel 60_20MHz_Antenna 1




IEEE 802.11ac_Channel 60_20MHz_Antenna 2




IEEE 802.11ac_Channel 60_20MHz_Antenna 3




IEEE 802.11ac_Channel 64_20MHz_Antenna 0




IEEE 802.11ac_Channel 64_20MHz_Antenna 1




IEEE 802.11ac_Channel 64_20MHz_Antenna 2



IEEE 802.11ac_Channel 64_20MHz_Antenna 3



IEEE 802.11ac_Channel 100_20MHz_Antenna 0



IEEE 802.11ac_Channel 100_20MHz_Antenna 1

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11ac_Channel 100_20MHz_Antenna 2




IEEE 802.11ac_Channel 100_20MHz_Antenna 3




IEEE 802.11ac_Channel 116_20MHz_Antenna 0



IEEE 802.11ac_Channel 116_20MHz_Antenna 1



IEEE 802.11ac_Channel 116_20MHz_Antenna 2



IEEE 802.11ac_Channel 116_20MHz_Antenna 3

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11ac_Channel 140_20MHz_Antenna 0




IEEE 802.11ac_Channel 140_20MHz_Antenna 1




IEEE 802.11ac_Channel 140_20MHz_Antenna 2




IEEE 802.11ac_Channel 140_20MHz_Antenna 3




IEEE 802.11ac_Channel 38_40MHz_Antenna 0




IEEE 802.11ac_Channel 38_40MHz_Antenna 1




IEEE 802.11ac_Channel 38_40MHz_Antenna 2




IEEE 802.11ac_Channel 38_40MHz_Antenna 3




IEEE 802.11ac_Channel 46_40MHz_Antenna 0



IEEE 802.11ac_Channel 46_40MHz_Antenna 1



IEEE 802.11ac_Channel 46_40MHz_Antenna 2



IEEE 802.11ac_Channel 46_40MHz_Antenna 3

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11ac_Channel 54_40MHz_Antenna 0




IEEE 802.11ac_Channel 54_40MHz_Antenna 1




IEEE 802.11ac_Channel 54_40MHz_Antenna 2



IEEE 802.11ac_Channel 54_40MHz_Antenna 3



IEEE 802.11ac_Channel 62_40MHz_Antenna 0



IEEE 802.11ac_Channel 62_40MHz_Antenna 1

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-EN300328-V1.2




IEEE 802.11ac_Channel 62_40MHz_Antenna 2




IEEE 802.11ac_Channel 62_40MHz_Antenna 3




IEEE 802.11ac_Channel 102_40MHz_Antenna 0




IEEE 802.11ac_Channel 102_40MHz_Antenna 1




IEEE 802.11ac_Channel 102_40MHz_Antenna 2




IEEE 802.11ac_Channel 102_40MHz_Antenna 3




IEEE 802.11ac_Channel 110_40MHz_Antenna 0




IEEE 802.11ac_Channel 110_40MHz_Antenna 1




IEEE 802.11ac_Channel 110_40MHz_Antenna 2




IEEE 802.11ac_Channel 110_40MHz_Antenna 3




IEEE 802.11ac_Channel 134_40MHz_Antenna 0




IEEE 802.11ac_Channel 134_40MHz_Antenna 1




IEEE 802.11ac_Channel 134_40MHz_Antenna 2




IEEE 802.11ac_Channel 134_40MHz_Antenna 3




IEEE 802.11ac_Channel 42_80MHz_Antenna 0




IEEE 802.11ac_Channel 42_80MHz_Antenna 1




IEEE 802.11ac_Channel 42_80MHz_Antenna 2




IEEE 802.11ac_Channel 42_80MHz_Antenna 3




IEEE 802.11ac_Channel 58_80MHz_Antenna 0




IEEE 802.11ac_Channel 58_80MHz_Antenna 1




IEEE 802.11ac_Channel 58_80MHz_Antenna 2




IEEE 802.11ac_Channel 58_80MHz_Antenna 3




IEEE 802.11ac_Channel 106_80MHz_Antenna 0




IEEE 802.11ac_Channel 106_80MHz_Antenna 1




IEEE 802.11ac_Channel 106_80MHz_Antenna 2




IEEE 802.11ac_Channel 106_80MHz_Antenna 3




IEEE 802.11ac_Channel 50_160MHz_Antenna 0




IEEE 802.11ac_Channel 50_160MHz_Antenna 1




IEEE 802.11ac_Channel 50_160MHz_Antenna 2




IEEE 802.11ac_Channel 50_160MHz_Antenna 3




IEEE 802.11ac_Channel 114_160MHz_Antenna 0




IEEE 802.11ac_Channel 114_160MHz_Antenna 1




IEEE 802.11ac_Channel 114_160MHz_Antenna 2




IEEE 802.11ac_Channel 114_160MHz_Antenna 3




IEEE 802.11ax_Channel 36_20MHz_Antenna 0_RU&Index SU




IEEE 802.11ax_Channel 36_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 36_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 36_20MHz_Antenna 3_RU&Index SU




IEEE 802.11ax_Channel 44_20MHz_Antenna 0_RU&Index SU



IEEE 802.11ax_Channel 44_20MHz_Antenna 1_RU&Index SU



IEEE 802.11ax_Channel 44_20MHz_Antenna 2_RU&Index SU



IEEE 802.11ax_Channel 44_20MHz_Antenna 3_RU&Index SU