

User Manual for FM-04 FM transmitter

- 1: Transmit frequency wirelessly to MP3 in car.
- 2: with LCD screen display; with time display; real-time temperature display; the battery power display function.
- 3: 211 frequency (88.1-107.9MHz), effective range up to 5 meters
- 4: 1 function key "SET"; 3 frequency memory keys M1, M2, M3 (can store frequency when the battery off).
- 5: Power supply : AAA rechargeable battery, car charger, USB power supply plug.
- 6: Digital transmission chip, even if under the terrible environment of rapid change temperature, radio wave transmission will not be affected at all. The multi-frequency design can choose different frequency .
- 7: High fidelity, low stress, stereo sound, CD sound.
- 8: Applicable to MP3, MP4, PDA, Notebook, PC, CD, MD, DVD and other audio playback device.
- 9: Long working hours, 2 AAA battery (700mA/H) can be used continuously for more than 23 hours!
- 10: Low operating voltage, the voltage of the battery low to 2.7V still can work !

Use Method

★Install 2 AAA batteries or use an external power supply, battery cannot be used at the same time with external power supply

★plug 3.5 Jack of FM transmitter into the audio device (such as MP3), adjust the volume appropriate.

★Tune the radio frequency and volume (avoid the frequency to be occupied by the local station).

★Press the power switch, adjust the frequency of the FM transmitter same as the radio frequency. When the signal is occupied by the radio station, adjust another frequency of FM transmitter and radio.

★ ON/OFF switch: long press "ON/OFF" key to tune on or off. Short press "ON/OFF" to tune to transmitting mode or time mode

★Frequency selection: short press "UP" or "DOWN" key to select frequency (88.1 - 107.9MHz); long press "UP" or "DOWN" key to select frequency quickly.

★ Frequency storage: press "UP" or "DOWN" key to select the frequency, long press "M1" or "M2" or "M3" key to memory; press "M1" or "M2" or "M3" key to find out the storage frequency..

★Time setting: in the time mode, long press "SET" key to enter the hour set state, short press "SET" button, enter the minutes setting state, press "UP" or "DOWN" button to adjust the hour or minute; short press "SET" key to finish setup.

FCC Notice: this device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.