

## Cautions

- Wireless connections are affected by obstructions such as walls, human body and other devices.
- Keep P604 Wireless dry, moisture may damage electronic components.
- Exposure to high temperature will shorten the life and damage electronic components.
- Opening / altering the P604 Wireless voids all product warranty.
- Rough handling may damage inside electronic components.
- Listening to music at high volume for long periods can lead to hearing problems. We do not recommend using these headphones at maximum volume, particularly for long periods of time.
- Excessive sound pressure from earphones and headphones can cause hearing loss.
- The storage temperature range is -20 - 60°C and operating temperature range is -10 - 50°C

## Specifications

Wearing Style	Supra-aural, On-ear
Bluetooth Version	V 4.0 Class 2
Frequency Response	20 Hz – 20 kHz
Driver Size	40 mm
Impedance	32 Ω
Microphone Sensitivity	- 42 dB +/- 3 dB
Battery	Rechargeable 850mAh Lithium-ion battery
Playback Time	30 hours
Weight	142 g

## Warranty

This ARCTIC product includes a two-year limited warranty.

For please visit <http://warranty.arctic.ac>

The USB port is for charge use only.

The equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



## FCC ID Z3AP604BT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## CE0700

### Regulatory Conformance

Hereby, ARCTIC declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For the declaration of conformity, visit the Web site <http://p604wireless.arctic.ac#support>

Notice: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU)



### Directive 2002/96/EC about Waste of Electrical and Electronic Equipment (WEEE)

Waste of Electrical and Electronic Equipment must not be disposed of with domestic waste.

If the device cannot be used anymore, the user is legally obliged to separate it from domestic waste and hand it over to a designated collection point of his community/district.

Thereby it is guaranteed that the Waste of Electrical and Electronic Equipment is recycled properly and negative impacts for the environment are avoided.

Therefore, electronic devices are marked by this sign.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by ARCTIC (HK) Ltd. is under license. Other trademarks and trade names are those of their respective owners.

ARCTIC and the ARCTIC logo are registered trademarks of Boost Up International Limited.

### © 2015 ARCTIC (HK) Ltd. All rights reserved.

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC (HK) Ltd. In no event shall ARCTIC, its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.

PKMNL0005B



# P604 Wireless

## Welcome Guide



[support.arctic.ac/p604wireless](http://support.arctic.ac/p604wireless)

Dear Customer,

Thank you for choosing the ARCTIC P604 Wireless.

YOU are the centre of ARCTIC. We work hard to approach all angles from a user's perspective and are fully dedicated to create innovative, user-friendly and affordable devices. YOUR satisfaction is our ultimate goal. In order to assist you even better, we launched a support platform for Smartphones ([support.arctic.ac](http://support.arctic.ac)).

I hope you enjoy the P604 Wireless as much as I do and we at ARCTIC look forward to further enriching your life with our products. If you would like to share how you use ARCTIC's products please do so at <https://www.facebook.com/ARCTIC.en>

ARCTIC is a fully carbon neutral company and your support helps us to compensate every kilogram of CO<sub>2</sub> we produce. Thank You.

Sincerely,


Magnus Huber  
ARCTIC CEO

## Packaging Contents

P604 Wireless  
x 1



Micro USB Cable x 1




Travel Pouch x 1



Welcome Guide x 1




## Music Stutters



## Function Diagram

- ① Switch On / Off multifunction button
- ② LED indicator
- ③ Micro-USB charging
- ④ Microphone
- ⑤ Previous track
- ⑥ Next track




## Switch the Headset On or Off

### Switch on

Press the multifunction button for 3 seconds until the blue LED lights up

### Switch off


Press the multifunction button for 3 seconds until the red LED lights up



## Getting Connected


The P604 Wireless allows you to pair with your mobile device in 2 different ways:

### A. Bluetooth Pairing

1. Switch on the P604 Wireless by Press the Multifunction Button  for 3 seconds.
2. The P604 Wireless automatically enters pairing mode shown by the red and blue LED flash alternately.
3. Turn on Bluetooth on your phone and pair it with the headphone.


### Example: iOS

Press Settings > Bluetooth and switch Bluetooth on > P604 Wireless > Pair



### Example: Android 4.0

Press Menu > Settings > Switch on Bluetooth > Bluetooth > Search for devices > P604 Wireless > Pair




### Notes:


- Pairing mode will last up to ten minutes or until a device is found, two tones will sound to let you know when pairing has stopped.
- If you exceed the effective range of approx. 10M (33ft) the headphone will disconnect and will automatically reconnect if the speaker re-enters the effective range within ten minutes.

## How to wear the headset







## B. NFC One Touch Pairing (only for NFC enabled phones)

1. Switch on the P604 Wireless by Press the Multifunction Button  for 3 seconds.
2. Enable NFC on your mobile device.
3. Slide your phone very slowly from top to bottom across the shown area of the right side of the headphone until you hear a beep and a confirmation message comes up on your mobile device.
4. Play music!



## Phone Operations

If the mobile device that is paired (via Bluetooth) with the P604 Wireless headphone is a cellular phone you can:

<b>Answer Call</b>	Press the  once.
<b>End Call</b>	Press the  once.
<b>Refuse Call</b>	Press and hold  for 2 seconds.
<b>Switch Call</b>	Press and hold  for 2 seconds while in a call.

## LED Indicators

Status	Indication
Charging	Red LED on
Battery Full	Blue LED on
On and Paired	Blue LED flashes
Pairing Mode	Red and Blue LED will flash alternately
Low Battery	Red LED flashes


## Reconnection

1. Turn on Bluetooth on phone.
2. Switch on the P604 Wireless by pressing the multifunction button for 3 seconds.
3. If your device was the latest one to be paired with the P604 Wireless it will connect automatically otherwise please repeat pairing section.

## Charging the headset

The P604 Wireless can be charged while switched on or off.

1. Insert the micro USB cable into the P604 Wireless and the USB side into a power source.
2. When the Blue light on constantly the P604 Wireless is fully charged.



It is recommended to fully charge before initial use for better battery life.

USB Chargers are available at [chargers.arctic.ac](http://chargers.arctic.ac)