
WIFI siren alarm instructions

Product Configuration



Specification

Reset

- (1) Press the reset button for 6 seconds till the indicator flash rapidly. Then device turns to smart wifi mode.
- (2) Press the reset button again for 6 seconds till the indicator flash slowly. The device t urns to AP mode.

Battery:CR123A-3V X 2

USB Power adapter:5V/1A

Max current:>60mA

sound intensity:90db/1M

Wireless type:2.4GHz

Wireless standard: IEEE 802.11b/g/n

Wireless range:45M

Working temperature:0 $^{\circ}$ C \sim 40 $^{\circ}$ C (32 $^{\circ}$ F \sim 104 $^{\circ}$ F)

Working humidity:20% $\,\sim\,$ 85%


Storage temperature:0 $^{\circ}\text{C}~\sim~60\,^{\circ}\text{C}$ (32 $^{\circ}~\text{F}~\sim$ 140 $^{\circ}~\text{F})$

Storage humidity:0% \sim 90%

Product size: 68 mm x68 mm x33mm

Certificate:RoHS, FCC, CE,





- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

1. APP download

- 1) Android phone:Download"Smart life" from Google play store;IOS device:Download"Smart life" from APP store.
- 2) Scan QR code bellow to install.



3) Register and login.



Adding device


The default is Smart Wifi mode as the device is power-up(the indicator light flashes quickly); If the indicator light shows and exception, pls press the reset button for 6s, forced reset into smart wifi mode; Press reset button again for 6s to change AP mode.(the indicator light flash slowly)

The configuration mode will last for 2 minutes, after 2 minutes, the light goes off and the device goes into sleep mode. The user needs to long press reset button to wake up the device before adding it again.

Note:Pressing resetting button for 2-3s during network configuration, LED will be 0FF then device will be in sleeping model.


1. Select the item that you want to add, add the device via Smart Wifi or AP mode.

Note: The device currently supports 2.4G wifi signals.



(1) Smart WiFi mode (follow the steps of app)

(Pressing the resetting button for 6s, the LED will rapidly blink.)



a. In AP mode, press and hold the reset button for 6s after entering the smart WiFi mode. The indicator light will blink slowly.




Main function

1. Setting Alarm duration and alarm sound type




2. Scheduled alarm (Scheduled alarm will have around 30s deviation)



3. Scenes setting (Sound type setting and duration setting must be set)

Note: When you set the linkage, please set the alarm time and sound first.




4. Device Sharing: Allow others to control the device by sharing device.

Note: you can delete the sharing in profile setting.




Other functions:

1. Push notification: Enable to turn off .



2. Reset again:(take out the battery and then install it,wait for about 10-20 seconds to add device again,if device reset failed)



3. indicator

Device Status	Indicator Status
Smart WiFi	Indicator flashes quickly
AP mode	Indicator flashes slowly
Triggered	The indicator will rapidly blink, and OFF after scheduled time
Reset	Indicator lights up for 4s and after 2 seconds lights off, device goes into configuration mode