


6. Place or Mount Your Camera

To mount your camera to the wall: Fasten the mounting screw into the wall, and then mou the camera from the screw.

You can place your camera on a shelf or other flat surface, or you can mount it to the wall.



You' re done! Congratulations! Your camera is set up and ready to go.



Appendix: Camera LED Guide

NO.	LED Status	Camera Status
1	Red LED on	System starting up
2	Red LED blinks quickly	Standby for configuration
3	Green LED blinks quickly	Network pairing
4	Green LED on	Camera online
5	Red and Green LED blinks alternately	OTAupgrade



All trademarks are used for reference purposes only. Thanks again for choosing our smart camera! Make life safe in your hands! Boost security mobility in your smartphone!

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequence energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

- Connect the equipment into an autlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body