

# Installation Instruction

---

The Small Remote Unit (SRU), Fiber Hub Unit (FHU) and Master Unit (MU) has to be installed by a professionally trained installer.