
























尺寸：67*80mm

80g书写纸

正反面，

风琴折，单黑印刷

<div><h1>Aero</h1><h2>Auracast™ headset</h2><p>User Manual</p></div>	<div><h3>What's in the box?</h3><div><p>Charging case</p></div><div><p>Aero Auracast headset</p></div><div><p>Type-C charging cable</p></div><div><p>Earbuds</p></div><div><p>User manual</p></div></div>	<div><h3>Overview</h3><div><p>Left</p></div><div><p>Right</p></div><div><p>Microphone LED indicator Touch area</p></div><div><p>Charging contact Microphone</p></div><div><p>Type-C charging port</p></div><div><p>LED indicator</p></div></div>	<div><h3>Power On</h3><ul style="list-style-type: none">• Open the charging case, the earbuds will automatically power ON.• To manually power ON, press and hold the touchpad on earbud for 2 seconds.<p>2s</p></div> <div><h3>Power Off</h3><ul style="list-style-type: none">• Match the corresponding L & R letters on the charging, the earbuds will auto power OFF and start charging.• To manually power OFF, press and hold the touchpad on earbud for 8 seconds.<p>8s</p></div>	<div><h3>Connection</h3><div><p>Bluetooth connecting</p><ul style="list-style-type: none">• Power on the earbuds, they will automatically enter Bluetooth pairing mode.• Select "Aero" on your device's Bluetooth list to connect.</div><div><p>Bluetooth / Auracast (Broadcast)</p><ul style="list-style-type: none">• 4x tap the right / left earbud to switch mode.• 3x tap broadcast scanning (in broadcast mode)</div><div><p>AURACAST A BLUETOOTH TECHNOLOGY</p></div></div>	<div><h3>Charging</h3><div><p>Charging Pins</p><p>Charge the earbuds</p><ul style="list-style-type: none">• Place the earbuds in and close the charging case to charge the earbuds.</div><div><p>LED indicator</p><p>Charge the case</p><ul style="list-style-type: none">• Plug the charging cable into the TYPE-C interface to charge.<div><p>Led orange - Charging 0 - 20%</p><p>Led white - Charging 20 - 99%</p><p>Led turn solid white when fully charged.</p></div></div></div>	<div><h3>Operation</h3><h4>Volume UP & DOWN</h4><ul style="list-style-type: none">• Up - Single tap the right earbud to increase volume.• Down - Single tap the left earbud to decrease volume.<h4>Voice Enhancement</h4><ul style="list-style-type: none">• On/Off - Tap & hold 2+ sec the right earbud.<h4>Ambient Mode / Sound Mode</h4><ul style="list-style-type: none">• Tap & hold 2+ sec the left earbud to switch mode.<h4>Bluetooth Mode (connected with phone)</h4><ul style="list-style-type: none">• Answer ☎ - Double tap the right / left earbud• Hangup ☎ - Double tap the right / left earbud• Reject incoming calls ☎ - Tap & hold 2+ sec the right / left earbud• Play / Pause ▶◀ - Double tap• Previous ◀◀ - 3x tap the left earbud• Next ▶▶ - 3x tap the right earbud</div>	<div><h3>Specification</h3><h4>Bluetooth</h4><ul style="list-style-type: none">• Version : v5.3 (Classical Bluetooth + Auracast)• Solution : Airoha AB1565• Range : ≥ 20 meters<h4>Battery</h4><ul style="list-style-type: none">• Headset playtime : 7 Hr• Headset charging time : 1.5 Hr• Charging case charging time : 2 Hr• Headset battery : 50 mAh at 3.7V• Charging case battery : 400 mAh at 3.7V<h4>Weight</h4><ul style="list-style-type: none">• Headset : 4.18g*2• Charging Case : 36.25g</div>
--	--	--	---	---	--	--	--

<div><h3>Safety guide</h3><h4>Important safety instructions</h4><ul style="list-style-type: none">• Please read this user guide and warranty manual carefully before using the product for the first time.• Do include this user guide if passing the product on to new users.• Please inspect the product before use. If there are signs of defects, please stop using the product immediately.• Use only the product in environments where wireless Bluetooth® transmission is permitted.<h4>Preventing damage to health and accidents</h4><ul style="list-style-type: none">• Do not listen at high volumes, especially for extended periods, to prevent hearing injury.• The permanent magnetic fields created by this product may interfere with medical implants such as cardiac pacemakers and implanted defibrillators (ICDs).• Please always maintain a distance of at least 10cm (3.94") between the products' magnetic component/s and implanted medical device/s at all times.• Keep this product, its accessories and packaging out of reach of young children or pets, as these may pose choking hazards.• Do not use the product in an environment that requires your special-attention (e.g. in traffic).</div>	<div><h4>Preventing damage to the product and malfunctions</h4><ul style="list-style-type: none">• Always keep the product dry and avoid exposure to heat sources (including hair dryers, heaters, prolonged strong sunlight etc.) as this may result in product deformation or malfunction.• The normal operating temperature of the product is 0 °C-40 °C or 32 °F-104 °F.• Please do not use any attachments, accessories, or spare parts with the product unless they are included with the product or recommended by Aeromax• The product should only be cleaned, where necessary, with a soft, dry cloth.</div>	<div><h4>Safety instructions for lithium rechargeable batteries</h4><p>WARNING In extreme cases, rechargeable batteries may leak and may cause the following hazards if abused or misused:</p><ul style="list-style-type: none">• explosion• fire development• heat generation• smoke or gas development<p>Dispose of defective products with built-in rechargeable batteries at special collection points or return them to your specialist dealer.</p><p>Only use rechargeable batteries recommended by Aeromax and the appropriate chargers.</p><p>Only charge the product / rechargeable batteries at ambient temperatures between 10°C/50°F and 40°C/104°F.</p><p>Switch battery pack-powered products off after use.</p><p>When not using for extended periods of time, recharge the product / rechargeable batteries regularly (about every 3 months).</p><p>Do not heat the product / rechargeable batteries above 70 °C/158°F.</p><p>Avoid exposure to sunlight and do not throw the product / rechargeable batteries into fire.</p></div>	<div><h4>Intended use/Liability</h4><p>Aeromax will not be responsible for any indirect or consequential loss, loss of profits, or loss of data. The warranty will be void under the following conditions, and the manufacturer reserves the right to refuse to provide service and to demand charges for any costs of servicing from the customer.</p><p>There will be no warranty if the product has been modified or repaired by persons not authorized by the manufacturer; Mishandling or wrong application of the product, such as leaving batteries over an extended period in the product causing battery fluid leakage, or applying the wrong voltage, manual destruction, damage caused by natural disaster or accident; Product caused by impact sand or liquid damage, tampering, or operating failure; Install and maintain product without following instructions provided by the manufacturer; If the model number or item code attached with the product has been erased or modified; Modify without authorization the contents of this warranty policy. If the product has been used for commercial, display, demonstration, or rental purposes. All parts replaced within the warranty period are the properties of the manufacturer. We have the right to handle those parts as necessary.</p><p>The warranty covers only the hardware of the product's main body. All other accessories are not covered within the warranty terms, such as external connection cable, power cable, computer cables, software, CD, external cover/cabinet, and user manual. (For item description and accessories, please refer to the user manual/instruction manual/user guide).</p></div>	<div><h4>Manufacturer Declarations</h4><p>Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials. Electrical and electronic products contain a lot of valuable materials, including metals (such as copper, aluminum, steel, and magnesium) and precious metals (such as gold, silver, and palladium). All materials of the device can be recovered as materials and energy. The crossed-out wheelee bin symbol on your product, battery, literature, or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collections at the end of their working life. Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.</p><p>CE, Recycle, No Incineration, No Landfill</p></div>	<div><h4>FCC Statement</h4><p>FCC ID : Z6K-AEROAURACAST</p><p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.</p><p>This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p><ul style="list-style-type: none">--Reorient or relocate the receiving antenna.-- Increase the separation between the equipment and receiver.-- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.-- Consult the dealer or an experienced radio/TV technician for help.<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:</p></div>	<div><h4>FCC Statement</h4><p>(1). This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation.</p><p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment</p><p>*RFwarning for Portable device: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.</p><p>FCC</p><p>AURACAST</p><p>While Auracast technology is designed to improve your audio experience, compatibility issues may arise when used with devices from other brands. However, we guarantee full compatibility and seamless performance within our Auracast ecosystem. Rest assured that our Auracast devices will work together flawlessly to deliver the best possible audio experience.</p></div>	<div><p>Aeromax Technology Co., Ltd. 16F-2, No.77, Sec. 1, Sintai 5th Rd., Sijhih Dist., New Taipei City, Taiwan 221 TEL: +886 2-2698-8686 E-MAIL: aeromax@aeromax.com.tw</p></div>
--	--	---	---	--	--	--	--