

<p>© 2017 Hasbro Inc. All rights reserved. "SHARPER IMAGE" is a registered trademark of Hasbro Inc. "Robotic Arm" is a trademark of Hasbro Inc. "JUMBO GRIP CLAW" is a trademark of Hasbro Inc. "2.4 GHz" is a registered trademark of Hasbro Inc. "360 DEGREE ARM" is a trademark of Hasbro Inc. "FULL-FUNCTION REMOTE CONTROL" is a trademark of Hasbro Inc. "LED SPOTLIGHT" is a trademark of Hasbro Inc. "RAISE OBJECTS 15" OFF THE GROUND" is a trademark of Hasbro Inc. "BATTERY OPERATED PLAY ROBOT" is a trademark of Hasbro Inc. "WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years." is a trademark of Hasbro Inc.</p>	<p>Product Line: Robotic Arm Product Name: Sharper Image Robotic Arm Item No.: 51101 UPC: 5010925110100 Dimensions: 11.5" x 11.5" x 11" (W x H x D) Weight: 1.8 lbs (0.8 kg) Age Range: 8+ Country of Origin: China</p>
--	--



BATTERY OPERATED PLAY ROBOT
WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.



SHARPER IMAGE FULL FUNCTION WIRELESS CONTROL **Robotic Arm**

MOBILE WHEELS & FULLY FUNCTIONAL • PICK UP OBJECTS WITH CLAW • ADVANCED ROBOTIC RC TECHNOLOGY

AGES 8+

JUMBO GRIP CLAW
FOR GRABBING OBJECTS

360 DEGREE ARM
360 DEGREE OF MOTION TECHNOLOGY

FULL-FUNCTION REMOTE CONTROL
CONTROL 8 POINTS OF ARM ROTATION

2.4 GHz
QUICKER RESPONSE
LONG DISTANCE CONTROLS

FULL FUNCTION WIRELESS CONTROL **Robotic Arm**

BATTERY INSTALLATION

Operation requires 4 "D" batteries (not included) for Robotic Arm, and 1 "9V" battery (not included) for Remote Controller.

- Carefully remove items from package.
- Locate the battery compartment on the underside of the Robotic Arm and wireless Remote Controller.
- Using 8 Phillips screws, remove the screws on the battery compartment located on the bottom of the robotic arm to expose the battery compartment.
- Insert 4 "D" batteries according to the polarity diagram located on the battery tray. (Fig. 1)
- Replace the battery compartment door and replace screws.
- Slide open the battery compartment door of the Remote Controller. (Fig. 2)
- Insert 1 "9V" battery following the correct polarity.
- Replace the battery compartment door.

BASIC OPERATION

- Switch both the Robotic Arm and Remote Controller power switches to the "ON" position. (Fig. 3) This will pair the two devices. LED light on Robotic Arm will be solid light if paired correctly.
- When operating, press Robotic Arm at a time, turn on each Robotic Arm and remote pair separately to allow remotes to pair with the correct Robotic Arm.
- To operate, see diagram below for basic functions. For a complete set of features, please see the included instruction manual.

- FEATURES**
- A FULLY MOBILE, ARTICULATED ROBOTIC ARM THAT YOU CONTROL.
 - MULTIPLE MOVEMENTS AND FUNCTIONS IN WIRELESS MODE.
 - GRIP CLAW WITH BUILT-IN LED LIGHT.
 - 3 MOTORS, GEAR BOXES AND FUNCTIONS.
 - 360 DEGREE MOVEMENT ALLOWS YOU TO REACH A VARIETY OF ITEMS.
 - OPERATE THE ARM USING 4 POINTS OF POSITION.
 - TANK-STYLE WHEELS FOR EASY MOBILITY.

RAISE OBJECTS 15" OFF THE GROUND

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

BATTERY OPERATED PLAY ROBOT

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

© 2017 Hasbro Inc. All rights reserved. "SHARPER IMAGE" is a registered trademark of Hasbro Inc. "Robotic Arm" is a trademark of Hasbro Inc. "JUMBO GRIP CLAW" is a trademark of Hasbro Inc. "2.4 GHz" is a registered trademark of Hasbro Inc. "360 DEGREE ARM" is a trademark of Hasbro Inc. "FULL-FUNCTION REMOTE CONTROL" is a trademark of Hasbro Inc. "LED SPOTLIGHT" is a trademark of Hasbro Inc. "RAISE OBJECTS 15" OFF THE GROUND" is a trademark of Hasbro Inc. "BATTERY OPERATED PLAY ROBOT" is a trademark of Hasbro Inc. "WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years." is a trademark of Hasbro Inc.

Manufactured by Hasbro Inc. 1000 Lakeside Drive, Pawtucket, RI 02860, USA. All other trademarks are the property of their respective owners. © 2017 Hasbro Inc. All rights reserved.

Imported by Hasbro Inc. 1000 Lakeside Drive, Pawtucket, RI 02860, USA. All other trademarks are the property of their respective owners. © 2017 Hasbro Inc. All rights reserved.

© 2017 Hasbro Inc. All rights reserved. "SHARPER IMAGE" is a registered trademark of Hasbro Inc. "Robotic Arm" is a trademark of Hasbro Inc. "JUMBO GRIP CLAW" is a trademark of Hasbro Inc. "2.4 GHz" is a registered trademark of Hasbro Inc. "360 DEGREE ARM" is a trademark of Hasbro Inc. "FULL-FUNCTION REMOTE CONTROL" is a trademark of Hasbro Inc. "LED SPOTLIGHT" is a trademark of Hasbro Inc. "RAISE OBJECTS 15" OFF THE GROUND" is a trademark of Hasbro Inc. "BATTERY OPERATED PLAY ROBOT" is a trademark of Hasbro Inc. "WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years." is a trademark of Hasbro Inc.