

EUT Photos - Internal



EUT – Interior View




Antenna Inside EUT View




Host – Top View




Host – Bottom View




Radio Module - Top View



Radio Module - Bottom View



Antenna - Top View



Antenna - Bottom View