


PREMIUM WIRELESS EARBUDS




Model:TUWEB


FCC ID:Z7RTUWEB

IC:10013A-TUWEB

TUMI



GET TO KNOW YOUR TUMI EARBUDS



1. "+" Button

- Volume up
- ◌ Next track

2. "O" Button

- Pause / play / answer call
- ◌ Power on, enter pairing mode / reject call


3. "-" Button

- Volume down
- ◌ Previous track

4. Micro-USB Charge Port

- Connect Micro-USB cable here to charge Earbuds
- Pull tab to open

5. Removable Sport Hooks



TURN ON & BLUETOOTH PAIRING

1. Activate Bluetooth® on the phone or device you are pairing with (see your device's instruction manual for information on activating its Bluetooth® settings).
2. Press and hold the “O” Multi-Function button for 5 seconds on your Earbuds. The Earbuds will turn on, and then automatically enter pairing mode.
3. LED will flash alternating RED and WHITE
4. Go to your phone or device's Bluetooth® settings and select “TUMI Earbuds” from the list.
5. If asked for a passcode enter “0000”

Your Tumi Earbuds will remember the last 8 devices it has paired with.

NOTE: If your Earbuds do not have an active Bluetooth® connection and is left on, it will shut itself off after 5 minutes. To restart your Earbuds you will need to press and hold the “O” Multi-Function button for 5 seconds.

CHARGING YOUR TUMI EARBUDS

- Before using your Earbuds for the first time, charge the unit 7 to 9 hours.
- To charge your Earbuds, plug the included USB-to-Micro-USB cable into a wall power adapter (not included) or into a powered USB port on a computer. Plug the Micro-USB connector end of the cable into the Earbud charging port.
- It will take approximately 2 hours to reach a full charge.

PLAY MUSIC

1. Start playing music on your paired device. Music plays through your Earbud.
2. On your Earbud, push “+” or “-“ button to increase or decrease volume.
3. NOTE: A tone sounds when maximum volume setting is achieved.
4. Press the “O” Multi-Function button to pause playback. Press again to resume playback.

TAKING CALLS

You can listen through your Earbuds and speak through your Earbud's microphone during phone calls.

If you make a call while paired: The audio and microphone automatically default to your Earbuds.

- Use your phone to make the call
- Press the "O" Multi-Function button to end the call

If you receive a call while paired: Your phone rings through your Earbuds.

To listen and speak through your speaker:

- Press the "O" Multi-Function button to answer the call
- Press the "O" Multi-Function button to end the call
- Press and hold the "O" Multi-Function button to reject the call


To listen and speak through your phone (depending on your phone), use your phone to answer the call, or use your phone settings to switch to your phone during a call.

USE EARBUDS WITH LOW / NO REMAINING BATTERY POWER

If your Earbuds lose power and will not turn on, you can still listen to music by connecting your Earbuds to an audio device (like a phone) with the included AUX-Micro-USB cable.

- To complete the connection, connect the Earbuds and your audio device with the included AUX-to-Micro-USB cable. Plug the AUX connector end of the cable into your Audio Device, and the Micro-USB connector end of the cable into your Earbud charging port located on the remote control.
- Your Wireless Earbuds should now play music through the AUX-Micro-USB connection.


NOTE: Your TUMI Wireless Earbuds will need minimal power to use this feature. If Earbuds have used all available power and have not been charged in several weeks, you may need to plug Earbuds in for 5-10 minutes to initiate this feature.



TUMI 500MAH BATTERY BANK


A 500mAh battery bank is included with your Wireless Earbuds to extend audio playtime.

1. USB: Charge Out
2. Battery LED's
 - 4 Battery Status LED's
 - Each light represents 25% charge capacity
3. Micro-USB: Charge In
4. Power Button
 - Power On (Press 1x)
 - Power Off (Press 2x)




CHARGING YOUR BATTERY BANK

- To charge your Battery Bank, plug the included USB-to-Micro-USB cable into a wall power adapter (not included) or into a powered USB port on a computer. Plug the Micro-USB connector end of the cable into the Battery Bank charging port.



CHARGING YOUR EARBUD WITH YOUR TUMI BATTERY BANK


- To charge your Earbuds with your Battery Bank, connect the Earbuds and Battery Bank with the included USB-to-Micro-USB cable. Plug the Micro-USB connector end of the cable into the Wireless Earbuds charging port, and the USB connector end of the cable into the Battery Bank.
- A red status LED will appear on the Earbud remote, indicating the Earbuds are charging.



CHARGING YOUR EARBUDS WHILE LISTENING TO MUSIC

Step 1: Connect Audio Device to Battery Bank

- To charge your Earbuds with your Battery Bank while listening to music, connect the Battery Bank and your audio device (like a phone) with the included AUX-to-Micro-USB cable. Plug the Micro-USB connector end of the cable into the Battery Bank charging port, and the AUX connector end of the cable into the audio device.




CHARGING YOUR EARBUDS WHILE LISTENING TO MUSIC (CONT.)

Step 2: Connect Battery Bank to Earbuds


- To complete the connection, connect the Battery Bank and your Earbuds with the included USB-to-Micro-USB cable. Plug the Micro-USB connector end of the cable into the Earbud charging port located on the remote control, and the USB connector end of the cable into the Battery Bank.

The Earbuds should now play music while charging.




TUMI EARBUD CARRY CASE

Interior pockets designed to hold Earbuds, and all accessories.



REMOVABLE SPORT HOOKS

1. Insert into ear
2. Lock forward



WARNINGS, CAUTIONS & LEGAL INFORMATION

To reduce the risk of fire or electric shock, do not expose the Tumi Earbuds to rain or moisture while charging. The Tumi Earbuds should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on or near it while being charged or charging other devices. As with any electronic products, use care not to spill liquids into any part of the product. Liquids can cause a failure and/or a fire hazard. The power supply must be used indoors only. Make no modifications to the product or accessories. Unauthorized alterations may compromise safety, regulatory compliance, and system performance, and will void the warranty. Do not place any flame sources, such as lighted candles, on or near the Tumi Earbuds. The Tumi Earbuds contains small parts that may be a choking hazard and is not suitable for children under age 3. Do not continue charging the battery if it does not reach full charge within the specified charging time. Overcharging may cause the battery to become hot, rupture, or ignite. If you see any heat deformation or leakage, properly dispose of the battery. Do not attempt to charge the battery in temperatures outside the range of 32°-104°F (0°-40°C). If the battery begins to leak, do not allow the liquid to come in contact with your skin or eyes. If contact has been made, wash the affected area with plenty of water and seek medical attention immediately. Do not expose the product or battery to excessive heat, including direct sunlight or fire and storage or use inside cars in hot weather, where it can be exposed to temperatures in excess of 115°F (60°C). Doing so may cause the battery and power supply to generate heat, rupture, or ignite. Using the product

in this manner also may result in a loss of performance and a shortened life expectancy. Extended exposure to direct sunlight may damage the external appearance and material qualities. Do not step on, throw, or drop batteries or the power supply or device, or expose them to a strong shock. Do not pierce, crush, dent, or deform the batteries or power supply in any way. If either becomes deformed, properly dispose of it. Do not short-circuit batteries. Do not attempt to service the Tumi Earbuds yourself. Opening or removing covers may expose you to dangerous voltages or other hazards and will void the manufacturer's warranty. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles. Your Bluetooth device (mobile phone, music player, tablet, laptop, etc.) must support the A2DP Bluetooth profile in order to work wirelessly with your new Tumi Earbuds. The A2DP profile is supported by most recent mobile products with built-in Bluetooth capability. Please refer to your device's user manual for details and instruction regarding the Bluetooth profiles it supports. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RADIATION EXPOSURE STATEMENT: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :


- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Lithium Battery installed is not intended to be replaced by the USER.

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

Where the MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

 **Correct Disposal of this product.** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.



This product complies with California Energy Commission efficiency standards for consumer battery chargers.

TUMI'S ACCESSORIES WARRANTY

Since our founding in 1975, Tumi has been committed to providing our customers with an ownership experience that is second to none. Specifically, we make three promises to our customers:

1. You will enjoy using innovative products that are designed and manufactured to be the best;
2. You will experience world-class customer service for as long as you own your product;
3. For two (2) years after you purchase Tumi small leather goods or accessories, virtually any problem that you encounter with the product will be covered by our warranty.

Tumi's warranty is just a small part of the ownership experience that we provide to our customers, and you will find that it is straightforward and comprehensive.

FIRST YEAR OF OWNERSHIP: TOTALLY WORRY FREE

For the first twelve (12) months of ownership, if any damage – including wear and tear – happens to your Tumi product, Tumi will cover all repair expenses, including shipping costs to and from our repair facility.

The only exceptions to this are purely cosmetic damage, such as scratched leather, and incidents or consequential damages, such as damage to, or loss of, the contents of a bag, loss of use, loss of time or similar expenses.

YEAR TWO: FULL COVERAGE

Through your second year of ownership, Tumi will cover all of the repair costs for any problems that result from defective materials or workmanship or damage from wear and tear. The only exceptions to this are damages caused by obvious abuse of the product, purely cosmetic damage and incidental or consequential damages as described above. Your only responsibility is to ship your item to us for repair, or take it to a Tumi store or authorized Tumi dealer, who will be happy to process the repair for a nominal handling and shipping fee. Many repairs can actually be handled right in the store, but if your item does need to be sent to our facility, we will repair it quickly and ship it back at no cost to you. In those rare cases mentioned above where our warranty does not apply, we will promptly provide you with an estimate of any repair costs that may be involved.

A LIFETIME OF SERVICE

It is extremely rare that we see an accessory product problem due to a manufacturing defect show up after two years of use, but we do have many customers with older items that they would like to have refurbished. For these customers, we offer a lifetime of courteous, responsive service and the highest quality repairs and refurbishment done at the lowest possible cost.

TOTAL COMMITMENT

The bottom line is that at Tumi, we are totally committed to keeping you happy about our products and our service. Once you have had the pleasure of owning and using our products, we hope that they will become your trusted companions for life. You can reach us online, 24 hours a day, 7 days a week at www.tumi.com/repair or call 800.781.TUMI (8864) to speak with a customer service representative during normal business hours. (To contact customer service outside of the US and Canada, please see the list of international centers that follows.)

PROOF OF PURCHASE

Please save your store receipt as proof of purchase. This will be needed to facilitate your first year worry-free coverage. Additionally, this will serve as proof that your purchase was made at an authorized Tumi retailer. Our warranty services only apply to products that were purchased from an authorized Tumi store or dealer.

CUSTOMER SERVICE CONTACT NUMBERS

USA/Canada
800.781.8864

For additional locations, please refer to tumi.com

TUMI

1001 Durham Avenue
South Plainfield, NJ 07080

TUMI.COM

TUMI



PKG5416R01016