

Label and Label Location

Size:28CM*2.5CM



Size:10cm*5cmm



The active speaker has been paired with the subwoofer before leaving factory.
The wireless connection is supposed to resume automatically when both active speaker and subwoofer are powered on, and the red indicator will be constantly lit.
If the wireless connection fails to resume, please follow the steps below to complete the pairing again.

1. Power on the subwoofer, the status indicator should blink slowly, which means no active wireless connection;
2. Press the "Pair" button on the back panel of the subwoofer to put it into pairing mode. The status indicator will blink rapidly;
3. Press the "Pair" button on the back panel of the active speaker to put it into pairing mode;
4. Wait until the status indicator is lit constantly. Then the pairing is done and wireless connection is made.
