


右线控上壳视图



注:

编码规则:MMYY, 共四位

MM-月份,01-1月, ...,12-12月。

依此类推,YY-年份,06-2006年,07-2007年, ...,10-2010年,之后,16-2016年,17-2017年,

例:1016 — 镭雕日期编码(字体为 Arial 大小:3pt)
 月 年

Code Rule:MM YY

"MM" represent MONTH,for example 01 stands for January, ... ,12 stands for December.

then,16 for year2016,17 for year2017,

and so on, "YY" represent YEAR,for example 06 stands for year2006,07 for year2007, ...,10 for year2010,

For example: 1016 means the product is produced in October 2016.

For example:1016 — Product information (Fonts:Arial Size:3Pt)
 MONTH
 YEAR