



Directions

Fully charge insoles prior to first use. To charge, move power switch to OFF position, plug in charging cable and connect to any USB charger or computer port. Insoles should charge fully in about 5 hours. For more information please see detailed instructions on www.heatfactory.com

To use: Move power switch to ON position and press either medium or high heat on the remote. Trim insoles in from the toe to fit shoes or boots. Do not cut past line or it will invalidate the warranty.

Storage/Care

Always store insoles with fully charged batteries to keep in peak working order. Spot clean as needed. If insoles become wet, dry fully before use.

Product Registration and Warranty

Insoles purchased from an authorized distributor are warranted for 1 year from date of purchase when accompanied by online registration. Register at www.heatfactory.com/insole-registration.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B apparatus complies with Canadian ICES-003B. Cet appareil numérique de la classe B est conforme à la norme NMB-003B du Canada.