



802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 6 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 10 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 11 CHANNEL CARRIER LEVEL




802.11ax-20 MHz(SU) 11 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 11 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 3 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 3 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 3 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 4 CHANNEL CARRIER LEVEL




802.11ax-40 MHz(SU) 4 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 4 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 6 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 8 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 8 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 8 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 9 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 9 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz



802.11ax-40 MHz(SU) 9 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




MIMO-Main Antenna


802.11g 1 CHANNEL CARRIER LEVEL




802.11g 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 2 CHANNEL CARRIER LEVEL



802.11g 2 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 2 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 6 CHANNEL CARRIER LEVEL



802.11g 6 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 6 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 10 CHANNEL CARRIER LEVEL



802.11g 10 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 10 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 11 CHANNEL CARRIER LEVEL




802.11g 11 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 11 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz 1 CHANNEL CARRIER LEVEL



802.11n-20 MHz 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz 2 CHANNEL CARRIER LEVEL



802.11n-20 MHz 2 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 2 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 6 CHANNEL CARRIER LEVEL



802.11n-20 MHz 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 10 CHANNEL CARRIER LEVEL



802.11n-20 MHz 10 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 10 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 11 CHANNEL CARRIER LEVEL



802.11n-20 MHz 11 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 11 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 3 CHANNEL CARRIER LEVEL



802.11n-40 MHz 3 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 3 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 4 CHANNEL CARRIER LEVEL



802.11n-40 MHz 4 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 4 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 6 CHANNEL CARRIER LEVEL



802.11n-40 MHz 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 8 CHANNEL CARRIER LEVEL



802.11n-40 MHz 8 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 8 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 9 CHANNEL CARRIER LEVEL




802.11n-40 MHz 9 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 9 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 1 CHANNEL CARRIER LEVEL




802.11ax-20 MHz(SU) 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 2 CHANNEL CARRIER LEVEL




802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 6 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 10 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 11 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 11 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 11 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 3 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 3 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 3 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 4 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 4 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 4 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 6 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 8 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 8 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-40 MHz(SU) 8 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-40 MHz(SU) 9 CHANNEL CARRIER LEVEL



802.11ax-40 MHz(SU) 9 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz



802.11ax-40 MHz(SU) 9 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




MIMO-Aux. Antenna


802.11g 1 CHANNEL CARRIER LEVEL




802.11g 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 2 CHANNEL CARRIER LEVEL



802.11g 2 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 2 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 6 CHANNEL CARRIER LEVEL



802.11g 6 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 6 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 10 CHANNEL CARRIER LEVEL



802.11g 10 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 10 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11g 11 CHANNEL CARRIER LEVEL



802.11g 11 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11g 11 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz 1 CHANNEL CARRIER LEVEL



802.11n-20 MHz 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11n-20 MHz 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11n-20 MHz 2 CHANNEL CARRIER LEVEL



802.11n-20 MHz 2 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 2 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 6 CHANNEL CARRIER LEVEL



802.11n-20 MHz 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 10 CHANNEL CARRIER LEVEL




802.11n-20 MHz 10 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 10 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-20 MHz 11 CHANNEL CARRIER LEVEL



802.11n-20 MHz 11 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-20 MHz 11 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 3 CHANNEL CARRIER LEVEL



802.11n-40 MHz 3 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 3 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 4 CHANNEL CARRIER LEVEL



802.11n-40 MHz 4 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 4 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 6 CHANNEL CARRIER LEVEL



802.11n-40 MHz 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 8 CHANNEL CARRIER LEVEL



802.11n-40 MHz 8 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 8 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11n-40 MHz 9 CHANNEL CARRIER LEVEL



802.11n-40 MHz 9 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11n-40 MHz 9 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 1 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 1 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 1 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 2 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 2 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 6 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
30 MHz ~ 3 GHz




802.11ax-20 MHz(SU) 6 CHANNEL, SPURIOUS
2 GHz ~ 25 GHz




802.11ax-20 MHz(SU) 10 CHANNEL CARRIER LEVEL



802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS 30 MHz ~ 3 GHz



802.11ax-20 MHz(SU) 10 CHANNEL, SPURIOUS 2 GHz ~ 25 GHz



802.11ax-20 MHz(SU) 11 CHANNEL CARRIER LEVEL

