


INSTUCTIONS

Model: ES4-20W;ES4-25W

Before using this product, please read the following instructions carefully

1. must cut off the power when Installation or replacement
2. when Installation or replacement, it should hold the plastic parts lightly , can not hod the tube to avoid damage(as shown)



3. not suitable for dimmers, voice control, remote control or sensor circuit
4. operating environment
temperature 5°C-45°C humidity ≤80%
not suitable working in high dusty.
Below 25W, each switch control 15pcs lamps at most.
Above 25W, each switch control 10 pcs lamps at most.
5. Power: AC120V/60Hz
6. when the lamp arise self-extinguishing or flicker, please check the base , lamp holder and power .
if all is ok, please replace new one.
7. Warning: This device complies with Part 18 of FCC rules.