



2.4G-RF

1) C19和R7短接则进入EMI模式，断开为正常模式



R7	1
R6	2
R5	3
R4	4
R3	5
R2	6
R1	7
R0	8
C19	9
C18	10
C17	11
C16	12
C15	13
C14	14
C13	15
C12	16
C11	17
C10	18
C9	19
C8	20
C7	21
C6	22
C5	23
C4	24
C3	25
C2	26
C1	27
CON1&CON2	28

对码键为：R1+C9 或 R6+C9

COMPANY: **ELVISION**

TITLE: **keyboard WK718**

DATE:2009/11/07

NO:

REV: ver3.0