

Bluetooth® Remote Controller

User's Manual

ST-ARC

ST-ARCG / ST-ARCM /

ST-ARCS / ST-ARCR

Version 1.0 201702

ID NO:

About This Manual

This manual is designed to assist you in installing and using the Bluetooth® Remote Controller. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice.

Edition

1st Edition,

Copyright

© Copyright 2017

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

Trademarks

All trademarks and registered trademarks are the property of their respective owners.

FEDERAL COMMUNICATIONS COMMISSION STATEMENT

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This Equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined

by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ◆ Reorient or relocate the receiving antenna.
- ◆ Increase the separation between the equipment and receiver.
- ◆ Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- ◆ Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION:

**RISK OF EXPLOSION IF BATTERY IS REPLACED
BY AN INCORRECT TYPE.**

**DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS.**

INPUT : USB 5Vdc / 100 mA ,
max charging temperature < 45 °C

Introduction

Thank you for purchasing the Bluetooth® Remote Controller. This User's Manual contains information that will help to operate the device as well as answering questions about certain special keys and buttons. Please keep this manual in a safe place for future reference.

System Requirements

- iPhone 4/4S/5/5S/6/7 iPad/ iPad2/ The New iPad/ iPad mini/iPad Air
- MAC OS X
- Smart phones and tablet PCs with Android 3.0 or higher
- Bluetooth 2.1 or higher

Package includes:

Bluetooth® Remote Controller * 1, Manual * 1

Type-C cable * 1

Device pairing

1. Turn on the Bluetooth from iPad/Smart Phone.
2. Turn on the Bluetooth Remote controller power and press the “✱” button. (Please make sure the blue LED is flashing)
3. The device ”Bluetooth Remote controller” displays on iPad/Smart Phone. Then, choose “Connect”.
4. Start to use Bluetooth Remote controller.





Note: 1. There is a switch at top of the Bluetooth Remote controller to switch between Media mode and Presentation mode.




2. There is a power switch at bottom of the Bluetooth Remote controller. When not in use, please turn to OFF to save battery power.

3. After 30 minutes non-operation, the Bluetooth Remote controller will go to low-power mode. Please press any key to wake up and wait the blue LED turn off before using.






4. Please charge the battery before using until the red LED turn off.



Key function description: Media mode

Function name		Android	ios	Mac OS
	V+	Increases the device's sound volume. Hold down to increase volume more quickly.	Increases the device's sound volume. Hold down to increase volume more quickly. /	Increases the device's sound volume. Hold down to increase volume more quickly.
	Pre-track	Switches to the previous media track. Press once for each preceding media track.	Switches to the previous media track. Press once for each preceding media track.	Switches to the previous media track. Press once for each preceding media track.
	Play/Pause	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.	Switches between Play and Pause. Once Pause is pressed, pressing this button again resumes play.
	Next track	Switches to the next media track. Press once for each subsequent media track.	Switches to the next media track. Press once for each subsequent media track.	Switches to the next media track. Press once for each subsequent media track.

	V-	Decreases the device's sound volume. Hold down to decrease volume more quickly.	Decreases the device's sound volume. Hold down to decrease volume more quickly.	Decreases the device's sound volume. Hold down to decrease volume more quickly.
	Mute	Mute the device's sound volume. Press it again to turn the system volume back on.	Mute the device's sound volume. Press it again to turn the system volume back on. Hold on to call the virtual keyboard. Hold on again to disable virtual keyboard.	Mute the device's sound volume. Press it again to turn the system volume back on.
	Home	Back to main screen.	Back to main screen.	Non-function

Key function description: Presentation mode

Function name		Android	ios	Mac OS
	Move up	Move up. Hold down to move up more quickly	Move up. Hold down to move up more quickly	Move up. Hold down to move up more quickly
	Move left	Move left. Hold down to move left more quickly	Move left. Hold down to move left more quickly	Move left. Hold down to move left more quickly
	Enter key	Enter key	Enter key	Enter key
	Move right	Move right. Hold down to move right more quickly	Move right. Hold down to move right more quickly	Move right. Hold down to move right more quickly
	Move down	Move down. Hold down to move down more quickly	Move down. Hold down to move down more quickly	Move down. Hold down to move down more quickly

	<p>Mute</p>	<p>Mute the device's sound volume. Press it again to turn the system volume back on.</p>	<p>Mute the device's sound volume. Press it again to turn the system volume back on. Hold on to call the virtual keyboard. Hold on again to disable virtual keyboard.</p>	<p>Mute the device's sound volume. Press it again to turn the system volume back on.</p>
	<p>Home</p>	<p>Back to main screen.</p>	<p>Back to main screen.</p>	<p>Non-function</p>