

# Fan Fold User Manual Artwork

说明书 折页

157g 铜版纸

157g double side glossy paper

Size for each page 120mm x 120mm

每页尺寸 120mm x 120mm














































1

2

3

4

5

 <p>TECHREBELLION <b>Portable Wireless Keyboard User Manual</b> TWKBI</p>  <p>Windows, Android, Mac, iPadOS, iOS</p>	<h3>How to Connect?</h3> <ol style="list-style-type: none"> <li>Set the power switch to "On". Long press the connect button for 3 seconds until the indicator light start to flash.</li> <li>Turn on your Tablet's Bluetooth and search for the device name: TWKBI. Click to connect.</li> <li>After connect successful, there is no need to reconnect next time.</li> </ol> <p><b>Specifications:</b> Keyboard Layout: US Layout Battery: 150mAh Cable Length: 20 Inches Voltage: 3.0-4.2V</p> <p>Working Current: &lt;2.5mA Charging Time: 2.5-3 Hours Battery Life: around 50 Hours Charging Port: USB-C</p>	<h3>Function Keys Guide</h3> <table border="1"> <tr> <td>Press Fn + </td> <td>Home/ESC</td> </tr> <tr> <td>Press Fn + </td> <td>Search</td> </tr> <tr> <td>Press Fn + </td> <td>Select All</td> </tr> <tr> <td>Press Fn + </td> <td>Copy</td> </tr> <tr> <td>Press Fn + </td> <td>Paste</td> </tr> <tr> <td>Press Fn + </td> <td>Cut</td> </tr> </table>	Press Fn + 	Home/ESC	Press Fn + 	Search	Press Fn + 	Select All	Press Fn + 	Copy	Press Fn + 	Paste	Press Fn + 	Cut	<table border="1"> <tr> <td>Press Fn + </td> <td>Previous Song</td> </tr> <tr> <td>Press Fn + </td> <td>Play/Pause</td> </tr> <tr> <td>Press Fn + </td> <td>Next Song</td> </tr> <tr> <td>Press Fn + </td> <td>Volume Down</td> </tr> <tr> <td>Press Fn + </td> <td>Volume Up</td> </tr> <tr> <td>Press Fn + </td> <td>Off The Screen</td> </tr> </table>	Press Fn + 	Previous Song	Press Fn + 	Play/Pause	Press Fn + 	Next Song	Press Fn + 	Volume Down	Press Fn + 	Volume Up	Press Fn + 	Off The Screen	<table border="1"> <tr> <td>Press Fn + </td> <td>Soft Keyboard Switch</td> </tr> <tr> <td>Press Fn + </td> <td>Language Switch</td> </tr> </table> <p><small>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</small></p> <p><small>This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the device and receiver. --Connect the device into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.</small></p> <p><small>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</small></p> <p>Windows® and the logo are registered trademarks of Microsoft Corporation in the United States and other countries. Android™ and the logo are trademarks of Google, Inc. in the US and/or other countries. iOS® is a registered trademark of Cisco in the US. iPad®, Mac® and their logos are registered trademarks of Apple Inc. in the United States and other countries.</p> <p><b>TECHREBELLION</b> "TECH REBELLION" and "TR" logos are trademarks of Hello to Green, LLC. ©2023 Tech Rebellion. All Rights Reserved.</p> 	Press Fn + 	Soft Keyboard Switch	Press Fn + 	Language Switch
Press Fn + 	Home/ESC																															
Press Fn + 	Search																															
Press Fn + 	Select All																															
Press Fn + 	Copy																															
Press Fn + 	Paste																															
Press Fn + 	Cut																															
Press Fn + 	Previous Song																															
Press Fn + 	Play/Pause																															
Press Fn + 	Next Song																															
Press Fn + 	Volume Down																															
Press Fn + 	Volume Up																															
Press Fn + 	Off The Screen																															
Press Fn + 	Soft Keyboard Switch																															
Press Fn + 	Language Switch																															