

BLUETOOTH HANDS FREE CAR KIT

with FM Transmitter and Bass Boost Functionality
BT712S (PWFMT11)



Thanks for choosing our Bluetooth FM Transmitter. This device streams music and phone calls directly from your Bluetooth device to the car FM stereo system. The built-in microphone provides you with an amazing hands free function, it is also with a Micro SD card/USB Disk slot that lets you enjoy favorite MP3 and WMA tunes by your car's stereo system and charge your phone simultaneously. It also can deliver a deeper bass by pressing the bass button when playing the music. Please read the User Manual carefully before using it. Hope this device makes your driving more interesting and safer.

Packing contents:

- Bluetooth FM Transmitter
- User Guide

Features:

1. Wireless transmit phone call & audio playing to the car FM stereo system via Bluetooth;
2. Switch to Hands-free mode automatically from music playing status when receiving calls;
3. Adjustable goose-neck design allows us to find a better viewing;
4. Elegant design with big white LED display;
5. Support to read Micro SD (Max 32 GB);
6. Dual USB output QC3.0+DC 5V/2.4A;
7. Voice prompt and hands-free calling for safety driving;
8. Adopt the Bluetooth 5.0 Technology;
9. Siri/Google assistant quick activation.

Specifications:

- Bluetooth Version: 5.0;
- Frequency range: 88.1-107.9MHZ;
- Frequency stability: ± 10 ppm;
- Product Input:12-24V;
- Dual USB output: QC3.0+DC 5V/2.4A;
- Micro SD Card (Max Capacity) :32GB;
- Music Format: MP3/WMA/WAV/FLAC;
- Product Dimension: 59*90*127 mm;
- Product Weight: 73.3g;

Compatibility:


This device can be paired as a hands free kit with any compatible Bluetooth 2.1 or higher enabled devices.

Precautions:

Please read all safety instruction warnings carefully before using this product. Improper use of this product may result in damage to this or attached products. To ensure the products work well, please never use this in the following conditions:

1. Moist or underwater conditions.
2. Conditions near heater or high-temperature service.
3. Conditions with direct and strong sunshine,
4. Never dismantle the product without due permission, otherwise it may nullify the warranty clause.

Appearance:



Operation Instructions




Setup the FM Transmitter Connection:

1. Plug the unit into your vehicle's cigarette lighter or power port.
2. Tune your radio to an unused FM frequency, then match the same frequency of this unit.
3. Insert Micro SD card or USB disk which containing MP3/WMA files into the card/USB slot. It will play and transmit the file automatically.


Using Bluetooth function:

1. Using Bluetooth for the first time, you need to pair your mobile phone with this unit. Activate your mobile phone's Bluetooth function, then search new device. When the mobile phone detects this unit (named as "**PWFMT11**"), please pair or connect.
2. On music playing mode, when there is an incoming call, this unit will automatically switch to telephone mode.

Bluetooth calling:

1. Please press  to answer the incoming call or hang off a call.
2. Please press  and hold for 3 seconds during call to reject the incoming call in Bluetooth calling mode.
3. Please press  twice to dial the last Number automatically.
4. When making a call, you can only dial the phone number by your mobile phone, but once the call connected, you can use the hands-free function to enjoy it.

HOW TO ACTIVATE VOICE ASSISTANT (e.g. Siri/Google assistant)

Press "" hold for 2 seconds to quickly access voice assistant.

Quick Guide:

Operation Guide	On FM transmitter
1. Answer/hang up the call:	Press "☎" button: answer the call Press "☎" button: hang up the call
2. Ignore call	Press "☎" and hold for 3 seconds to reject incoming calls
3. Call last Number	Press "☎" twice to dial the last Number automatically.
4. Private calling	When answering a call, press "☎" and hold for 3 seconds to switch to private call mode.
5. Play and Pause the music:	Press "☎" Button: Play the music Press "☎" Button again: Pause playing
6. Adjust the Volume:	Press "∧" and hold for 2 seconds to increase the Volume Press "∨" and hold for 2 seconds to decrease Volume
7. Set frequency:	press "CH" and then press "∧" to increase the frequency Press "CH" and then press "∨" to decrease the frequency
8. Choose music:	Press "∨" Button: Play the next song Press "∧" Button: Play the previous song

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.