

Functionality check

LED

The ME401-2 is fitted with an LED that has the following status indications:

LED mode	Status indication
A constant green light shortly interrupted by a red blink:	The unit is attached to the GSM network and the GPS is navigating – Everything is OK.
No light:	The unit is not connected to a power supply
Constant red light:	The unit is powered up, but is not yet attached to the GSM network
Short red blink:	The unit is powered up and it is attached to the GSM network, but is not yet navigating
Constant green light:	The unit is navigating (GPS-satellite position fix)

