

---

## Test Setup photographs (DXX)

---

### EUT Position: X-axis



---

## Test Setup photographs (DXX)

---

### EUT Position: Y-axis



---

## Test Setup photographs (DXX)

---


### EUT Position: Z-axis



---

## Test Setup photographs (DXX)

---



## Test Setup photographs (DXX)

