

English
<b>Safety Cautions</b>
<b>▲ CAUTION</b>
<p>Do not disassemble, adjust, or repair the product arbitrarily.</p> <p>Do not place the product near excessive heat or flammable material.</p> <p>Do not arbitrarily replace the battery, as it may explode.</p> <p>The product may be damaged if an incompatible recharger is used.</p> <p>Make sure that an infant or a child does not swallow a magnet or a small component of the product.</p> <p>Make sure that foreign objects do not enter the charger's connectors (charging port and power plug). Failure to do so may result in fire or electric shock.</p> <p>If you have a medical device implanted, contact your doctor before using this device.</p> <p>For your safety, do not remove the battery installed in the product.</p> <p>The lithium-ion polymer battery is a hazardous component which can cause injury.</p> <p>Battery replacement by an unqualified professional can cause damage to your device.</p> <p>Make sure that foreign substances do not enter the audio input terminal.</p>
<b>▲ WARNING</b>
<p>Do not apply excessive force to, make holes in, or drop the product from a high place.</p> <p>Keep the product away from water, alcohol, benzene, etc.</p> <p>Do not store the product in a wet or a dusty place.</p> <p>Do not place any heavy objects on the product.</p> <p>This product is not waterproof. Avoid humidity or water when using the product.</p>
<b>🔋 NOTE</b>
<p>Do not pull the earphone cable with excessive force.</p> <p>If the product is exposed to excessive sweat, clean the product.</p> <p>Keep the earbuds clean.</p> <p>For your safety, do not wear the product while it is being charged.</p>

1	2	3	4	5	6
---	---	---	---	---	---

- If LG Electronics repairs or replaces the product, the repaired or replaced product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of LG Electronics.

- This warranty does not cover any failure of the product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with instructions for use and maintenance of the product. Nor does this warranty cover any failure of the product due to accident, modification or adjustment, acts of God, or damage resulting from liquid.

- This warranty does not cover product failures due to improper repair installations, modifications, or service performed by a non-LG Electronics authorized person. Tampering with any of the seals on the product will void the warranty.

- THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL LG ELECTRONICS OR ITS VENDORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS, TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

- Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you. The warranty provided does not affect the consumer's statutory rights under applicable national legislation in force, nor the consumer's rights against the dealer arising from their sales/purchase contract.

### Limited Warranty

Subject to the conditions of this Limited Warranty, LG Electronics warrants this product to be free from defects in design, material, and workmanship at the time of its original purchase by a consumer, and for a subsequent period of one (1) year. Should your product need warranty service, please return it to the dealer from whom it was purchased or contact your local LG Electronics contact center to get further information.

7	8	9	10	11	12
---	---	---	----	----	----

#### Aviso de conformidad

##### AVISO DE LA FCC PARA LOS USUARIOS

Este dispositivo cumple con el artículo 15 de la normativa de la FCC.

El funcionamiento está sujeto a las dos condiciones siguientes:

(1) Este dispositivo no puede causar interferencia nociva,
(2) Este dispositivo debe aceptar cualquier interferencia que reciba, incluso la que provoque un funcionamiento no deseado.

Las modificaciones o los cambios que no estén expresamente aprobados por el fabricante (o la parte responsable) del cumplimiento podrían anular la autoridad del usuario para utilizar el producto.

##### Declaración del artículo 15.105

Este equipo ha sido evaluado y se ha comprobado que cumple con los límites para un dispositivo digital clase B, conforme el artículo 15 de las reglas de la FCC.

Estos límites han sido diseñados para brindar una protección razonable contra la interferencia nociva en una instalación residencial. Este equipo genera, utiliza y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, podría causar interferencia nociva para las comunicaciones radiales.

No obstante, no se garantiza la ausencia de interferencia en una instalación en particular. Si este equipo causa interferencias con la señal de recepción de la radio o televisión, lo cual se verifica apagando y encendiendo el equipo, el usuario puede intentar corregir la interferencia tomando una o más de las siguientes medidas:

- Reorientar o reubique la antena receptora.
- Aumente la distancia entre el equipo y el receptor.
- Conecte el equipo en un tomacorriente que no pertenezca al mismo circuito del tomacorriente en el que está conectado el receptor.
- Consulte al distribuidor o a un técnico de radio/TV experimentado para obtener ayuda.

##### LG Tone & Talk™

Search for "LG Tone & Talk" in Google Play store or scan the QR code on the right to install LG Tone & Talk.

NOTE: The LG Tone & Talk feature can only be used one function at a time.

#### HBS-W120 Pairing and Connecting

##### Dual Play

You can connect two HBS-W120 headsets to listen to the same music.

- Connect the first HBS-W120 to your mobile phone or device.
- Press and hold the **Next (▶) button** and **Play/Pause button** of the first HBS-W120 simultaneously for more than one second. (This HBS-W120 becomes the Master headset.)
- Press and hold the **Previous (◀) button** and **Play/Pause button** of the second HBS-W120 simultaneously for more than one second. (This HBS-W120 becomes the Slave headset.)
- An alert will indicate the connection status once the two HBS-W120 headsets are connected.

To disconnect Dual Play, press the **Previous (◀) button** or the **Next (▶) button** and the **Play/Pause button** simultaneously for at least one second.

NOTE: Dual Play supports both Android and iOS.
In Dual Play, music playback and volume of the device connected to the Master headset can be controlled from both the Master and Slave headsets.
If the Master headset and Slave headset are disconnected during Dual Play and they later enter an environment in which they can reconnect, they will automatically attempt a Dual Play connection.
Multi-connection is not available during Dual Play.

##### Wired connection (audio input terminal)

NOTE: When wired audio is connected, the Dual Play connection and the *Bluetooth* connection will be cut.

The audio cable is purchased separately and is not provided when purchasing the product. When the audio cable is disconnected, an automatic connection is established with the most recently connected device. (If no device is found, Search mode is activated.) No notifications for equalizer mode change are provided when connecting a wired connection.

### Important Safety Information

##### Avoiding hearing damage

Permanent hearing loss may occur if you use your headset at a high volume.

Set the volume to a safe level. Over time you can become accustomed to a higher volume that may sound normal but can be damaging to your hearing.

If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected.

Hearing experts suggest that to protect your hearing:

- Limit the amount of time you use the headset at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.



Lower the volume before switching to Earphones mode from Speaker mode.

While in Speaker mode, do not listen to or adjust the volume with the headset placed close to your ears.

##### Using headsets safely

Use of headsets to listen to music while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive while driving. Stop using this device if you find it disruptive or distracting while operating any type of vehicle or performing any other activity that requires your full attention.

#### Pairing with TV and other devices (tablet, notebook PC, etc.)

You can connect and use HBS-W120 with TV and other devices that support the *Bluetooth* function.

For details on how to connect, refer to the user manual supplied with the product.

#### Troubleshooting

Problem	Solution
The power does not turn on	Check the battery level and charge it.
Cannot make a call with HBS-W120	If the mobile phone does not support headset and hands-free function, you cannot use the calling features. Check the battery level and charge it. <p>Check whether HBS-W120 is turned on.</p> <p>Check whether HBS-W120 is in Search mode.</p> <p>- If you press and hold the <b>Call button</b> while you slide the <b>Power switch</b> to the ON position to turn the power on, the HBS-W120 switches to Search mode.</p>
Cannot register HBS-W120 to the mobile phone	Check whether HBS-W120 is in Search mode.
The sound is low	Control the sound level of the device connected to HBS-W120.
Connection to TV is lost, or TV cannot be connected	Check whether the TV is turned off or switched to sleep mode. If you turn off the TV and turn it on again, you will need to reconnect it (refer to the user manual provided with the TV).
	Please check your battery level and charge the battery. Refer to the Connecting Quickly/Connecting Manually instructions and connect your HBS-W120 to your mobile phone or device. Position two HBS-W120 headsets within 1 foot (30 centimeters) of each other.
Dual Play cannot be connected	Refer to the Dual Play connection instructions to connect the two HBS-W120 headsets. <p>NOTE: Connections are only supported between two identical HBS-W120 models.</p>

1	2	3	4	5	6
---	---	---	---	---	---

### Specifications and Features

Item	Comments
<i>Bluetooth</i> Specifications	V 4.2 (Headset/Hands-Free/A2DP/AVRCP)
Battery	3.7 V / 445 mAh* 2, lithium-ion polymer
Standby Time	Up to 61 days*
Talk Time	Up to 40 hours (16 hours when in Speaker mode)*
Music Play Time	Up to 35 hours (6 hours when in Speaker mode, Based on 50% volume level)*
Charging Time	Less than 2.5 hours
Rated Input Voltage	DC 4.75 - 5.3 V, 700 mA
Operating Temperature	-10°C (+14°F) ~ +50°C (+122°F)
Dimension/Weight	7.6" (W) X 6.9" (L) X 0.7" (H) / 4.4 oz
Operating Frequency	2402 MHz to 2480 MHz

\*Duration of use may vary depending on the connected mobile device, features being used, settings, signal strength, operating temperature, frequency band, and other methods of use.

NOTE: When using the speaker mode, the usage time may vary depending on the volume size set by the user.

<b>▲ ADVERTENCIA</b>
<p>No aplique fuerza excesiva, no haga orificios ni arroje el producto desde un lugar elevado.</p> <p>Mantenga el producto alejado de agua, alcohol, benceno, etc.</p> <p>No almacene el producto en lugares húmedos o con polvo.</p> <p>No coloque objetos pesados sobre el producto.</p> <p>Este producto no es resistente al agua. Evite la humedad o el agua cuando utilice el producto.</p>
<b>🔋 NOTA</b>
<p>No tire del cable del auricular con fuerza excesiva.</p> <p>Si se expone al producto a sudor excesivo, límpielo.</p> <p>Mantenga siempre limpias las puntas del auricular.</p> <p>Por su seguridad, no utilice el producto mientras se está cargando.</p>

7	8	9	10	11	12
---	---	---	----	----	----

#### 3. Atmósferas potencialmente explosivas

Cuando se encuentre en una atmósfera potencialmente explosiva, apague el dispositivo electrónico. Aunque es poco frecuente, este dispositivo electrónico podría generar chispas. Las chispas en dichas áreas pueden causar una explosión o un incendio y provocar lesiones personales o incluso la muerte. Las zonas con riesgo de explosión suelen estar claramente señaladas, aunque no en todos los casos.

#### 4. Llamadas de emergencia

(¡IMPORTANTE!)

Este auricular *Bluetooth* y el dispositivo electrónico conectado a él funcionan con señales de radio, redes terrestres y móviles, además de funciones programadas por el usuario, que no pueden garantizar la conexión en todas las situaciones. Por lo tanto, nunca debe depender únicamente de un dispositivo electrónico para casos de comunicaciones esenciales (por ej. emergencias médicas). Recuerde que, para realizar o recibir llamadas, el auricular y el dispositivo electrónico conectado a él deben estar encendidos y en un área de servicio con una señal móvil de buena potencia. Las llamadas de emergencia no pueden hacerse en todas las redes de telefonía celular ni cuando están en uso ciertos servicios de red o funciones del teléfono. Compruebe la disponibilidad con su proveedor de servicio local.

#### 5. Información sobre la batería

Las baterías recargables tienen una vida útil prolongada si reciben el tratamiento adecuado. Las baterías nuevas o que no se hayan utilizado por mucho tiempo podrían tener una capacidad reducida las primeras veces que se utilizan. No exponga la batería a temperaturas extremas, superiores a +50°C (+122°F) o inferiores a -10°C (+14°F). Para obtener la máxima capacidad de la batería, úsela a temperatura ambiente. Si se utiliza la batería en condiciones de temperaturas bajas, la capacidad se verá reducida. La batería solo puede cargarse a temperaturas entre +10°C (+50°F) y +45°C (+113°F).

#### 6. Reciclado de la batería del auricular *Bluetooth*

La batería del auricular *Bluetooth* debe desecharse con el procedimiento adecuado y nunca debe arrojarse al basurero municipal. Los encargados del servicio técnico de LG Electronics que extraigan baterías las desearán de acuerdo con las reglamentaciones locales.

#### Declaration of Confirmation

##### FCC NOTICE TO USERS:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer (or party responsible) for compliance could void the user's authority to operate the equipment.

##### FCC Part 15.105 statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

1	2	3	4	5	6
---	---	---	---	---	---

7	8	9	10	11	12
---	---	---	----	----	----

Español
<b>Precauciones de seguridad</b>
<b>▲ PRECAUCIÓN</b>
<p>No desmonte, modifique ni repare el producto de forma arbitraria.</p> <p>No coloque el producto cerca de calor excesivo ni de materiales inflamables.</p> <p>No reemplace la batería de forma arbitraria, ya que podría explotar.</p> <p>El producto podría dañarse si utiliza un cargador incompatible.</p> <p>Asegúrese de que no le bebés ni niños ingieran un imán o un componente pequeño del producto.</p> <p>Asegúrese de que no se introduzcan sustancias extrañas en los conectores del cargador (puerto de carga y cable de alimentación). Esto es para prevenir incendios y descargas eléctricas.</p> <p>Si tiene un dispositivo médico implantado, consulte a su médico antes de usar el producto.</p> <p>Por su seguridad, no quite la batería que viene instalada en el producto.</p> <p>La batería de polímero de iones de litio es un componente peligroso que puede provocar lesiones.</p> <p>Su dispositivo se puede dañar si el reemplazo de la batería lo realiza un profesional no calificado.</p> <p>Asegúrese de que no ingresen sustancias extrañas en el terminal de entrada de audio.</p>
<b>▲ ADVERTENCIA</b>
<p>No aplique fuerza excesiva, no haga orificios ni arroje el producto desde un lugar elevado.</p> <p>Mantenga el producto alejado de agua, alcohol, benceno, etc.</p> <p>No almacene el producto en lugares húmedos o con polvo.</p> <p>No coloque objetos pesados sobre el producto.</p> <p>Este producto no es resistente al agua. Evite la humedad o el agua cuando utilice el producto.</p>
<b>🔋 NOTA</b>
<p>No tire del cable del auricular con fuerza excesiva.</p> <p>Si se expone al producto a sudor excesivo, límpielo.</p> <p>Mantenga siempre limpias las puntas del auricular.</p> <p>Por su seguridad, no utilice el producto mientras se está cargando.</p>

7	8	9	10	11	12
---	---	---	----	----	----

#### 7. Condiciones

- La garantía tiene validez únicamente si, junto con el producto que se va a reparar o reemplazar, se presenta la factura original que el distribuidor le emitió al comprador original. LG Electronics se reserva el derecho de denegar el servicio de garantía si no se presenta dicha información o si hubiera habido modificaciones luego de la compra original del producto al distribuidor.

- Si LG Electronics repara o reemplaza el producto, el plazo de garantía del producto reemplazado o reparado equivaldrá al tiempo restante del plazo de la garantía original o noventa (90) días a partir de la fecha de reparación, el período que sea mayor. La reparación o el reemplazo podrían implicar el uso de unidades reacondicionadas con funciones equivalentes. Los componentes o las piezas reemplazadas pasarán a ser propiedad de LG Electronics.

- La presente garantía no cubre fallas por desgaste natural ni uso indebido, entre otros casos, usos fuera de lo normal y habitual, conforme a las instrucciones de uso y mantenimiento del producto. La cobertura tampoco abarca fallas del producto que se deban a accidentes, modificaciones o ajustes, caso fortuito o daño producido por algún líquido.

- La garantía no cubre fallas del producto a causa de instalaciones, reparaciones o modificaciones incorrectas llevadas a cabo por personas que no estén autorizadas por LG Electronics. Todo indicio de manipulación en cualquiera de los sellos del producto anulará la garantía.


- NO EXISTEN GARANTÍAS EXPRESAS, NI ORALES NI ESCRITAS, SALVO LAS QUE CONSTAN EN EL PRESENTE DOCUMENTO, INCLUYENDO, ENTRE OTRAS, LAS GARANTÍAS IMPLÍCITAS DE COMERCIALIZACIÓN O DONEIDAD PARA UN FIN DETERMINADO. LA DURACIÓN DE CUALQUIER GARANTÍA IMPLÍCITA SE LIMITA AL PLAZO DE LA PRESENTE GARANTÍA LIMITADA. ASIMISMO, LG ELECTRONICS O SUS DISTRIBUIDORES NO SERÁN RESPONSABLES, EN NINGUNA CIRCUNSTANCIA, POR DAÑOS FORTUITOS O EMERGENTES DE ÍNDOLE ALGUNA, INCLUYENDO, ENTRE OTROS, PÉRDIDAS COMERCIALES O DE GANANCIAS, HASTA EL MÁXIMO DESCARGO DE RESPONSABILIDAD PERMITIDO POR LA LEY.

- En algunos estados y países, no se permite la exclusión o la limitación de daños fortuitos y emergentes, ni la limitación del plazo de las garantías implícitas. Por lo tanto, las exclusiones o limitaciones de los párrafos anteriores podrían no aplicarse en su caso. La garantía provista no afecta los derechos del consumidor establecidos por la legislación nacional pertinente en vigencia ni los derechos del consumidor en relación con el distribuidor que surjan del contrato de compra-venta.

#### IMPORTANT NOTE:

To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void the user's authority to operate the device.

*Bluetooth®* is a registered trademark of Bluetooth SIG, Inc. worldwide.



#### Additional Information

##### 1. Radio frequency exposure

This *Bluetooth* Wireless Stereo Headset HBS-W120 is a radio transmitter and receiver. When in operation it communicates with a *Bluetooth*-equipped mobile device by receiving and transmitting radio frequency (RF) electromagnetic fields (microwaves) in the frequency range 2.4 to 2.4835 GHz. Your *Bluetooth* headset is designed to operate in compliance with the RF exposure guidelines and limits set by national authorities and international health agencies when used with any compatible LG Electronics mobile phone.

##### 2. *Bluetooth* connection precautions

The following environments affect the range and reception of *Bluetooth* signals:

- When walls, metal, human bodies, or other obstacles exist between the *Bluetooth* device and the connected device.
- When equipment that uses 2.4 GHz frequency signals (wireless LANs, wireless phones, microwave ovens, etc.) is placed near the devices being used.

1	2	3	4	5	6
---	---	---	---	---	---

### LG Tone & Talk™

Para instalar LG Tone & Talk, busque "LG Tone & Talk" en Google Play Store o lea el código QR de la derecha.

NOTA: LG Tone & Talk puede utilizar solo una función a la vez.

#### Vinculación y conexión de HBS-W120

##### Dual Play

Puede conectar dos auriculares HBS-W120 para escuchar la misma música.

- Conecte el primer HBS-W120 a su dispositivo o teléfono móvil.
- Mantenga presionado los **Botones siguiente (▶) y reproducir/pausar** del primer HBS-W120 al mismo tiempo durante más de un segundo. (Este HBS-W120 se convierte en el auricular principal.)
- Mantenga presionado los **Botones anterior (◀) y de reproducir/pausar** del segundo HBS-W120 al mismo tiempo durante más de un segundo. (Este HBS-W120 se convierte en el auricular secundario.)
- Una alerta indicará el estado de la conexión una vez que los dos auriculares HBS-W120 estén conectados.

Para desconectar Dual Play, presione el **Botón anterior (◀)** o el **Botón siguiente (▶)** y el **Botón reproducir/pausar** al mismo tiempo durante al menos un segundo.

NOTA: Dual Play es compatible con Android y iOS.

En Dual Play, la reproducción de música y el volumen del dispositivo conectado al auricular principal se pueden controlar desde el auricular principal y el secundario. Si el auricular principal y el secundario están desconectados durante la conexión Dual Play y luego ingresan a un entorno en el que se pueden volver a conectar, intentarán realizar una conexión Dual Play automáticamente. La conexión múltiple no está disponible durante Dual Play.

##### Conexión por cable (terminal de entrada de audio)

NOTA: si el audio está conectado por cable, se cortarán las conexiones de Dual Play y *Bluetooth*. El cable de audio se vende por separado y no viene incluido con la compra del producto. Cuando el cable de audio está desconectado, se establece una conexión automática con el dispositivo conectado más reciente (Si no se encuentra ningún dispositivo, se activa el modo de búsqueda)
No se proporcionan notificaciones para el cambio de modo del ecualizador cuando se realiza una conexión por cable.

### Garantía limitada

Sujeta a las condiciones de la presente garantía limitada, LG Electronics garantiza que este producto no presenta fallas de diseño, materiales ni mano de obra en el momento en que el consumidor realiza la compra original, y que no las presentará por un período posterior de un (1) año. En caso de que el producto requiera servicio técnico de garantía, sírvase llevarlo al establecimiento del distribuidor que se lo vendió o comuníquese con el centro de contacto de LG Electronics de su región para obtener más información.

### Información importante de seguridad

#### Reducción de la capacidad auditiva

Si utiliza el auricular con un nivel de volumen alto, podría sufrir hipoacusia permanente. Configure el volumen en un nivel incoo. Con el tiempo, podría acostumbrarse a un volumen de sonido más alto que podría parecer normal, pero que podría dañar su capacidad auditiva.

Si le zumban los oídos o siente que los sonidos le llegan medio apagados, no utilice el dispositivo y consulte a un otorrinolaringólogo. Cuanto más alto sea el volumen, más rápido podría verse afectada su audición.

Algunos expertos en audición sugieren que, para proteger la audición, se debe:

- Limitar el tiempo de uso del auricular a volumen alto.
- Evitar subir el volumen para contrarrestar el exceso de ruido ambiental.
- Bajar el volumen si ni oye a la gente que habla cerca de usted.

Baje el volumen antes de cambiar al modo Auriculares desde el modo Altavoz.

Mientras está en modo Altavoz, no escuche ni ajuste el volumen con los auriculares puestos cerca de los oídos.

##### Uso seguro de los auriculares

No se recomienda utilizar auriculares para escuchar música mientras conduce un vehículo y, en algunas zonas, es ilegal hacerlo. Sea precavido y cauto al conducir. No utilice el dispositivo si le resulta molesto o lo distrae mientras maneja cualquier tipo de vehículo o realiza alguna otra actividad que requiera toda su atención.

#### 3. Potentially explosive atmosphere

Turn off your electronic device when in any area with a potentially explosive atmosphere. Although this is uncommon, your electronic device could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive atmosphere are often but not always clearly marked.

#### 4. Emergency calls

IMPORTANT!

This *Bluetooth* headset and the electronic device connected to the headset operate using radio signals and mobile and landline networks as well as user-programmed functions, which cannot guarantee connection under all conditions. Therefore, you should never rely solely upon any electronic device for essential communications (e.g., medical emergencies). Remember, in order to make or receive calls, the headset and the electronic device connected to the headset must be switched on and in a service area with adequate mobile signal strength. Emergency calls may not be possible on all mobile phone networks or when certain network services and/or phone features are in use. Check with your local service provider.

#### 5. Battery information

A rechargeable battery has a long service life if treated properly. A new battery or one that has not been used for a long period of time could have reduced capacity the first few times it is used. Do not expose the battery to extreme temperatures, never above +50°C (+122°F) or below -10°C (+14°F). For maximum battery capacity, use the battery at room temperature. If the battery is used in low temperatures, the battery capacity will be reduced. The battery can only be charged in temperatures between -10°C (+50°F) and +45°C (+113°F).

#### 6. Recycling the battery in your *Bluetooth* headset

The battery in your *Bluetooth* headset must be disposed of properly and should never be placed in municipal waste. The LG Electronics service partner that removes the battery will dispose of it according to local regulations.

#### 7. Conditions

- The warranty is valid only if the original receipt issued to the original purchaser by the dealer, specifying the date of purchase and serial number, is presented with the product to be repaired or replaced. LG Electronics reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the product from the dealer.

1	2	3	4
---	---	---	---

**FCC Warning Statement**

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

**IC Warning Statement**

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) L'appareil ne doit pas produire de brouillage, et (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.