



Antenna and Device Information



Antenna	Mode	Band
ANT1	Main LB	LTE B5/12/13/17/28 W5/8 GSM850/EGSM – TX,RX
ANT2	Main MB/HB	LTE B2,4,7,66 W2/4 DCS/PCS – TX,RX
ANT3	LB/HB MRD	LTE B5/12/13/17/28 LTE 7 W5/8 GSM850/EGSM– RX
ANT4	MB MRD	LTE B2,4,66 W2/4 DCS/PCS – RX
ANT5	GPS	GPS
ANT6	WIFI	2.4G



Antenna	Mode	Band
ANT1	Main LB	LTE B5/12/13/17/28 W5/8 GSM850/EGSM – TX,RX
ANT2	Main MB/HB	LTE B2,4,7,66 W2/4 DCS/PCS – TX,RX
ANT3	LB/HB MRD	LTE B5/12/13/17/28 LTE 7 W5/8 GSM850/EGSM– RX
ANT4	MB MRD	LTE B2,4,66 W2/4 DCS/PCS – RX
ANT5	GPS	GPS
ANT6	WIFI	2.4G

SAR Test Setup Photographs

■ **Test Setup Photo (Left All)**



■ Test Setup Photo (Left Touch/Tilt)



■ **Test Setup Photo (Right All)**



■ **Test Setup Photo (Right Touch/Tilt)**



■ Test Setup Photo (Body All)



■ **Test Setup Photo (Rear)**



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Front)



[Distance of **1.0 cm** from the EUT]

■ Test Setup Photo (Left)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo (Right)



[Distance of 1.0 cm from the EUT]

■ Test Setup Photo(Top)



[Distance of 1.0 cm from the EUT]

■ **Test Setup Photo(Bottom)**



[Distance of 1.0 cm from the EUT]