

STAGE LIGHTING

BRIEF INTRODUCTION

QS-003

Technical Specification

Power source: AC120V 60Hz

Power: Max. 5W when flashing.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using.
- **READ AND FOLLOW ALL SAFETY INSTRUCTIONS**
- **DANGER —** To reduce the risk of electric shock, always unplug this flash light from the electrical outlet before cleaning.
- **WARNING —** To reduce the risk of burns, fire, electric shock, or injury to persons:
 1. Unplug from outlet before putting on or taking off parts.
 2. Close supervision is necessary when this flash light is used by, or near children, invalids, or disabled persons.
 3. Use this flash light only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
 4. Never operate this flash light if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the flash light to a service center for examination and repair.
 5. Keep the cord away from heated surfaces.
 6. Never operate the flash light with the air openings blocked. Keep the air openings free of lint, hair, and the like.
 7. Never drop or insert any object into any opening.
 8. Do not use outdoors.
 9. To disconnect, turn all controls to the off position, then remove plug from outlet.
- This flash light is intended for use in a dry, indoor place. Installation and use shall be strict accordance with relevant instructions in this manual.
- Do not place the flash light onto wet or uneven surfaces. Accidental falls may cause fire.
- Do not put this flash light on a wet or uneven surface and avoid shock.
- Disconnect this flash light from power immediately in case of malfunction. Do not resume use until it's repaired.
- Please unplug the power cord if you want to stop use of this unit for a long time.
- Please keep this flash light out of reach of little children or pets.
- Not for children playing.
- Do not strip the parts lest of electric shock.
- **SAVE THESE INSTRUCTIONS**

Use & Maintenance Instructions

- HOW TO USE
 1. Adjust the handle of flash light to the lowest position (reference to figure 1).
 2. Put this product onto a clean, stable and horizontal surface carefully (reference to figure 1), such as a table-top or cabinet-top, and connect to power.
 3. Then the flash light will start to blink. You can use the speed control potentiometer to control potentiometer to control the blinking frequency. The speed will be increased when the potentiometer knob is turned clockwise, and decreased when the knob is turned counterclockwise.
- PRODUCT CONTAINS THREE COLOR FILMS, RED, BLUE AND GREEN.
- HOW TO ASSEMBLE COLOR FILM
 1. Unscrew and remove the clear lens.- (reference to figure 2)
 2. Place color film onto side of clear lens facing flashing strobe then tighten it by screw. - (reference to figure 3)
- MAINTENANCE
 1. Unplug this flash light from the electrical outlet before cleaning.
 2. Do not wet any electric parts of this flash light. Please use a dry, soft cloth instead of sharp tools for cleaning.

WARNING:

1. To reduce the risk of electric shock, this flash light has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.
2. The handle use for taking only, do not for wall or ceiling mounting.

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Consumer ISM equipment, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.”

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.”

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. ”

This device complies with Part 18 of the FCC Rules. This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz

Importer: Seasonal Visions International Ltd. Address: 5701 Hollis Street, Emeryville, California 94608 USA




Figure 1




Figure 2




Figure 3