

Pencllic[®]

www.pencllic.se



EN

Welcome to the quick guide.
Penclic Mini Keyboard combines ergonomically sound design with modern keyboard technology to bring you comfort and efficiency.

Penclic Mini Keyboard setup

Insert the rechargeable batteries and start charging with the included micro-USB charging cable.
Insert the Nano-USB receiver into the USB port, then set the keyboard power switch on the bottom of the keyboard to ON.
Driver installation starts automatically.
The wireless connection activates automatically.

How to use your Penclic Mini Keyboard

Penclic Mini Keyboard K2 (wireless) has 1 LED indicating battery status.

LED behavior	Indication
1 red flash	The keyboard on/off switch was set to on.
LED flashes red repeatedly	Recharge your battery. (NOTE: Do not recharge non-rechargeable batteries.)
LED flashes green repeatedly	Battery is currently being recharged.
LED is constantly green	Battery is currently being recharged.

Num Lock activates the numpad functions which is the smaller orange numbers.
Special functions (blue text) activated by holding the Fn key and then pressing:

Fn +	Function
F2	Mute
F3	Lower volume
F4	Higher volume
F9	Pause/Break
F10	Scroll Lock
F11	Num Lock
F12	Print Screen
Delete	Insert
Up arrow	Page Up
Left arrow	Home
Down Arrow	Page Down
Right Arrow	End

Technical specifications

- The supported platforms for Penclinc Mini Keyboard are all operating systems that support HID 1.1. These include Windows XP or later, Mac OS X version 10.1 or later and most Linux/BSD flavors. No extra software/driver installation is needed.
- Connection USB.
- AAA 1.2V NiMH Recharging battery (Everyday use last approximately 2 months before charging is needed).
 - Charging via USB .
- LR 03/AAA/1.5V Alkaline None rechargeable battery can be used. NOTE: DO NOT RECHARGE.
- Nano USB-receiver 2,4GHz.
 - Wireless reach, minimum 5 metres
 - Connection via USB .
- Energy saving mode starts after 10 min, press a button to start.
- MAC operating systems do not support all the special functions.

Measurements

- Height: 6 mm (21 mm at top).
- Base: 285 x 162 mm.
- Weight: 381g including 1.4m cable.

Troubleshooting

- Make sure the Penclinc Mini Keyboard USB connector is firmly attached to the computer's USB port.
- Un-plug and re-plug the Nano-USB receiver.
- Connect to another USB port.
- Connect to another computer.
- Check the battery.

Technical support

Should you require additional technical support with your Penclinc®, please use our Web site (www.penclinc.se) for further information or contact our support group through e-mail. Call Technical Support during business hours, Central European time [UTC+1].

Contact
+ 46 8 544 98 995
contact@penclinc.se



FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device complies with Industry Canada RSS-210 standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.