

# ZelHer® P30<sub>a</sub>



**USER GUIDE**

## ZelHer P30a

Thank you for choosing the ZelHer P30a Bluetooth headset, please examine the contents of the package to ensure that you have received all items, please read the entire full user guide before using the headset.

### PACKAGE CONTENTS

- P30a Bluetooth headset
- USB Cable
- User Guide


## User Guide for P30a

### KEY SPECIFICATIONS

#### Model P30a

- Bluetooth v4.1
- 26 Hours: Talk Time
- 750 Hours: Standby time
- Enhanced Battery Saver (EBS) Extending battery live up to 8 months
- Working Range: 33ft
- Multipoint Support: (Pair and keeps connections with 2 Bluetooth devices)
- Balanced and Lite Weight
- Fits Comfortably on Either Ear
- Supporting profiles: Headset Profile (HSP), Hand-Free Profile (HFP), Advanced Audio Distribution Profile (A2DP), Audio/Video Remote Control Profile (AVRCP)

## ABOUT YOUR ZELHER P30a



- 1** Volume Up  
Volume Down
- 2** Multifunction Button
- 3** Indicator LED
- 4** USB Charge slot

## GETTING STARTED

- It is important to fully charge the headset, before starting the pairing process before initial use.
- Recommended Initial charge time is 3-5 hours.
- Do not use the headset while charging.

### Note:

- If you do not use your headset for a long period of time, it is recommended to recharge the headset for at least 3-5 hours before resuming use.
- Recharge unit in places at room temperature between 41°F (5°C) and 104°F (40°C).

## **CHARGING THE HEADSET**

### **To Charge the unit:**

1. Connect the large end of the USB cable into charger port.
2. Connect the small end of the USB cable into headset charging port.
3. Plug the charger into a proper outlet.
4. While charging, the indicator light on headset will turn red, when charging is complete; the indicator light will change to blue, flashing once every 10 seconds.

**Turning on:**

Press and hold the Multi-function button (MFB) for 3-5 seconds, the blue light indicator will flash 3 times, and you will hear a voice prompt saying “Power on”.

**Turning off:**

Press and hold the MFB for 3-5 seconds; the red light indicator will flash 3 times, and you will hear a voice prompt saying “Power off”.

**PAIRING THE HEADSET:****Pairing to 1 device**

1. Press and hold the MFB for approximately 6-8

seconds, until the LED light alternates between red and blue, you will hear a voice prompt saying “pairing” indicating that it is in pairing mode.

2. Activate the Bluetooth search feature on your phone; refer to your phone’s manual for further instructions.

3. Select the P30 from the list of devices detected on your phone or computer.

4. If necessary enter pin code 0000 and accept connection.

5. When pairing is complete, you will hear a voice



prompt saying “your headset is connected” and the LED will flash blue indicating that your Bluetooth headset is connected to your phone.

**Pairing a 2nd Device:**

1. Pair the first phone following the steps above.
2. Temporarily turn off the first connected phone's Bluetooth wireless technology function.
3. Pair the second phone using the steps above.
4. Turn off the headset, and once again turn on the first phone's Bluetooth wireless technology functionality.

5. Once again turn on the headset, and it will reconnect to both devices automatically.

### **GENERAL FUNCTIONS:**

#### **Turning on:**

Press and hold the MFB for 3-5 seconds; the blue light indicator will flash 3 times and you will hear a voice prompt saying "Power on". The headset will automatically attempt to connect with the last device to which it was paired. Once connected, you will hear a voice prompt saying "your headset is connected", and the blue light will blink once every 10 seconds.

**Turning off:**

Press and hold the MFB for 3-5 seconds; the red light indicator will flash 3 times and you will hear a voice prompt saying “Power off. Your headset is disconnected”.

Whenever your Bluetooth gets disconnected from other Bluetooth devices, a voice prompt will say “Your headset is disconnected”.

When Bluetooth gets disconnected, the Enhanced battery saver (EBS) mode will automatically turn on.

**Adjust the volume:**

Press Volume + or – while on a call or streaming audio.

**Incoming call / Ending a call:**

Simply Press the MFB once.

**Reject a call:**

Press and hold MFB for 3 seconds.

**Redial:**

Press the MFB twice.

**Voice dial /Voice Control:**

Press the MFB for 2 seconds and wait for the phone

prompt for voice dialing and other voice controls

Voice control feature will use the last paired device, for example if you pair device A and device B the voice dial will jump to device B.

### **Mute On/Off:**

Press and hold the (-) volume button for 2-3 seconds and a voice prompt will say "Mute on." To unmute, Press and hold (-) volume button again for 2-3 seconds and a voice prompt will say "Mute off".

You will hear a double beep every 15 sec. while your Bluetooth is on mute.

**Play Audio:**

Press and hold the (+) volume button for 2-3 seconds to turn on your audio. Press and hold again the (+) volume button for 2-3 seconds to turn off.

**Wearing the Headset:**

This headset can be worn on either ear and can be adjusted according to your preference and comfort.

**Low Battery Warning:**

When battery will reach to only 10% of power, the indicator light will begin to blink red and you will hear a voice prompt saying “low battery” every 30 seconds.

### **Enhanced Battery Saver (EBS):**

Extending battery life up to 8 months

When Bluetooth power is on without being connected to any paired Bluetooth device, the blue light will start to blink twice every 5-6 seconds for approximately 10 minutes, signaling that device will automatically turn off after 10 minutes of not getting any paired Bluetooth connection.

### **Keep your Battery alive:**

- For ideal charge capacity and extended battery life, do not overcharge your Bluetooth headset; wait until you get the Low battery warning signal.

- Make sure to keep this product within the recommended temperature range of -4°F (-20°C) and 104°F (40°C).

### **Getting out of 32 feet distance:**

When your Bluetooth headset gets out of the 32 feet distance from your other Bluetooth device, you will hear a double beep every 10 seconds signaling that you are out of the 32 ft. range, after 10 minutes of being out of range, your device will automatically revert to EBS mode.



**Headset Storage:**

- Only use original accessories with this device.
- Do not disassemble headset, it will void the warranty.
- Store headset away from dust, heat, and water.
- Use clean, soft, static free cloth to clean headset surfaces.
- Do not allow children to play or use headset.
- Do not store headset or charger in extreme environments.

## Fifth Avenue Accessories Corp. Limited Warranty

All Zelher Bluetooth headsets carry a one year limited warranty, from date of purchase.

Fifth Avenue Accessories Corp. Warrants this headset will be free from defects in materials and workmanship for a period of one year from the date of purchase.

During the first year, we will at our option, repair or replace this product or any defective parts, free of charge.

Consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions are not included in this one-year warranty.

We recommend that you keep the original shipping materials, as it is important that the product will not be damaged during shipping.

To obtain Warranty Service, please contact us at [warranty@zelher.com](mailto:warranty@zelher.com) or by calling 866-783-4546.

The following information must be presented to obtain Warranty Service, (1) Proof of purchase, which clearly indicates the name of the dealer, the product type, the date of purchase, name and address of purchaser, (2) the Bluetooth headset.

Consumer will be responsible for shipping or transportation charges to us.

Products returned to Fifth Avenue Accessories Corp. For repair under this warranty will be return shipped to the customer at our expense.

The warranty does not cover damage caused by accident, direct and indirect, misuse or abuse, neglect, improper operation, unauthorized product modification or repairs, or any cause other than defects in the materials or workmanship of Fifth Avenue Accessories Corp.'s products.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d' Industrie Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :1) l' appareil ne doit pas produire de brouillage;2) l' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d' en compromettre le fonctionnement.

- Do not install this equipment in a confined or building-in space such as a book case or similar unit, and remain a well ventilation conditions at open site. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.;

- **WARNING:** The batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

- No naked flame sources, such as lighted candles, should be placed on the apparatus.

- The product is designed to use in moderate climates



- Correct Disposal of this product. This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Fifth Avenue Accessories Corp.

P O BOX 1002,  
Harriman, NY 10926

**P.866.783.4546**

[www.zelher.com](http://www.zelher.com)

[info@zelher.com](mailto:info@zelher.com)

